

WORK PROCEDURE

PRO-MEC-005A

DISMANTLING THE CUBEX FOR SLINGING

OBJECTIVES

The objective of this procedure is to provide safe methods for dismantling the CUBEX to move it and/or sling it.

APPLICATION

This procedure applies to all employees of MACHINES ROGER INTERNATIONAL, and to all others involved persons from the clients.

INTERPRETATION

The personnel with authority for the interpretation of this document is the maintenance director. Any request for modification, revision or update must be made to this person.

RESPONSABILITIES

The supervisor is responsible for supervising the work and ensuring that the procedure is followed.

Assembly and disassembly work must always be done by a competent worker (mechanic or supervisor).

The worker must follow the procedure. If a situation arises and it is not covered in the procedure, a risk analysis must be carried out.

NECESSARY EQUIPMENT

- Lifting equipment
- Manitou or any other equipment with forks with 7000 lbs capacity
- 6-ton winch
- 6-ton chain hoist
- Come along
- 6-ton slings
- Lifting hand (customer's engineer's plans and specifications)

DISMANTLING THE CUBEX FOR SLINGING

Prior to any dismantling or assembly of the CUBEX, a visit must be made to the site where the work is to be carried out. In addition to assessing the installations and lifting equipment, this visit will enable us to establish the order of arrival of parts before assembly, and of exit after dismantling of the CUBEX.

PROCEDURE

NEVER POSITION YOURSELF UNDER A LOAD DURING LIFTING AND SLINGING OPERATIONS

The procedure PRO-MEC-001A Dismantling of the mast must be applied to remove the mast.

- 1- Position the CUBEX correctly, in a safe place;
- 2- Apply the lockout procedure;
- 3- Disconnect the ANSUL system;
- 4- Close the hydraulic pump suction valves and cap the return block;
- 5- An electrician must disconnect the electric motor;
- 6- Dismantle the slide-over and actuator using lifting equipment.
- 7- **Remove:**
 - a. The metal plates on the top;
 - b. The frame;
 - c. The compressor by attaching a choke sling to the center head and using lifting equipment;
 - d. The hydraulic pump and electric motor can be removed together. Slings should be attached to the motor ring and pump in choking position **to balance the load.**
- 8- Disconnect the DEUTSCH connectors under the electrical panel;
- 9- Remove the hydraulic tank with basket slings;

DISMANTLING THE CUBEX FOR SLINGING

- 10- Attach the hoses and secure the components;
- 11- Install the parts to be moved on carts;
- 12- Turn the drill on its side by attaching itself to one of the tractions;
- 13- Leave the traction attached to the slings;
- 14- Secure the drill with air chain hoists;
- 15- Unbolt the upper traction on which you are attached;
- 16- Remove the unbolted traction;
- 17- Unbolt the bottom traction;
- 18- Lift the drill from the anchors determined by supervision;
- 19- Place the drill on the "SKID".

Movements in the drift and equipment to do it are the responsibility of the mine.

Slinging in the shaft is the responsibility of the mine.

For reassembly, use this procedure and reverse the process.



Karl Béchard
Maintenance Manager

Adds or modifications	Date	By
Complete update and remove the specification for GARSON in the title because the procedure will be used on other contracts	November 2023	S. Tremblay D. Baribeault K. Béchard
Add the visit of the workplace before carrying out the work	January 2024	S. Tremblay JF Gagnon
Translation review	May 2024	S. Tremblay R. Harrower