

WORK PROCEDURE

PRO-MEC-SM-001

PROCEDURE TO CHANGE THE FEED CYLINDER ON ALL 9000 SERIES STOPEMASTERS

OBJECTIVE

The objective of this procedure is to define safe manner to change a feed cylinder on a STOPEMASTER

APPLICATION

The procedure applies to all the employees of MACHINES ROGER INTERNATIONAL.

INTERPRETATION

The person with authority for the interpretation of this document is the Maintenance Manager. Any request for modification, revision or update must be made to this person.

RESPONSABILITIES

The worker is responsible for applying this procedure when changing the feed cylinder. The supervisor or a mechanic, must be there when this job is done. The supervisor name a leader of the job.

PROCEDURE

- 1- Once you have decided that the feed cylinder needs to be changed, remove the drill and carriage;
- 2- Barricade the accesses of your workplace.

WARNING

**IF THE GROMMETS ARE MISSING OR WORN OUT, THE CYLINDER COULD
FALL OUT ONCE THE CARRIAGE PLATE IS REMOVED.**

- 2- Place drill and carriage plate so they are not a tripping hazard;
- 3- Rotate the feed boom to a horizontal position, with the damaged cylinder on the bottom of the feed boom;

PROCEDURE TO CHANGE THE FEED CYLINDER ON ALL 9000 SERIES STOPEMASTERS

- 4- Remove the protective cap over the rod end;
- 5- Remove and cap the hydraulic hoses so oil does not leak out;
- 6- Coil and put the hoses back in a safe place;
- 7- Using a pipe wrench rotate the rod end (square block with hydraulic fitting) counter clockwise until the rod comes loose from the cylinder;
- 8- Pull the rod back about 3 or 4 inches;
- 9- Knock out the rubber grommet located in the horseshoe;
- 10-Now free the other end of the cylinder by pulling its rod end back from the horse shoe on that end and knock out that rubber grommet also;
- 11-Lift the feed cylinder out of the feed boom by lifting it out of the horseshoes, which once held the rubber grommets;
- 12-Use proper lifting techniques and watch for pinch points;
- 13-Place the damaged cylinder where it will not be a tripping hazard.
- 14-Being very careful and watching for pinch points install the centralizer end first of the replacement feed cylinder;
- 15-Install the rod ends so that the rods are sitting in the horseshoe;
- 16-Install the grommets onto the rods and slide them into position so they are entering into the horseshoe;
- 17-Push the loose rod end in and begin to thread it into the cylinder. Be careful not to cross thread while aligning the coupling;
- 18-Thread it in until the grommets enter the horseshoes on each end of the cylinder and tighten the rod end so the hydraulic fitting is in the proper position;
- 19-Replace the hydraulic hoses and the protective cap;
- 20-Rotate the feed boom to its vertical position and replace the drill and carriage plate;

Karl Béchard
Maintenance Manager