

WORK PROCEDURE

PRO-OP-DD-005A

DISMANTLING AND REASSEMBLING A CLAMP AND A CHUCK ON A DIAMOND DRILL

OBJECTIVE

The purpose of this procedure is to define the safe methods for disassembling and reassembling a clam or chuck on the drill.

APPLICATION

This procedure applies to all employees of **MACHINES ROGER INTERNATIONAL**.

INTERPRETATION

The person with authority for the interpretation of this document is the Operations manager. Any request for modification, revision or update must be made to this person.

RESPONSIBILITIES

The worker is responsible to apply this procedure for disassembling and reassembling a clamp and a chuck on the drill. The supervisor is responsible to make sure that the workers respect this procedure

MATÉRIEL NÉCESSAIRE	OUTILS NÉCESSAIRES
9 Bolts ½ X 2" 1/4	Wrench ¾"
Chuck springs	Ratchet with socket ¾"
All other parts to be changed	Torque wrench
	Wrench 1" 1/8

PROCEDURE

1. Make sure the controls to lock the clam or chuck are in the closed position **so that the springs are stretched as far as possible**



DISMANTLING AND REASSEMBLING A CLAMP AND A CHUCK ON A DIAMOND DRILL

1. Make sure the jaws in the clam or chuck are in closed position.
2. Lock the drill using the lockout procedure.
3. Unscrew the 6 bolts $\frac{3}{4}$ " with a 1 $\frac{1}{8}$ " key from the cover of the jaws (jaws)



5. Remove the nine half inch with a $\frac{3}{4}$ key from the cover.



6. Remove the three half inch bolts with a $\frac{3}{4}$ key with the bushing on the cone and put them back without the bushing to prevent the cone projection.

Without the bushings



DISMANTLING AND REASSEMBLING A CLAMP AND A CHUCK ON A DIAMOND DRILL

7. Remove the last six $\frac{1}{2}$ bolts with a $\frac{3}{4}$ key in the order shown in the picture.
It is important to unscrew the bolts only 1 turn at a time, following the order in the picture, the springs are crushed $\frac{1}{4}$ inch.



8. Unscrew the last 3 bolts



DISMANTLING AND REASSEMBLING A CLAMP AND A CHUCK ON A DIAMOND DRILL

9. Change the parts to be changed (eg: springs, chuck bowl, piston);
10. Thoroughly clean both sides of the cover before replacing it;
11. To replace the piston, it is important to replace these 3 bolts at the beginning and then follow the order of tightening of step # 7, by screwing 1 turn at a time, so as not to crush the springs just side to side ;
12. As soon as the 9 ½ by 2 ¼ bolts are removed from a chuck, you must change them all;
13. The 9 bolts must be tightened with the torque wrench to

105 lbs / foot

Ajouts ou modifications	Date	By
Change title adding reassembling	May 15th 2021	S. Tremblay
Added tools and equipment	May 15th 2021	S. Tremblay
Added points 9, 10, 12 et 13	May 15th 2021	S. Tremblay



Christian St-Amour
Directeur des opérations