FRANMARINE UNDERWATER SERVICES PTY LTD

WINCH OPERATIONS

Procedure

MV INTEGRITY III | UVI: 414562

Marine Order 504 (2024) — Schedule 1 Compliance

Document Number:	FUS-SMS-INT3-05I
Revision:	01
Date:	7 July 2026
Author:	Matthew Hilder
Reviewed By:	Belinda Brooks
Approved By:	Kirby Hamilton
Vessel:	MV Integrity III (UVI 414562)

DOCUMENT CONTROL

Revision History

Rev	Date	Author	Description	Approved
01	7 July 2026	M. Hilder	Initial issue	K. Hamilton

Approval

Role	Name	Date
Author	Matthew Hilder	7 July 2026
Reviewed	Belinda Brooks	7 July 2026
Approved	Kirby Hamilton	7 July 2026

Review Frequency

This document shall be reviewed at least every 12 months, or sooner following a significant incident, change of operations, vessel modification, or change in applicable legislation.

Controlled Distribution

This document is a controlled distribution issued from the Franmarine document management system (DMS), which holds the master record, revision history, and approval log. The controlled digital copy is located in the vessel's SharePoint folder. Printed or downloaded copies are uncontrolled; refer to the SMS Document Register for the current revision status.

TABLE OF CONTENTS

1. PURPOSE AND SCOPE

This procedure establishes the safe operating procedure for the 5-tonne capacity winch fitted to MV Integrity III.

1.1 Regulatory Reference

Marine Order 504 (2024), Schedule 1, Clause 11(5). WHS Regulation 2017 (NSW), Chapter 4.

2. GENERAL REQUIREMENTS

- Only trained and competent personnel shall operate the winch.
- The winch shall not be loaded beyond its safe working load (SWL) of 5 tonnes.
- All lifting equipment (slings, shackles, hooks) shall be inspected before each use and shall have current test certificates.
- A designated signaller shall be appointed when the winch operator cannot see the load.
- No person shall stand in the bight of a line under tension.
- No person shall stand or walk under a suspended load.

3. PRE-OPERATION CHECKS

- Visually inspect the winch for damage, corrosion, or oil leaks.
- Check the wire rope for broken wires, kinks, or bird-caging.
- Test the winch brakes and clutch.
- Confirm the winch power source is operating correctly.
- Verify the load to be lifted does not exceed the SWL.
- Establish an exclusion zone around the lifting area.

4. OPERATING PROCEDURE

- Attach the load using appropriate certified lifting gear.
- Take up slack slowly. Check the attachment before lifting.
- Lift the load smoothly and steadily. No sudden or jerking movements.
- Control the load at all times. Use tag lines to prevent swinging.
- Lower the load under control. Do not free-spool.
- When the load is landed, release tension before disconnecting lifting gear.

5. POST-OPERATION

- Power down the winch.
- Stow the wire rope neatly on the drum.
- Secure the hook or pendant.
- Report any defects to the master and record in the vessel logbook.

6. REFERENCES

- FUS-SMS-INT3-07 Maintenance
- Winch manufacturer's operating manual
- Marine Order 504 (2024), Schedule 1, Clause 11(5)