FRANMARINE UNDERWATER SERVICES PTY LTD

FLOODING

Emergency Procedure

MV INTEGRITY III | UVI: 414562

Marine Order 504 (2024) — Schedule 1 Compliance

Document Number:	FUS-SMS-INT3-06I
Revision:	01
Date:	7 July 2026
Author:	Matthew Hilder
Reviewed By:	Belinda Brooks
Approved By:	Kirby Hamilton
Vessel:	MV Integrity III (UVI 414562)

DOCUMENT CONTROL

Revision History

Rev	Date	Author	Description	Approved
01	7 July 2026	M. Hilder	Initial issue	K. Hamilton

Approval

Role	Name	Date
Author	Matthew Hilder	7 July 2026
Reviewed	Belinda Brooks	7 July 2026
Approved	Kirby Hamilton	7 July 2026

Review Frequency

This document shall be reviewed at least every 12 months, or sooner following a significant incident, change of operations, vessel modification, or change in applicable legislation.

Controlled Distribution

This document is a controlled distribution issued from the Franmarine document management system (DMS), which holds the master record, revision history, and approval log. The controlled digital copy is located in the vessel's SharePoint folder. Printed or downloaded copies are uncontrolled; refer to the SMS Document Register for the current revision status.

TABLE OF CONTENTS

1. PURPOSE

This procedure establishes the actions to be taken in the event of flooding or uncontrolled water ingress on MV Integrity III.

1.1 Regulatory Reference

Marine Order 504 (2024), Schedule 1, Clause 12. NSCV Part G Ch 3 Table 1 (Bilge Pumps).

2. DEWATERING CAPABILITY

Per the NSCV Part G Ch 3 Table 1, MV Integrity III (7.68 m measured length, 7.5-13 m length band) carries the following dewatering equipment:

- Two manual bilge pumps, each rated 4.0 kL/hr, located on the transom (one port, one starboard).
- Bailing buckets are also carried onboard and can be used in conjunction with the bilge pumps where practical, particularly in situations where the rate of ingress exceeds the bilge pump capacity or where pumps are obstructed by debris.

All dewatering equipment shall be maintained in serviceable condition and tested as part of the pre-departure checks.

3. IMMEDIATE ACTIONS

- Identify the source of the flooding if possible.
- Operate both manual bilge pumps and locate and stem the ingress; keep the master informed.
- If ingress exceeds pumping capacity, deploy the bailer and portable pump, prepare to abandon to the liferaft or dinghy, don lifejackets, and issue a MAYDAY on VHF Ch 16 with the vessel name and UVI.
- Use bailing buckets in addition to the bilge pumps if practical — particularly effective for large-volume ingress where pump capacity is being exceeded, or if debris is clogging the pump strainers.
- If the source can be identified, attempt to stop or reduce the ingress (bungs, soft plugs, rags, damage control patches).
- All persons don lifejackets.

4. MASTER'S ACTIONS

- Assess the rate of water ingress against the combined dewatering capacity (pumps plus bailing).
- If dewatering is keeping up with ingress, proceed to the nearest safe berth at reduced speed.
- If dewatering is not keeping up, issue a MAYDAY on VHF Ch 16 immediately. Advise the relevant port authority (refer FUS-SMS-INT3-05J for VHF channels).
- Head for the nearest shore, shallow water, or berth where the vessel can be safely beached.
- Prepare life-saving equipment for deployment (lifebuoy with self-activating light, EPIRB, pyrotechnic distress signals).
- If sinking is imminent, activate the EPIRB and abandon vessel (refer FUS-SMS-INT3-06 Emergency Plan).

5. COMMON CAUSES

- Missing or dislodged bungs.
- Hull damage from collision, grounding, or impact with debris.
- Failed hull fittings (through-hulls, transducer, cable glands).
- Hose connection failure.
- Overtopping in heavy seas.

6. POST-INCIDENT

- Once the vessel is secured and the flooding is controlled, inspect the hull thoroughly.
- Do not return to service until the cause is identified and repaired.
- Report to the East Coast Operations Superintendent.
- Record all details in the vessel logbook.
- Complete an incident report.
- Report to AMSA if applicable.

7. REFERENCES

- FUS-SMS-INT3-06 Emergency Plan
- FUS-SMS-INT3-06G Collision Emergency Procedure
- FUS-SMS-INT3-06H Grounding Emergency Procedure
- NSCV Part G Ch 3 Table 1 (Bilge Pumps)
- Marine Order 504 (2024), Schedule 1, Clause 12