FRANMARINE UNDERWATER SERVICES PTY LTD

CRANE OPERATIONS

Procedure

MV ROHANI | UVI: 457394 | Class 2C

Marine Order 504 (2024) — Schedule 1 Compliance

Document Number:	FUS-SMS-ROH-05I
Revision:	01
Date:	7 July 2026
Author:	Matthew Hilder
Reviewed By:	Belinda Brooks
Approved By:	Kirby Hamilton
Vessel:	MV Rohani (UVI 457394)

DOCUMENT CONTROL

Revision History

Rev	Date	Author	Description	Approved By
01	7 July 2026	Matthew Hilder	Initial release	

Approval

Role	Name	Date
Author	Matthew Hilder	7 July 2026
Reviewed	Belinda Brooks	7 July 2026
Approved	Kirby Hamilton	7 July 2026

Review Frequency

This document shall be reviewed at least every 12 months, or sooner following a significant incident, change of operations, vessel modification, or change in applicable legislation.

Controlled Distribution
This document is a controlled distribution issued from the Franmarine document management system (DMS), which holds the master record, revision history, and approval log. The controlled digital copy is located in the vessel's SharePoint folder. Printed or downloaded copies are uncontrolled; refer to the SMS Document Register for the current revision status.

1. PURPOSE AND SCOPE

This procedure establishes the requirements for the safe operation of the deck crane on MV Rohani, including pre-start checks, lifting operations, diver recovery, and stowage for transit.

1.1 Equipment

Crane: Unic UB-V504J (Serial Number B701009), 3.5 tonne capacity. Serviced annually by Maxilift Australia. The crane is also used as the primary diver recovery system via a recovery pulley arrangement.

1.2 Regulatory Reference

Marine Order 504 (2024), Schedule 1, Clause 11(5). Certificate of Survey COS-94585-003 conditions: crane and vessel to be operated in accordance with the approved stability book. Lifting operations in smooth and partially smooth waters only.

2. PRE-START CHECKS

The following checks shall be completed before any crane operation. These checks are also captured in the Deck Hiab Pre-Start QR code form.

(a) Visually inspect the crane structure, controls, welds, motor, mounting bracket, fixings, hook block, and wire rope for damage or defects.

(b) Confirm load charts, safety labels, warning labels, and control labels are present and legible.

(c) Confirm the crane has been serviced within the last 12 months.

(d) Check hydraulic fluid levels (46 Weight fluid only).

(e) Inspect hydraulic system for leaks.

(f) Assess weather and swell conditions against the stability book limits for lifting operations. Lifting is permitted in smooth and partially smooth waters only.

(g) Confirm hook safety latch is functioning and in good condition.

(h) Inspect all rigging gear for condition and confirm tags are current.

(i) Confirm crane was previously stowed correctly for travel. Never drive the vessel with the boom extended.

(j) Confirm the crane battery isolator is in the OFF position before starting the crane hydraulic system.

3. CRANE START-UP

(a) Ensure the vessel is stationary and stable (spud legs deployed or securely moored where practicable).

(b) Switch crane battery isolator to ON.

(c) Start the crane hydraulic power unit.

(d) Allow the system to warm up for a minimum of 2 minutes.

(e) Test all crane functions at low speed: slew, luff, extend/retract boom, hoist up/down.

(f) Confirm all movements are smooth and no unusual noises, vibrations, or hydraulic leaks are present.

4. LIFTING OPERATIONS

(a) Determine the load weight before lifting. Do not exceed the crane's safe working load (SWL) for the boom radius and configuration as shown on the load chart and the approved stability book.

(b) The master shall consult the approved stability book and confirm that the planned lift is within the vessel's stability limits for the current loading condition and sea state.

(c) Establish an exclusion zone around the lift area. No personnel shall stand beneath a suspended load.

(d) Use tag lines to control load swing where practicable.

(e) Lift loads smoothly — avoid sudden starts, stops, or slewing with a suspended load.

(f) Do not drag loads sideways with the crane.

(g) If conditions change (wind, swell, vessel motion), cease lifting operations and secure the crane.

5. DIVER RECOVERY

MV Rohani uses a recovery pulley system rigged on the crane boom to recover divers from the water. The crane is certified safe for use as a recovery system (Maxilift Australia inspection, August 2025).

(a) Rig the recovery pulley system on the crane boom before the diver enters the water.

(b) Test the recovery system under no-load conditions before the dive commences.

(c) When recovering a diver, hoist slowly and smoothly. The diver shall signal readiness before recovery commences.

(d) A dedicated crew member shall operate the crane during diver recovery. The crane operator shall maintain visual contact with the diver at all times during recovery.

(e) The vessel's engines shall be placed in neutral before the diver approaches the vessel for recovery. Engines shall ideally be shut down during recovery.

(f) In an emergency, the recovery system may be used to extract an incapacitated diver. Follow the emergency procedures in FUS-SMS-ROH-06B Person Overboard.

6. CRANE SHUT-DOWN AND STOWAGE

(a) Lower any suspended load to the deck and disconnect rigging.

(b) Retract the boom fully and lower to the stowed position in the crane rest.

(c) Shut down the hydraulic power unit.

(d) Switch the crane battery isolator to OFF.

(e) Secure the boom with the stowage pin/lashing. The vessel must never transit with the boom extended or unsecured. Note: when transiting with spud legs installed (sheltered waters only), ensure the crane boom is fully stowed and does not add to the overall vessel height.

7. REFERENCES

FUS-SMS-ROH-05A Pre-Departure Checks

FUS-SMS-ROH-05H Diving Operations

FUS-SMS-ROH-05L Spud Leg Operations

Approved Stability Book (must be onboard)

Unic UB-V504J Operator’s Manual