FRANMARINE UNDERWATER SERVICES PTY LTD

CONFINED SPACE ENTRY

Procedure

MV ROHANI | UVI: 457394 | Class 2C

Marine Order 504 (2024) — Schedule 1 Compliance

Document Number:	FUS-SMS-ROH-05N
Revision:	01
Date:	7 July 2026
Author:	Matthew Hilder
Reviewed By:	Belinda Brooks
Approved By:	Kirby Hamilton
Vessel:	MV Rohani (UVI 457394)

DOCUMENT CONTROL

Revision History

Rev	Date	Author	Description	Approved By
01	7 July 2026	Matthew Hilder	Initial release	

Approval

Role	Name	Date
Author	Matthew Hilder	7 July 2026
Reviewed	Belinda Brooks	7 July 2026
Approved	Kirby Hamilton	7 July 2026

Review Frequency

This document shall be reviewed at least every 12 months, or sooner following a significant incident, change of operations, vessel modification, or change in applicable legislation.

Controlled Distribution
This document is a controlled distribution issued from the Franmarine document management system (DMS), which holds the master record, revision history, and approval log. The controlled digital copy is located in the vessel's SharePoint folder. Printed or downloaded copies are uncontrolled; refer to the SMS Document Register for the current revision status.

1. PURPOSE AND SCOPE

This procedure establishes the requirements for safe entry into the engine room of MV Rohani, which is classified as a confined space under Schedule 1, Clause 11(5)(m) of Marine Order 504 (2024). The engine room contains twin Detroit Diesel 6V-92T diesel inboard engines, fuel lines, exhaust systems, and a Firepro FP-5700S aerosol fire suppression system.

2. HAZARD IDENTIFICATION

The following hazards are associated with the engine room:

(a) Oxygen depletion — engines consume oxygen during operation; residual exhaust gases may accumulate.

(b) Toxic/flammable atmosphere — fuel vapours, exhaust gases (carbon monoxide), battery gases (hydrogen).

(c) Fire suppression discharge — the fixed fire-suppression system is designed to discharge into the engine room. A discharged aerosol system will create an atmosphere immediately dangerous to life or health (IDLH).

(d) Hot surfaces — engines, exhaust manifolds, and coolant systems reach high temperatures during and after operation.

(e) Moving parts — belts, pulleys, and rotating machinery present entanglement hazards.

(f) Noise — engine noise in the confined space may exceed safe exposure levels.

3. ENTRY REQUIREMENTS

3.1 Routine Entry (Engines Not Running)

(a) Open all engine room hatches, air intake covers, and outlet covers to establish natural ventilation.

(b) Turn on the engine room blowers and allow a minimum of 5 minutes ventilation before entry.

(c) Confirm no flammable vapours are present (sniff test at the hatch level before descending).

(d) Inform another person onboard before entering the engine room. No one shall enter the engine room alone without another person aware and able to raise the alarm.

(e) Carry a torch. Ensure the engine room lighting is functional.

(f) Do not smoke or use open flames in or near the engine room.

3.2 Entry While Engines Are Running

Entry while engines are running should be avoided where possible. If entry is necessary (e.g. to investigate an alarm or unusual noise):

(a) All ventilation must be running.

(b) Limit the duration of entry to the minimum necessary.

(c) Wear hearing protection.

(d) Do not approach rotating machinery, belts, or pulleys.

(e) Maintain communication with the master or another crew member at all times.

3.3 Entry After Fire Suppression Discharge

If the fixed fire-suppression system has discharged:

(a) DO NOT enter the engine room until the space has been fully ventilated.

(b) Open all hatches and run blowers for a minimum of 30 minutes before entry.

(c) Entry shall only be made with breathing apparatus (SCBA) until the atmosphere has been confirmed safe.

(d) Follow the fire emergency procedure (FUS-SMS-ROH-06A Fire).

4. EMERGENCY PROCEDURES

(a) If a person collapses or becomes unresponsive in the engine room, do not enter to attempt rescue without first ensuring your own safety. Open all hatches and ventilate the space.

(b) Call for assistance immediately. Contact emergency services (000) if required.

(c) If safe to do so, attempt to extract the person from the engine room using a rope or line without entering the space.

(d) Administer first aid once the person is in open air.

5. REFERENCES

FUS-SMS-ROH-05A Pre-Departure Checks

FUS-SMS-ROH-05B Vessel Start-Up and Shut-Down

FUS-SMS-ROH-06A Fire

Firepro FP-5700S aerosol fire suppression system — technical documentation