FRANMARINE UNDERWATER SERVICES PTY LTD

VESSEL START-UP AND SHUT-DOWN

Procedure

MV SEAGULL | UVI: 425689

Marine Order 504 (2024) — Schedule 1 Compliance

Document Number:	FUS-SMS-SGL-05B
Revision:	01
Date:	7 July 2026
Author:	Matthew Hilder
Reviewed By:	Belinda Brooks
Approved By:	Kirby Hamilton
Vessel:	MV Seagull (UVI 425689)

DOCUMENT CONTROL

Revision History

Rev	Date	Author	Description	Approved
01	7 July 2026	M. Hilder	Initial issue	K. Hamilton

Approval

Role	Name	Date
Author	Matthew Hilder	7 July 2026
Reviewed	Belinda Brooks	7 July 2026
Approved	Kirby Hamilton	7 July 2026

Review Frequency

This document shall be reviewed at least every 12 months, or sooner following a significant incident, change of operations, vessel modification, or change in applicable legislation.

Controlled Distribution

This document is a controlled distribution issued from the Franmarine document management system (DMS), which holds the master record, revision history, and approval log. The controlled digital copy is located in the vessel's SharePoint folder. Printed or downloaded copies are uncontrolled; refer to the SMS Document Register for the current revision status.

TABLE OF CONTENTS

1. PURPOSE AND SCOPE

This procedure establishes the engine start-up, post-launch verification, and shut-down procedure for MV Seagull, fitted with a single Yamaha F150XD four-stroke outboard engine running on its specified fuel.

1.1 Regulatory Reference

Marine Order 504 (2024), Schedule 1, Clause 11(5)(a).

1.2 Battery System

MV Seagull is fitted with two batteries (Battery 1 and Battery 2), each with its own isolator switch. A third battery selector switch provides four positions: OFF, 1, 2, or 1+2 (BOTH). Under normal operations the selector is set to 1+2 so that both batteries share the charging and starting load.

2. POST-LAUNCH CHECKS

Immediately after launching the vessel (or after arriving at the vessel if berthed afloat), the following checks shall be completed before starting the engine:

- Confirm the vessel sits well in the water with no unusual list or trim.
- Inspect the vessel for signs of leaks. Check around hull fittings, transom, and bilge area.
- Confirm the bilge system is functioning. MV Seagull is fitted with 1 manual bilge pump (4.0 kL/hr), located midships (per NSCV Part G Ch 3 Table 1). Operate the pump and verify discharge.

3. ENGINE START-UP PROCEDURE

3.1 Battery Isolation

- Switch both battery isolators to ON.
- Set the battery selector switch to 1+2 (BOTH).
- If one battery is known to be flat, select the good battery (position 1 or 2) for starting, then switch to 1+2 once the engine is running and charging.

3.2 Pre-Start

- Confirm engine kill switch lanyards are attached and functional.
- Confirm the outboard is trimmed down to the operating position.
- Confirm gear selector is in NEUTRAL.
- Visually inspect around the outboard for fuel leaks, oil leaks, or debris.

3.3 Starting the Engine

- Turn ignition key to the ON position. Allow the fuel injection system to prime (listen for fuel pump).
- Start the engine. Allow to idle. Immediately check the cooling water tell-tale for steady water flow.
- Confirm the engine idles smoothly with no abnormal noise or vibration.
- If the engine does not start on the first attempt, wait 10 seconds before reattempting. If the engine fails to start after three attempts, do not continue — investigate the cause before further attempts.

3.4 Post-Start Verification

With the engine running at idle, verify the following:

- Engine run test: no strange noises, vibrations, or false starts.
- Cooling system is functioning (steady tell-tale stream from the outboard).
- Oil pressure warning lights are extinguished.
- Battery charging indicator shows normal operation.
- Steering responds correctly.
- Throttle and gear selectors operate smoothly through forward, neutral, and reverse.
- Engine gauges (RPM, temperature, voltage) show normal readings.

Allow the engine to warm up at idle for a minimum of 2 minutes before applying load.

4. OPERATIONAL NOTES

- Do not operate the engine at sustained high RPM until engine oil temperature has reached operating range.
- Monitor the cooling tell-tale periodically throughout the voyage. Loss of tell-tale flow requires immediate investigation.
- If any engine alarm sounds during operation, reduce throttle to idle, assess the situation, and shut down the engine if necessary.
- Operate the engine at an appropriate RPM to maintain steerage and thrust.
- Monitor battery voltage periodically. If the battery is not charging, investigate the charging circuit before the next voyage.

5. SHUT-DOWN PROCEDURE

5.1 At Berth or Mooring

- Reduce throttle to idle.
- Place the gear selector in NEUTRAL.
- Allow the engine to idle for 1–2 minutes to allow cooling.
- Turn the ignition key to OFF.
- Trim the outboard up to the stowed position (if the vessel will remain on a mooring or trailer).

5.2 Battery Isolation

If the vessel will be unattended:

- Set the battery selector switch to OFF.
- Switch both battery isolators to OFF.

If the vessel will be attended or on a short stop, the battery selector may remain on 1+2 at the master's discretion.

5.3 Securing the Vessel

- Attach outboard securing straps (if applicable).
- Close all hatches, lockers, and access points.
- Remove or secure all loose equipment.
- Deploy fenders and mooring lines as appropriate (refer FUS-SMS-SGL-05C).
- Check bilge is dry. If water is present, identify the source before leaving the vessel.

6. RECORDS

Engine start-up and shut-down checks are captured as part of the QR code pre-start form and the physical vessel logbook. Any defects or anomalies identified during start-up or shut-down shall be recorded and reported to the East Coast Operations Superintendent.

7. REFERENCES

- FUS-SMS-SGL-05A Pre-Departure Checks
- FUS-SMS-SGL-07 Maintenance
- Yamaha F150XD Owner’s Manual
- NSCV Part G Ch 3 Table 1 (Bilge Pumps)
- Marine Order 504 (2024), Schedule 1, Clause 11(5)(a)