FRANMARINE UNDERWATER SERVICES PTY LTD

LIFEJACKET WEAR

Procedure

MV SEAGULL | UVI: 425689

Marine Order 504 (2024) — Schedule 1 Compliance

Document Number:	FUS-SMS-SGL-05E
Revision:	01
Date:	7 July 2026
Author:	Matthew Hilder
Reviewed By:	Belinda Brooks
Approved By:	Kirby Hamilton
Vessel:	MV Seagull (UVI 425689)

DOCUMENT CONTROL

Revision History

Rev	Date	Author	Description	Approved
01	7 July 2026	M. Hilder	Initial issue	K. Hamilton

Approval

Role	Name	Date
Author	Matthew Hilder	7 July 2026
Reviewed	Belinda Brooks	7 July 2026
Approved	Kirby Hamilton	7 July 2026

Review Frequency

This document shall be reviewed at least every 12 months, or sooner following a significant incident, change of operations, vessel modification, or change in applicable legislation.

Controlled Distribution

This document is a controlled distribution issued from the Franmarine document management system (DMS), which holds the master record, revision history, and approval log. The controlled digital copy is located in the vessel's SharePoint folder. Printed or downloaded copies are uncontrolled; refer to the SMS Document Register for the current revision status.

TABLE OF CONTENTS

1. PURPOSE AND SCOPE

This procedure establishes the lifejacket wear requirements for MV Seagull.

1.1 Regulatory Reference

Marine Order 504 (2024), Schedule 1, Clause 11(5). NSCV C7A. NSW Marine Safety Regulation 2016.

2. LIFEJACKETS CARRIED

MV Seagull carries two types of lifejacket:

- SOLAS lifejackets with self-activating light for 100% complement (all crew and maximum passengers). These are stored in deck storage midships.
- Auto-inflate 150 PFDs worn by crew during routine operations. These are worn on the person and provide Level 150 buoyancy with automatic inflation on immersion.

Both types comply with the NSCV C7A requirement for coastal lifejackets with self-activating light , which exceeds the minimum standard for Class 2D and 2E vessels.

3. MANDATORY WEAR

Lifejackets shall be worn by all persons on board at the following times:

- At all times when the vessel is underway.
- When crossing coastal bars.
- During all embarkation and disembarkation.
- During all mooring, berthing, and unberthing operations.
- During all over-side operations including diving, survey, and inspection.
- During any emergency or when directed by the master.
- In conditions of reduced visibility, heavy weather, or at night.
- When any person is working on the open deck and the vessel is underway.

During routine operations, crew wear the auto-inflate 150 PFDs. The SOLAS lifejackets in deck storage midships are available for passengers, special personnel, and emergency use.

4. INSPECTION AND MAINTENANCE

- Lifejackets visually inspected before each voyage (FUS-SMS-SGL-05A).
- Self-activating lights checked for battery condition and expiry.
- Inflatable lifejackets serviced per manufacturer's recommendations (typically annually).
- Auto-inflate PFD cylinders and bobbins checked and replaced as required.
- Damaged or expired lifejackets removed from service and replaced.

5. STOWAGE

- SOLAS lifejackets stowed in deck storage midships, clearly marked, readily accessible.
- Auto-inflate 150 PFDs assigned to individual crew members and worn on the person.
- Lifejackets shall not be used as cushions, fenders, or for any purpose other than personal flotation.

6. REFERENCES

- FUS-SMS-SGL-05A Pre-Departure Checks
- AS 4758 Personal Flotation Devices
- NSCV C7A
- Marine Order 504 (2024), Schedule 1, Clause 11(5)
- NSW Marine Safety Regulation 2016