
Setup guide for CaptainDMA Fuser






Step one:

Press "Windows key + P" on your second PC and set it to "Extend".



Step two:

Now click right click on an empty space on your desktop and open "Display Settings".



Scroll down and change both PC's resolution to same value. (PLEASE CHECK THE LIST OF SUPPORTED RESOLUTIONS)

Now click on "Advanced display settings".

Make sure to pick Display 1, and set them to same Refresh rate from the drop down menu.

Note: Make sure on your second PC to select the correct display connection to priority!

This step should be checked after the Fuser is ON and combining screens.

Scale and layout

Change the size of text, apps, and other items

100% (Recommended)

Advanced scaling settings

Display resolution



Multiple displays

Multiple displays

Extend these displays

Make this my main display

Advanced display settings

Graphics settings



List of supported resolutions:

- 3840*2160@60HZ
- 2560*1440@144HZ
- 2560*1080@165HZ
- 1920*1080@240HZ

Choose display

Select a display to view or change the settings for it.

Display 1: Dell AW2721D

Display information


	Dell AW2721D Display 1: Connected to NVIDIA GeForce RTX 30	
	Desktop resolution	2560 × 1440
	Active signal resolution	2560 × 1440
	Refresh rate (Hz)	239,970 Hz
	Bit depth	8-bit
1	Color format	RGB
ĺ	Color space	Standard dynamic range

Display adapter properties for Display 1

Refresh Rate

Choose the refresh rate for your display. A higher rate smoother motion, but also uses more power.

Refresh rate




Step three:

Press right click on your **SECOND PC** windows taskbar and go into "Taskbar settings".

Now set the "Lock the taskbar" to OFF

"Automatically hide the taskbar in desktop mode" to ON

In the section "Multiple displays" set the "Show taskbar on all displays" to OFF



Multiple displays

Show taskbar on all displays







Step four:


Now click right click on an empty space on your desktop and open "Personalize" and set your Background wallpaper to "Solid color" and pick Black. Also make sure just in case to hide all of the desktop icons.

Picture



Background





Show desktop icons

Step five:

NOTE: Do not plug in the power cable into Fuser just yet. HDMI cables should all be pluged in while its turned off.

Now plug the HDMI cables following this scheme:

- 1. Input 2 The main PC
- 2. Input 1 Second PC
- 3. Output 2 Main PC monitor

Note: Output 2 is usually better option, but if it doesn't work use Output 1!



Please only after plugging all of HDMI's you can move on to connect the power cable and check if all the correct lights are on, and move on to the next step.

(If the power light is on, and all of the others are off, please disconnect the power adapter from the wall, wait 10 seconds and plug it in again. The lights for input and output should now be ON.)

Step six: (final step)

Please use the MODE button on Fuser or Remote controller of the device to setup desired resolution and refresh rate.

Please after pressing any button on Fuser or Remote give it a second, <u>do not mash keys!</u> If you went through all of the possible resolutions and the Main PC monitor is not connecting, go back to the Step One and Step Two to check if anything changed after connecting the HDMI cables.

Information:

Package includes:

- 1x Fuser (screen combiner)
- 3x HDMI 2.1 Cables
- Remote Controller (without battery, please purchase your own CR 2025 Lithium battery)
- Power cord



Minimum requirements of SECOND PC:

- Intel 6th generation, or above Dual Core
- 8gb RAM Memory
- 64gb Hard Disk space
- GTX 950, AMD Radeon R7 370
- At least 1x HDMI port
- Windows 10 or 11

NOTE: For the laptops or PC's without dedicated graphics card the requirements may vary.