


# pH Sensor (S-pH-01) User Guide

Version: V2.1







### Content

1. Introduction	3
2. Wiring diagrams	4
3. Dimension	5
4. Installation Maintenance and Calibration	6
4.1 Installation	6
4.2 Maintenance	6
5. Output Signal Conversion	7
6. RS485 Modbus Protocol	8
6.1 Modbus Protocol	8
6.2 Modbus Register	9
6.3 Modbus Register Detail Description	. 12
7. Software Configuration Utility	.20





# 1. Introduction

S-PH-01 transmitter measures the PH of solution or semi-solid substrate. The output signal can be RS485 and Analog Voltage. The sensor is applicable for industrial, water processing, sewerage system, irrigation, smart agriculture etc.


- Can be used for PH measurement
- Output Interface with RS485, Voltage
- High impedance and isolated electrode input
- High accuracy with excellent stability
- Reverse power protection and Built-in TVS/ESD protection

	Specificatio ns				
Output Interface	Analog Voltage 0-2V (Output resistance ~0ohm)	RS485 Modbus-RTU			
Power Supply	3.9-30V/DC	3.9-30V/DC			
Power Consumption	35mA@24V DC	35mA@24V DC			
Start-up time	< 2 seconds				
PH Measurement	High impedance and isolated input; Range: 0-14PH, Resolution: 0.01PH,				
	Accuracy: +/-0.1PH; Can be used for solution or semi-solid substrate				
Temperature Measurement	Range: -40~80°C, Resolution: 0.1°C, Accuracy: +/-0.5°C				
(Option)					
IP Ratings	Electrode: IP68; Transmitter: IP65				
Operating Temperature	-40~85°C				
Installation	Electrode: 3/4"NPT screw threads; Transmitter: Mounting hole				
Cable Length	Power and Signal Cable:2 meters or Customize; Electrode Cable: 5 mete				
	rs				
Dimension	Electrode: Width*Diameter 160*30mm; 3/4"NPT screw threads				
Dillicipioli	Transmitter: 140mm*65mm*50mm				





# 2. Wiring diagrams








# 3. Dimension

#### **Electrode Dimension**



#### Transmitter Dimension



\*Note: Do not put the Transmitter into the liquid.





# 4. Installation Maintenance and Calibration

#### 4.1 Installation

Installation locations of Electrodes will vary depending on the system design. The key is to monitor a good representative sample of the whole solution directly after introduction of chlorine. The installation location must allow for complete contact of the scrubber liquid with the probes. Some example installation locations for Electrodes include the following:

- Outlet of packed tower
- Outlet of recycle pump
- Pump bypass line
- Heat Exchanger bypass line

#### 4.2 Maintenance

Under normal conditions, electrodes can last anywhere from several months to several years depending on the type of operation, rate of production, strength of product, and quality of the raw materials used in the process. Because each application is different, there is no average life expectancy.

Because the pH responsive glass bulb or flat surface is relatively thin, care should be taken so that the bulb does not become scratched or broken. It is also important that ORP measuring surfaces are not scratched or gouged. The suggestions in this sheet are intended to help avoid these problems. Coating of an electrode's measuring surface can lead to erroneous readings including shortened span and slow response times. The type of coating determines the type of cleaning technique. Soft Coatings can be removed by vigorous stirring, by use of a squirt bottle or, very carefully, by gently wiping with a soft, clean non-abrasive paper or cloth. Hard Coatings should be chemically removed. The chemical used to remove the coating should be the least harsh chemical that dissolves the coating in 1 or 2 minutes and does not attack the electrode's materials of construction. For example, a calcium carbonate coating might be removed with 5% HCI (muriatic acid). Oily or Organic Coatings are best removed with detergents or an appropriate solvent that does not attack the electrode's materials of construction. For example, isopropyl alcohol might be used but acetone should be avoided if the electrode's body is made of CPVC.





# **5. Output Signal Conversion**

#### PH output conversion

Output Interface	Parameters Range	Conversion Formula
Analog Voltage	PH range: 0-14PH	PH=7.00*VOLTAGE.When VOLTAGE=1.0V,then
Output 0-2V		PH =7.00*1.00=7.
RS485	PH range: 0-14PH	PH= (REGISTER VALUE)/100.When REGISTER
Modbus-RTU		VALUE=7000,then PH= 7000/100=7.00.
	Temperature range: -40-80°C	TEMPERATURE= (REGISTER VALUE)/100.When
		REGISTER VALUE=2013,then TEMPERATURE
		= 2013/100=20.13°C.

NOTE: The unit of VOLTAGE is (V)





# 6. RS485 Modbus Protocol

#### 6.1 Modbus Protocol

Modbus Protocol is widely used to establish master-slave communication between intelligent devices or sensors. A MODBUS message sent from a master to a slave contains the address of the slave, the function code (e.g. 'read register' or 'write register'), the data, and a check sum (LRC or CRC).

The sensor is RS485 interface with Modbus protocol. The default serial communication settings is slave address 1, modbus rtu, 9600bps, 8 databits and 1 stop bit. All communication settings can be changed with modbus command, and take effective after re-power up the sensor.

Following modbus function code are supported by sensor. Modbus Function Code 0x03: used for reading holding register. Modbus Function Code 0x04: used for reading input register.

Modbus Function Code 0x06: used for writing single holding register. Modbus Function Code 0x10: used for writing multiple holding register.





# 6.2 Modbus Register

Parameters	Register Addr. (HEX/DEC)	Dat a Typ e	Modbu s Functio n Code(DEC)	Range and Comments	Defaul t Value
TEMPRATURE	0x0000 /0	INT16 RO	3/4	-4000-8000 for - 40.00~80.00°C.	N/A
PH PHVALUE	0x0001 /1	UINT16 RO	3/4	0-1400 for 0.00-14.00	N/A
TEMPCOMPENSA TEE N	0x0020 /32	UINT16 R/W	3/6/16	0: External Temperature sensor 1: Disabled 2:On board temperature sensor	1
PHCALIBRAWAD0 PH calibration point for PH=4.01	0x0030 /48	UINT16 R/W	3/6/16	-2000~2000 for - 2000~2000; Write 0xFFFF to calibrate.	N/A
PHCALIBRAWAD1 PH calibration point for PH=7.00	0x0031 /49	UINT16 R/W	3/6/16	-2000~2000 for - 2000~2000; Write 0xFFFF to calibrate.	N/A
PHCALIBRAWAD2 PH calibration point for PH=10.01	0x0032 /50	UINT16 R/W	3/6/16	-2000~2000 for - 2000~2000; Write 0xFFFF to calibrate.	N/A
SLAVEADDRESS	0x0200 /512	UINT16 R/W	3/6/16	0-255	1 or 12
BAUDRATE	0x0201 /513	UINT16 R/W	3/6/16	0-6 0:1200bps 1:2400bps 2:4800bps 3:9600bps 4:19200bp s 5:38400bp	3:9600bps





#### User Guide

PROTOCOL	0x0202 /514	UINT16	3/6/16	0-1	0:Modbu
		R/W		0:Modbus RTU	s RTU
PARITY	0x0203 /515	UINT16	3/6/16	0-2	0:Non
		R/W		0:Non	e
				е	Parity
				1:Eve	
				n	
				2:Odd	
DATABITS	0x0204 /516	UINT16	3/6/16	1	1:8 databits





#### User Guide

		R/W		1:8 databits	
STOPBITS	0x0205 /517	UINT16	3/6/16	0-1	0:1 stopbit
		R/W		0:1 stopbit	
				1:2 stopbits	
RESPONSEDELAY	0x0206 /518	UINT16	3/6/16	0-255 for 0-2550	0
		R/W		milliseconds	
ACTIVEOUTPUTINTE	0x0207 /519	UINT16	3/6/16	0-255 for 0-255	0
R		R/W		seconds.	
VAL					

NOTE: UINT16:16 bit unsigned integer, INT16:16bit signed integer NOTE: RO: Register is Read Only, R/W: Register is Read/Write NOTE: HEX is Hexadecimal (data with 0x/0X

prefix), DEC is Decimal





# 6.3 Modbus Register Detail Description

TEMPERATURE		
Data Range	-4000-8000 For -40.00~80.00°C	Default: N/A
Power Down Save	N/A	

Note:Temperature value (Binary complement).

Example: When REGISTER = 0x0702 (HEX format), then

VALUE=(0x07\*256+0x02)/100=17.94°C.When REGISTER=FF05H (HEX format),then VALUE=((0xFF\*256+0x05)-0xFFFF-0x01)/100=(0xFF05-0xFFFF-0x01)/100=-2.51°C.

PH VALUE			
Data Range	0-1400 for 0-14.00PH		Default: N/A
Power Down Save	N/A		

Note: PH value

Example: When REGISTER = 0x02BC (HEX format), then

VALUE=(0x02\*256+0xBC)/100=7.00PH

TEMPCOMPENSATEEN		
Data Range	0: External Temperature sensor 1: Disabled	Default: 1
	2:On board temperature sensor	
Power Down Save	YES	

Note: Temperature compensation

PHCALIBRAWAD0		
Data Range	-2000~2000	Default: N/A
Power Down Save	YES	

Note:PH calibration AD value for PH=4.01; Immerse the electrode into PH=4.01 solution and wait until the reading value being stable, then write 0xFFFF to this register to calibrate.

PHCALIBRAWAD1		
Data Range	-2000~2000	Default: N/A
Power Down Save	YES	

Note:PH calibration AD value for PH=7.00; Immerse the electrode into PH=7.00 solution and wait until the reading value being stable, then write 0xFFFF to this register to calibrate.





Data Range	-2000~2000	Default: N/A
Power Down Save	YES	

Note:PH calibration AD value for PH=10.01; Immerse the electrode into PH=10.01 solution and wait until the reading value being stable, then write 0xFFFF to this register to calibrate.

SLAVEADDRESS Modbus Slave Address		
Data Range	0-255	Default: 1 or 12
Power Down Save	YES	

Note: Please re-power on the sensor to take effective after set.

BAUDRATE Serial Comm Baudrate			
Data Range	0-5		Default: 3
	<b>0:</b> 1200bps		
	<b>1:</b> 2400bps		
	<b>2:</b> 4800bps		
	<b>3:</b> 9600bps		
	<b>4:</b> 19200bp		
	s		
	<b>5:</b> 38400bps		
Power Down Save	YES		

Note: Please re-power on the sensor to take effective after set.

PROTOCOL Serial Comm Protocol		
Data Range	0 Default: 0	
	0:Modbus RTU	
Power Down Save	YES	

Note: Please re-power on the sensor to take effective after set.

PARITY Serial Comm Parity		
Data Range	0-2	Default: 0
	0:NONE	
	1:EVEN	
	2:ODD	
Power Down Save	YES	

Note: Please re-power on the sensor to take effective after set.





DATABITS Serial Comm Databits		
Data Range	1	Default: 1
	1:8 databits	1.66
Power Down Save	YES	4/3

Note: Please re-power on the sensor to take effective after set.

STOPBITS Serial Comm Stopbits		
Data Range	0-1	Default: 0
	0:1 stopbit	
	1:2 stopbits	
Power Down Save	YES	0

Note: Please re-power on the sensor to take effective after set.

RESPONSEDELAY Serial Comm Response Delay		
Data Range	0-255 for 0-2550 milliseconds, 0 for disabled	Default: 0
Power Down Save	YES	

Note: Please re-power on the sensor to take effective after set.

Note: Sensor will delay a period before response to master request command.

Example: When set to 5 and receive a request from master device, then sensor

will delay 5\*10ms=50ms, then response to master.

ACTIVEOUTPUTINTERVAL Serial Comm Active Output Interval time		
Data Range	0-255 for 0-255 seconds, 0 for disabled Default: 0	
Power Down Save	YES	

Note: Please re-power on the sensor to take effective after set.

Note: Sensor will output the data actively without any master request command.

Note: Only ONE sensor should be on RS485 network, or there will be data collision and corrupt the data on line.

Note: Use key button to restore the serial comm parameters factory value to exit the active output mode.

Example: When set to 5 then sensor will output the data every 5 seconds without any master request command.





#### 6.4 Modbus Function Code

For description below, data started with 0X/0x means that it's in HEX format.

#### 6.4.1 Function Code 3 Protocol Example

#### Master Request: AA 03 RRRR NNNN CCCC

AA	1 byte	Slave Address,0-255
0x03	1 byte	Function Code 3
RRRR	2 byte	Starting Register Addr
NNNN	2 byte	Quantity of Register to read
CCCC	2 byte	CRC CHECKSUM

#### Slave Response:AA 03 MM VV0 VV1 VV2 VV3... CCCC

AA	1 byte	Slave Address,0-255
0x03	1 byte	Function Code 3
ММ	1 byte	Register Data Byte Count
VV0,VV1	2 byte	Register Value (High8bits first)
VV2,VV3	2 byte	Register Value (High8bits first)
		Register Value (High8bits first)
cccc	2 byte	CRC CHECKSUM

# Example:Read register 0x0200-0x0201,that is slave address and baudrate. Master Request:01 03 0200 0002 C5B3

Slave Addr.	1 byte	0x01
Function Code	1 byte	0x03
Starting Register Addr.	2 byte	0x0200
Quantity of Register to read	2 byte	0x0002
Checksum	2 hvte	0xC5R3

#### Slave Response:01 03 04 00 01 00 03 EB F2

Slave Addr.	1 byte	0x01
-------------	--------	------





Function Code	1 byte	0x03
Register Data Byte	1 byte	0x04
Count		N. Carlotte
Register Value:	2 byte	0x00(HIGH 8 Bits)
Address		0x01(LOW8 Bits)
Register Value:	2 byte	0x00(HIGH 8 Bits)
Baudrate		0x03(LOW8 Bits)
Checksum	2 byte	0xEBF2

### 6.4.2 Function Code 4 Protocol Example

#### Master Request: AA 04 RRRR NNNN CCCC

AA	1 byte	Slave Address,0-255
0x04	1 byte	Function Code 4
RRRR	2 byte	Starting Register Addr
NNNN	2 byte	Quantity of Register to read
CCCC	2 byte	CRC CHECKSUM

#### Slave Response: AA 04 MM VV0 VV1 VV2 VV3... CCCC

AA	1 byte	Slave Address,0-255
0x04	1 byte	Function Code 4
MM	1 byte	Register Data Byte Count
VV0,VV1	2 byte	Register Value (High8bits first)
VV2,VV3	2 byte	Register Value (High8bits first)
60		Register Value (High8bits first)
cccc	2 byte	CRC CHECKSUM

# Example:Read register 0x0000-0x0002,that is temperature, PH value. Master Request: 01 04 0000 0002 71CB

Slave Addr.	1 byte	0x01
Function Code	1 byte	0x04
Starting Register	2 byte	0x0000
Addr.		





Quantity of Register	2 byte	0x0002
to read		
Checksum	2 byte	0x71CB

#### Slave Response: 01 04 04 08C3 029E 8910

Slave Addr.	1 byte	0x01
Function Code	1 byte	0x04
Register Data Byte	1 byte	0x04
Count		4
Register Value:	2 byte	0x08(HIGH 8 Bits)
Temperature		0xC3(LOW8 Bits)
Register Value:	2 byte	0x02(HIGH 8 Bits)
PH		0x9E(LOW8 Bits)
Checksum	2 byte	0x8910

Temperature =(0x08\*256+0xC3)/100=2243/100=22.43 °C PH=(0x02\*256+0x9E)/100=670/100=6.70PH

# 6.4.3 Function Code 6 Protocol Example

#### Master Request: AA 06 RRRR VVVV CCCC

AA	1 byte	Slave Address,0-255
0x06	1 byte	Function Code 6
RRRR	2 byte	Register Addr (High8bits first)
VVVV	2 byte	Register Value (High8bits first)
CCCC	2 byte	CRC CHECKSUM

#### Slave Response: AA 06 RRRR VVVV CCCC

AA	1 byte	Slave Address,0-255
0x06	1 byte	Function Code 6
RRRR	2 byte	Register Addr (High8bits first)
VVVV	2 byte	Register Value (High8bits first)
CCCC	2 byte	CRC CHECKSUM

#### Example: Write Register 0x0020, that is set temperature compensation





#### Request: 01 06 0020 0000 8800

Slave Addr.	1 byte	0x01
Function Code	1 byte	0x06
Register Addr.	2 byte	0x0020 (High8bits first)
Register Value	2 byte	0x0000 (High8bits first)
Checksum	2 byte	0x8800

#### Response:01 06 0021 0001 1800

Slave Addr.	1 byte	0x01
Function Code	1 byte	0x06
Register Addr.	2 byte	0x0020 (High8bits first)
Register Value	2 byte	0x0000 (High8bits first)
Checksum	2 byte	0x8800

# 6.4.4 Function Code 16 Protocol Example

#### Master Request: AA 10 RRRR NNNN MM VVVV1 VVVV2 ... CCCC

AA	1 byte	Slave Address,0-255
0x10	1 byte	Function Code 0x10
RRRR	2 byte	Starting Register Addr
NNNN	2 byte	Quantity of Register to write
ММ	1 byte	Register Data Byte Count
VVVV1	2 byte	Register Value(High8bits first)
VVVV2	2 byte	Register Value(High8bits first)
		Register Value(High8bits first)
CCCC	2 byte	CRC CHECKSUM

#### Slave Response: AA 10 RRRR NNNN CCCC

AA	1 byte	Slave Address,0-255
0x10	1 byte	Function Code 0x10
RRRR	2 byte	Starting Register Addr
NNNN	2 byte	Quantity of Register to write
cccc	2 byte	CRC CHECKSUM





# Example:Write Register 0x0200-0x0201,that is set slave address to 1,and baudrate to 19200bp. Master Request:01 10 0200 0002 04 0001 0004 BACC

0x01	1 byte	Slave Addr.	
0x10(HEX)	1 byte	Function Code 0x10	
0x0200	2 byte	Starting Register Addr	
0x0002	2 byte	Quantity of Register to write	
0x04	1 byte	Register Data Byte Count	
0x0001	2 byte	Register Value: Slave Address 1	
0x0004	2 byte	Register Value: Baudrate 19200bps	
0xBACC	2 byte	CRC CHECKSUM	


#### Salve Response:01 10 0200 0002 4070

0x01	1 byte	Slave Addr.	
0x10(HEX)	1 byte	Function Code 0x10	
0x0200	2 byte	Starting Register Addr(High8bits first)	
0x0002	2 byte	Quantity of Register to write(High8bits first)	
0x4070	2 byte	CRC CHECKSUM	





# 7. Software Configuration Utility



You can use software listed below to try reading/writing the register of sensor:

https://github.com/ed-chemnitz/qmodbus/releases

http://qmodbus.sourceforge.net/





# 8. Document Version

Version	Date	Description	Editor
V2.0		First edition	
V2.1	11/18/2022	Add Note in chapter 3	Kelvin.Lee

