Park only (no shooting)

Odo ROBOT Park and **Pollen ROBOT Park** don't shoot. They wait for the start delay, then drive straight forward and stop. We use them for testing, or if the launcher is broken and we only want the LEAVE points.

Mode	How it drives	Default
Odo ROBOT Park (group *Pollen Odometry*)	Measures the distance with odometry	55 cm (about 22 in) forward, power 0.60
Pollen ROBOT Park (group *Pollen*)	Drives for a set time	2.0 s forward at power 0.20 (about 55 cm)

Buttons during INIT

Button	Odo ROBOT Park	Pollen ROBOT Park
D-pad UP / DOWN	Start delay +/- 0.5 s	Start delay +/- 0.5 s
D-pad RIGHT / LEFT	Distance +/- 5 cm	Drive time +/- 0.05 s
R1 / L1	Power +/- 0.05	Power +/- 0.05
Triangle	Back to the defaults	Back to the defaults

Placement

These drive **straight ahead** from wherever the robot is. Point the robot so that straight ahead is clear and ends partly in the loading zone if you want PARK points too. Ask a programmer how far to set the distance for that start. Don't drive the straight diagonal from the middle of the audience wall: it hits the hive frame.

Check for **Build** `pollen-odo-v7` and `READY - waiting for START` before START.