Park only (no shooting)

Odo ROBOT Park doesn't shoot. It waits for the start delay, then drives straight **backward** (launcher end first, like every auto) and stops. We use it for testing, or if the launcher is broken and we only want the LEAVE points.

EMERGENCY Timed Park does the same job by time. It is for **emergencies only**: use it when the odometry sensor isn't working.

Mode	How it drives	Default
Odo ROBOT Park (group *Pollen Odometry*)	Measures the distance with odometry	55 cm (about 22 in) backward, power 0.60
EMERGENCY Timed Park (group *Pollen Emergency (timed)*)	Drives for a set time	2.0 s backward at power 0.20 (about 55 cm)

Buttons during INIT

Button	Odo ROBOT Park	EMERGENCY Timed Park
D-pad UP / DOWN	Start delay +/- 0.5 s	Start delay +/- 0.5 s
D-pad RIGHT / LEFT	Distance +/- 5 cm	Drive time +/- 0.05 s
R1 / L1	Power +/- 0.05	Power +/- 0.05
Triangle	Back to the defaults	Back to the defaults

Placement

These drive **straight backward** from wherever the robot is: the launcher end goes first. Point the robot's back where you want it to go, so that straight behind it is clear and ends partly in the loading zone if you want PARK points too. Ask a programmer how far to set the distance for that start. Don't drive the straight diagonal from the middle of the audience wall: it hits the hive frame.

Check for **Build** `pollen-hive-v1` and `READY - waiting for START` before START.