

# Getting started with the X-NUCLEO-IKS01A3 motion MEMS and environmental sensor expansion board for STM32 Nucleo

#### Introduction

The X-NUCLEO-IKS01A3 is a motion MEMS and environmental sensor evaluation board system.

It is compatible with the Arduino UNO R3 connector layout and features the LSM6DSO 3-axis accelerometer + 3-axis gyroscope, the LIS2MDL 3-axis magnetometer, the LIS2DW12 3-axis accelerometer, the HTS221 humidity and temperature sensor, the LPS22HH pressure sensor, and the STTS751 temperature sensor.

The X-NUCLEO-IKS01A3 interfaces with the STM32 microcontroller via the I<sup>2</sup>C pin, and it is possible to change the default I<sup>2</sup>C port.




Figure 1. X-NUCLEO-IKS01A3 expansion board



# 1 Getting started

### 1.1 Hardware requirements

The X-NUCLEO-IKS01A3 is designed to be used with STM32 Nucleo boards (visit www.st.com for further information).




Figure 2. X-NUCLEO-IKS01A3 plugged on an STM32 Nucleo board

The X-NUCLEO-IKS01A3 must be connected on the matching pins of any STM32 Nucleo board with the Arduino UNO R3 connector.

Note:

X-NUCLEO-IKS01A3 components are ESD sensitive and, as the board has male/female pass-through connectors, it is important to handle it with care to avoid bending or damaging the pins.

#### - RELATED LINKS -

See the X-CUBE-MEMS1 product page for firmware and related documentation

UM2559 - Rev 3 page 2/17



# 2 System requirements

To complete the system setup, you need:

- a Windows® (7, 8, 10) PC
- a USB type A to mini-B USB cable to connect the STM32 Nucleo to the PC
- board firmware and software package (X-CUBE-MEMS1) installed on the user PC

UM2559 - Rev 3 page 3/17



## 3 Hardware description

The board lets you test the functionality of the motion MEMS accelerometer, gyroscope and magnetometer, and environmental humidity, temperature and pressure sensors, via the I<sup>2</sup>C communication bus.

It also allows all LSM6DSO sensor hub function testing.

#### The board features:

- Operating range: 3.3 V, 250 mA
- LSM6DSO: MEMS 3D accelerometer (±2/±4/±8/±16 g) + 3D gyroscope (±125/±250/±500/±1000/±2000 dps)
- LIS2MDL: MEMS 3D magnetometer (±50 gauss)
- LIS2DW12: MEMS 3D accelerometer (±2/±4/±8/±16 g)
- LPS22HH: MEMS pressure sensor, 260-1260 hPa absolute digital output barometer
- HTS221: capacitive digital relative humidity and temperature
- STTS751: Temperature sensor (–40 °C to +125 °C)
- DIL 24-pin socket available for additional MEMS adapters and other sensors
- Free comprehensive development firmware library and example for all sensors compatible with STM32Cube firmware
- I<sup>2</sup>C sensor hub features on LSM6DSO available
- Compatible with STM32 Nucleo boards
- Equipped with Arduino UNO R3 connector
- RoHS compliant
- WEEE compliant

Each device has a separate power supply to allow power consumption measurement of every sensor.

The expansion board is power supply compatible with STM32 Nucleo boards: it mounts an LDO to generate 1.8 V for all the MEMS sensors except for the STTS751, which is supplied by a separate LDO generating 2.5 V.

All signals between the sensors and the main board are translated by a level shifter.

### 3.1 Default solder bridge configuration

The user can configure several aspects of the X-NUCLEO-IKS01A3 through several solder bridges which can be left open (not mounted) or closed (mounted) to configure different hardware settings.

Table 1. Default solder bridge default configuration (device to I<sup>2</sup>C bus connection)

Device	BUS	Solder bridge (default)	Solder bridge (not mounted)
LIS2DW12	I <sup>2</sup> C2	SB3, SB13	-
LSM6DSO	I <sup>2</sup> C2	SB7, SB11	-
HTS221	I <sup>2</sup> C1	SB24, SB31	-
LPS22HH	I <sup>2</sup> C1	SB29, SB32	-
STTS751	I <sup>2</sup> C1	SB26, SB27	-
LIS2MDL	I <sup>2</sup> C1	SB33, SB34	-
STM32 Nucleo	I <sup>2</sup> C2	SB35, SB36	-
DIL24 Adapter	I <sup>2</sup> C1	SB12, SB19	SB1, SB4, SB6, SB10, SB14, SB16, SB18, SB20, SB21, SB22
*DIL24 Adapter	I <sup>2</sup> C2	SB16, SB21	SB1, SB4, SB6, SB10, SB14, SB12, SB18, SB20, SB19, SB22
*DIL24 Adapter	I <sup>2</sup> Cx	SB14, SB20	SB1, SB4, SB6, SB10, SB12, SB16, SB18, SB19, SB21, SB22

UM2559 - Rev 3 page 4/17

94h

BAh

B8h

**BFh** 



Solder bridge (non default)	I <sup>2</sup> C address default
SB8	32h
SB9 <sup>(1)</sup>	30h
SB15	D6h
SB17 <sup>(1)</sup>	D4h
_	3C

Table 2. Device I<sup>2</sup>C address

LPS22HB

LPS22HB

Device
LIS2DW12
LIS2DW12
LSM6DSO
LSM6DSO
LIS2MDL
STTS751

Note: Other SBs mounted by default are SB40 to SB49 (STM32 Nucleo GPIO INT), SB23, SB25, SB39 Other SBs not mounted by default are SB38, SB37, SB50

### 3.2 Block diagram

The LSM6DSO has an  $I^2C$  sensor hub which allows it to behave as the  $I^2C$  master for other slave devices connected via an  $I^2C_{aux}$  bus. Various configurations are possible for different  $I^2C$  bus connections with or without the LSM6DSO sensor hub.

#### Mode 1: standard I<sup>2</sup>C bus connection (all sensors)

In standard I<sup>2</sup>C mode, all devices are connected to an external main board via the same I<sup>2</sup>C bus. The board configuration is:

**SB13** 

**SB14** 

- JP7: 1-2, 3-4 (I<sup>2</sup>C1 = I<sup>2</sup>C2, I<sup>2</sup>Cx=GND)
- JP8: 1-2, 3-4 (I<sup>2</sup>C1 = I<sup>2</sup>C2, I<sup>2</sup>Cx=GND)

STM32 Nucleo board

Arduino UNO R3

ST morpho

LIS2DW12

LIS2MDL

LPS22HH

HTS221

STTS751

DIL24

Figure 3. X-NUCLEO-IKS01A3 standard I<sup>2</sup>C

#### Mode 2: LSM6DSO I<sup>2</sup>C sensor hub (all sensors)

In this sensor hub I²C mode, the LSM6DSO is connected to an external main board by an I²C bus; all other devices except LIS2DW12 are slaves connected to LSM6DSO via I²C<sub>aux</sub>.

The board configuration is:

- JP7: 2-3 (I<sup>2</sup>C1 = I<sup>2</sup>Cx)
- JP8: 2-3 ( $I^2C1 = I^2Cx$ )

UM2559 - Rev 3 page 5/17

<sup>1.</sup> not mounted by default

DIL24



Figure 4. X-NUCLEO-IKS01A3 LSM6DSO I2C sensor hub

#### Mode 3: DIL24 plus LSM6DSO I2C sensor hub (all sensors, not DIL24)

In this sensor hub I<sup>2</sup>C mode, the LSM6DSO and the DIL24 adapter are connected to an external main board by an I<sup>2</sup>C bus; all other devices except LIS2DW12 are slaves of the LSM6DSO via I<sup>2</sup>C<sub>aux</sub>.


The board configuration is:

- JP7: 2-3 (I<sup>2</sup>C1 = I<sup>2</sup>Cx)
- JP8: 2-3 (I<sup>2</sup>C1 = I<sup>2</sup>Cx)

DIL24 adapter (to I2C2): SB16, SB21

Not mounted: SB6, SB10, SB12, SB14, SB18, SB19, SB20, SB22

Figure 5. X-NUCLEO-IKS01A3 DIL24, LSM6DSO I2C sensor hub (all sensors)



#### Mode 4: LSM6DSO plus DIL24 I<sup>2</sup>C sensor hub (all sensors)

In this sensor hub I<sup>2</sup>C mode, the LSM6DSO and the DIL24 adapter are connected to an external main board by an I<sup>2</sup>C bus; all other devices except LIS2DW12 are slaves of the DIL24 adapter via I<sup>2</sup>C<sub>aux</sub>.


The board configuration is:

- JP7: 2-3 (I<sup>2</sup>C1 = I<sup>2</sup>Cx)
- JP8: 2-3 (I<sup>2</sup>C1 = I<sup>2</sup>Cx)

DIL24 adapter (to I2C2): SB16 SB21

Not mounted: SB6, SB10, SB12, SB14, SB18, SB19, SB20, SB22

Figure 6. X-NUCLEO-IKS01A3 LSM6DSO, DIL24, I<sup>2</sup>C sensor hub (all sensors)



UM2559 - Rev 3 page 6/17



#### Mode 5: LSM6DSO plus I2C sensor hub DIL24

In this sensor hub I<sup>2</sup>C mode, the LSM6DSO and other sensors are connected to an external main board via an I<sup>2</sup>C bus; the DIL24 adapter is a slave of the LSM6DSO via I<sup>2</sup>C<sub>aux</sub>.


The board configuration is:

- JP7: 1-2 (I<sup>2</sup>C1 = I<sup>2</sup>Cx)
- JP8: 1-2 (I<sup>2</sup>C1 = I<sup>2</sup>Cx)

DIL24 adapter (to I2Cx): SB14, SB20

Not mounted: SB6, SB10, SB12, SB16, SB18, SB19, SB21, SB22

Figure 7. X-NUCLEO-IKS01A3 LSM6DSO plus sensor hub DIL24



#### 3.3 Sensor I<sup>2</sup>C address selection

Most sensors allow I<sup>2</sup>C address LSB selection by pulling the SD0 pin low or high. The board has solder bridges to control SD0 level.

Sensor SD0 high SD0 low STTS751 (U9) ADD= 94h LIS2DW12(U1) SB8 ADD=32h SB9 ADD=30h LSM6DSO (U2) SB15 ADD=D6h SB17 ADD=D4h LPS22HH (U4) SB28 ADD=BAh SB30 ADD=B8h LIS2MDL (U8) ADD =3Ch ADD =3Ch HTS221 (U3) ADD= BEh ADD= BEh DIL24 Adapter (J1) SB1/SB2 SB4/SB5

Table 3. Solder bridges for SD0 level control and I2C address

### 3.4 Sensor current consumption measurement

The X-NUCLEO-IKS01A3 expansion board is equipped with jumpers which allow separate current consumption measurement for each sensor.

To measure current consumption, connect an ammeter to the appropriate jumper.

Note: As the sensors have very low current consumption, you should set a suitable range and use an ammeter with low burden voltage.

UM2559 - Rev 3 page 7/17



Table 4. Jumpers for current consumption measurement

Sensor	Jumper
LIS2MDL (U8)	JP14
LSM6DSO (U2)	JP11
HTS221 (U3)	JP3
LPS22HH (U4)	JP4
STTS751 (U9)	JP13
LIS2DW12 (U1)	JP1
DIL24 Adapter (J1)	JP5

#### 3.5 Sensor disconnection

To disconnect a sensor, you should disconnect the I<sup>2</sup>C bus as well as the power supply. See the table below for the relevant jumpers and solder bridges.

Table 5. Link between sensors, jumpers and I<sup>2</sup>C solder bridges

Sensor	Power	SDA	SCL
LIS2MDL (U8)	JP14	SB34	SB33
LSM6DSO (U2)	JP11	SB11	SB7
HTS221 (U3)	JP3	SB24	SB31
LIS2DW12 (U1)	JP1	SB3	SB13
STTS751 (U9)	JP13	SB26	SB27
LPS22HH (U4)	JP4	SB32	SB29
DIL24 adapter	JP5	SB12,14,16	SB19,20,21

### 3.6 Adapter board for DIL24 socket

An additional sensor can be connected as an adapter board to J1 DIL24 socket.

As there are a few different interrupt signal assignments for DIL24 pins, the appropriate pin can be selected using the JP6 header.

— RELATED LINKS –

Please visit the ST website to find other available sensors

UM2559 - Rev 3 page 8/17



### 3.7 Connectors

Table 6. Arduino R3 UNO connectors

Connector	Pin <sup>(1)</sup>	Signal
	7	GND
CN5	9	I <sup>2</sup> C SDA
	10	I <sup>2</sup> C SCL
	2	3.3 V
	4	3.3 V
CN6	6	GND
	7	GND
	8	N.C.[FT1]
	3	LIS2MDL DRDY
CN8	4	LIS2DW12 INT
CINO	5	STTS751 INT
	6	INT1 (DIL24)
	3	USER INT
CN9	5	LSM6DSO INT1
Civa	6	LSM6DSO INT2
	7	LPS22HH INT1

<sup>1.</sup> unlisted pins are not connected.

Table 7. ST morpho connectors

Connector	Pin <sup>(1)</sup>	Signal
	12	3.3 V
	16	3.3 V
	20	GND
CN7	22	GND
CN7	32	LIS2MDL DRDY
	34	LIS2MDL DRDY
	36	STTS751 INT
	38	INT1 (DIL24)
	3	I <sup>2</sup> C SCL
	5	I <sup>2</sup> C SDA
CN10	25	LPS22HH INT1
CIVIO	27	LSM6DSO INT2
	29	LSM6DSO INT1
	33	USER INT

<sup>1.</sup> The unlisted pins are not connected.

UM2559 - Rev 3 page 9/17



# 4 Bill of materials

Table 8. X-NUCLEO-IKS01A3 bill of materials

Item	Quantity	Reference	Part / value	Description	Manufacturer	Part number
1	4	C3, C6, C15, C31	10μF	CAP CER 0603 6.3 V X5R ±20%	MULTICOMP	MC0603X106M6R3CT
2	12	C4, C5, C8, C9, C11, C12, C13, C14, C16, C17, C30, C80	100nF	CAP CER 0603 25 V X7R ±10%	MULTICOMP	MC0603B104K250CT
3	1	C18	2.2µF	CAP CER 0603 25 V X5R ±10%	MULTICOMP	MC0603X225K100CT
4	1	C32	220nF	CAP CER 0603 25 V X7R 10%	KEMET	C0603X224K4RACTU
5	4	CN5, CN6, CN8, CN9	10x1, 8x1, 6x1, 8x1	Headers	4UCON	-
6	1	J1	-	DIL24 Socket	MULTICOMP	2212S-12SG-85
7	7	JP1, JP2, JP3, JP4, JP11, JP13, JP14	2x1	Header + Shunt	HARWIN	M20-9990246
8	4	JP5, JP9, JP10, JP12	-	Header + Shunt	Generic Components	2211S-03G
9	1	JP6	2x7	Header	Generic Components	61301421121
10	2	JP7, JP8	-	Header + 2 shunts	Generic Components	2211S-04G
11	10	R1, R2, R9, R10, R11, R12, R14, R15, R16, R17	4k7	RES 0603 ±1% 1/16 W	MULTICOMP	MC0063W060314K7
12	2	R3, R8	2k2	RES 0603 ±1% 1/16 W	MULTICOMP	MC0063W060312K2
13	1	R6	12k	RES 0603 ±1% 1/16 W	MULTICOMP	MC0063W0603512K
14	1	R7	15k	RES 0603 ±1% 1/16 W	MULTICOMP	MC0063W0603515K
15	1	R13	7K5	RES 0603 ±0.5% 1/16 W	SUSUMU	RR0816P-752-D
16	34	SB2, SB3, SB5, SB7, SB8, SB11, SB12, SB13, SB15, SB19, SB23, SB24, SB25, SB26, SB27, SB28, SB29, SB31, SB32, SB33, SB34, SB35, SB36, SB39, SB40, SB41, SB42, SB43, SB44, SB45, SB44, SB45, SB46, SB47, SB48, SB49	-	Solder Bridge	-	-
17	1	U1	LIS2DW12	3-axis MEMS accelerometer	ST	LIS2DW12
18	1	U2	LSM6DSO	iNEMO 6DoF inertial measurement unit	ST	LSM6DSO

UM2559 - Rev 3 page 10/17




Item	Quantity	Reference	Part / value	Description	Manufacturer	Part number
19	1	U3	HTS221	Digital sensor for relative humidity and temperature	ST	HTS221
20	1	U4	LPS22HH	MEMS nano pressure sensor	ST	LPS22HH
21	1	U5	LDK130M-R	300 mA low quiescent current very low noise LDO	ST	LDK130M-R
22	2	U6, U7	ST2378E	8-Bit Level Translator with 15kV ESD Protection	ST	ST2378E
23	1	U8	LIS2MDL	Magnetic sensor digital output 50 gauss	ST	LIS2MDL
24	1	U9	STTS751	2.25 V low-voltage local digital temperature sensor	ST	STTS751
25	1	U10	NTS0104GU12	IC TXRX TRANSLATING 2BIT 8XSON	NXP	NTS0104GU12
26	1	U11	LDK120PU25	200 mA low quiescent current very low noise LDO	ST	LDK120PU25R

UM2559 - Rev 3 page 11/17

DIL24 Socket for Adapter Board







# **Revision history**

Table 9. Document revision history

Date	Version	Changes
18-Feb-2019	1	Initial release.
07-Jul-2020	2	Updated Section 3.2 Block diagram.
09-Sep-2020	3	Updated Section 3 Hardware description.

UM2559 - Rev 3 page 13/17



# **Contents**

1	Gett	ting started	2
	1.1	Hardware requirements	2
2	Sys	tem requirements	3
3	Hard	dware description	4
	3.1	Default solder bridge configuration	4
	3.2	Block diagram	5
	3.3	Sensor I <sup>2</sup> C address selection	7
	3.4	Sensor current consumption measurement	7
	3.5	Sensor disconnection	8
	3.6	Adapter board for DIL24 socket	8
	3.7	Connectors	9
4	Bill	of materials	10
5	Sch	ematic diagrams	12
Rev	vision	history	13
Co	ntents	;	14
Lis	t of ta	bles	15
Lis	t of fic	aures	16





# **List of tables**

Table 1.	Default solder bridge default configuration (device to I <sup>2</sup> C bus connection)	. 4
Table 2.	Device I <sup>2</sup> C address	. 5
Table 3.	Solder bridges for SD0 level control and I <sup>2</sup> C address	. 7
Table 4.	Jumpers for current consumption measurement	. 8
Table 5.	Link between sensors, jumpers and I <sup>2</sup> C solder bridges	. 8
Table 6.	Arduino R3 UNO connectors	. 9
Table 7.	ST morpho connectors	. 9
Table 8.	X-NUCLEO-IKS01A3 bill of materials	10
Table 9.	Document revision history	13

UM2559 - Rev 3 page 15/17



# **List of figures**

Figure 1.	X-NUCLEO-IKS01A3 expansion board	. 1
Figure 2.	X-NUCLEO-IKS01A3 plugged on an STM32 Nucleo board	. 2
Figure 3.	X-NUCLEO-IKS01A3 standard I <sup>2</sup> C	. 5
Figure 4.	X-NUCLEO-IKS01A3 LSM6DSO I <sup>2</sup> C sensor hub	. 6
Figure 5.	X-NUCLEO-IKS01A3 DIL24, LSM6DSO I <sup>2</sup> C sensor hub (all sensors)	. 6
Figure 6.	X-NUCLEO-IKS01A3 LSM6DSO, DIL24, I <sup>2</sup> C sensor hub (all sensors)	. 6
Figure 7.	X-NUCLEO-IKS01A3 LSM6DSO plus sensor hub DIL24	. 7
Figure 8.	X-NUCLEO-IKS01A3 board schematics	12

UM2559 - Rev 3 page 16/17



#### **IMPORTANT NOTICE - PLEASE READ CAREFULLY**

STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice. Purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST's terms and conditions of sale in place at the time of order acknowledgement.

Purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of Purchasers' products.

No license, express or implied, to any intellectual property right is granted by ST herein.

Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product.

ST and the ST logo are trademarks of ST. For additional information about ST trademarks, please refer to www.st.com/trademarks. All other product or service names are the property of their respective owners.

Information in this document supersedes and replaces information previously supplied in any prior versions of this document.

© 2020 STMicroelectronics - All rights reserved

UM2559 - Rev 3 page 17/17