m17web User Manual

M17 digital voice on a Raspberry Pi with an SDR, driven from your web browser

Version 1.2 — 14 October 2026

This manual is for anyone using the radio. It explains what the program does, how to start it, how to make a contact, and what to do when something does not work. You do not need to understand M17, SDR or Linux to use it — if someone set the system up for you, start at section 4.

A separate README in the same folder covers the technical details: building the program, the audio back ends, and the transmit timing.

What is in this manual

	Setting it up		Using it
1	What m17web does	7	Audio: where your voice comes from and goes
2	What you need	8	The controls, panel by panel
3	Starting and stopping it	9	Commands
4	Opening the interface	10	If something goes wrong
5	The screen at a glance, your position and the locator	11	Good practice
6	Making a contact, and the PTT switch	12	Quick reference

1. What m17web does

M17 is a digital voice mode for amateur radio: like FM voice, but it sends your speech as data, which gives clear audio and carries your callsign with it. m17web is a program that runs on a small computer (a Raspberry Pi) connected to a software-defined radio. It sends and receives M17 voice, and you control it entirely from a web page — no terminal commands needed in normal use.

Your voice comes from a microphone plugged into the Pi, or from the computer you are browsing from. Received voice comes out of the Pi's speaker (or your computer's).

If you are only practising, the program can run without a radio, in a mode that feeds your own audio straight back. See section 9.

2. What you need

Item	Notes
Raspberry Pi 4	Any 4 GB or 8 GB model, with a network connection. The Pi runs m17web.
ADALM-Pluto (PlutoSDR / Pluto+)	The radio itself, connected to the Pi by USB. A LimeSDR also works.
USB sound card with microphone and speaker or headphones	For audio at the Pi. Recommended - it is the most reliable audio path.
Antenna and a valid amateur licence	You need a licence for any frequency you transmit on.
A web browser	On any computer, tablet or phone on the same network as the Pi.
Optional: a GPS receiver	A small GPS receiver plugged into the Pi shows your position and Maidenhead locator on screen, and sends it to other stations (section 5).
Optional: a PTT switch	A switch wired to the Pi's header lets you transmit without the browser, from a hand microphone or a foot switch (section 6).

3. Starting and stopping it

m17web is started from a terminal on the Pi. If someone else set the system up for you, it may already be running — in that case go straight to section 4.

Start it (this also works after a reboot):

```
cd /mnt/hf/shared/projects/m17_sdr_web/m17gismo
RADIO=pluto MODE=radio bash tools/pi_m17web.sh start -a alsa
```

It keeps running after you close the terminal window. **Check it:**

```
bash tools/pi_m17web.sh status
```

Stop it, or look at the log to see what it is doing:

```
bash tools/pi_m17web.sh stop
bash tools/pi_m17web.sh log
```

What the settings mean

Setting	What it does
RADIO=pluto	Use the PlutoSDR. Use **RADIO=sim** instead to practise with no radio attached.
MODE=radio	Radio in, local sound out — the normal voice mode. It can also be changed while the program is running, from the Mode panel (section 8).
-a alsa	Send the voice to the Pi's sound card (see section 7). Use **-a browser** to use the browser's own microphone and speakers instead.

4. Opening the interface

In a browser on the same network, go to the address of the Pi followed by the port number:

```
http://10.168.1.33:8080/
```

Substitute the address of your own Pi. Bookmark it: this is the whole interface.

At the top right there is an **online / offline** marker. If it says offline, the page has lost contact with the Pi and nothing you press will do anything — check that the program is running (section 3) and reload the page.

5. The screen at a glance



Figure 1: the panels on the page. The header is always visible and carries your locator and position. The cards on the left are laid out two across - Station and Radio, Reflector and Position, then Audio with PUSH TO TALK at the bottom right - and the console and command help are the column on the right. (Sketch, not a screenshot.)

Area	What it is for
PUSH TO TALK	Bottom right. Press and hold while you speak, then release. You can hold the space bar instead. A physical switch on the Pi does the same job.
RX / TX light	Shows whether you are transmitting. Next to it, **in frame** means a valid M17 signal is being decoded, **no signal** means nothing is there.
signal and power bars	How strong the received signal is, and your transmit power setting.
Station	Your callsign, who you are calling, and the broadcast and log buttons.
Radio	The frequencies and gain settings, and the button that applies them.
Reflector	Linking over the internet to other M17 users (you may never need it).
Audio	Where your voice comes from and goes, the volume, and how healthy your transmit audio is.
Console	A command box for advanced settings, and the log that shows what is happening.
locator, position, gnss (top of the page)	Your Maidenhead locator and latitude/longitude from the GPS, and whether your position is being sent with your transmissions.

Your position: the locator, and the compass

If a GPS receiver is plugged into the Pi, your position is read from it and shown in two places: in the header at the top (locator, latitude and longitude) and in the **Position** panel, in large letters.

What you see	What it means
IO90ST	Your Maidenhead locator: six characters giving your position to about 5 km. Other operators use these to aim antennas, and they are the polite way to say where you are.
50.8036, -0.4419	Latitude and longitude in degrees. South and west are negative.
satellites / HDOP / altitude	How good the fix is. Six or more satellites and an HDOP below about 2 means a good one. Altitude is in metres.
copy locator	Puts the locator on the clipboard, ready to paste into a log or a message.
position ready / position sent / position off air	Whether your position is being sent with your transmissions. It is sent only while the fix is fresh, about every 5 seconds; it reads **position off air** when you have switched the sending off.
the compass	The bearing to the station you are hearing, with the distance in kilometres. The red needle points at them; the small yellow mark is the direction they say they are travelling. It needs a fix of your own to work.
heard G4ABC ...	The position another station sent, with its locator and how long ago it was received.

Your own position is sent to other stations as part of the M17 link setup, so send it only if you are happy for it to be public - it appears in the Location column of the reflector's own dashboard, and in any client that displays it. If you would rather not, untick **announce position on air** in the Position panel, or give the command **gps meta off**. The receiver keeps working either way, so the locator, the compass and the position log are unaffected, and the setting is remembered when you next start the program. Unplugging the receiver also works, if you want no position at all.

Keeping a log of your position

Tick **log to CSV** in the Position panel and a row is added to a file every few seconds, which you can open in a spreadsheet: date, time, latitude, longitude, locator, altitude, speed, course, satellites, HDOP, the age of the fix and a timestamp. The panel tells you where the file is — **gps_track.csv** in the program's folder on the Pi — and how many rows it holds. Untick it to stop. The **csv** command (section 9) does the same thing, and can change how often a row is written.

6. Making a contact

1. Type your callsign into **Station** → **my callsign**. It is sent with every transmission, so it must be correct.
2. Agree a frequency with the other station, then type it into **Radio** → **RX frequency (Hz)** and press **apply frequencies**. This sets transmit to the same frequency.
3. Listen first. When the other station speaks, the light shows **RX**, the signal bar moves, **in frame** appears and you hear them.
4. To reply, hold **PUSH TO TALK**, speak in your normal voice a little slower than a telephone call, then release.
5. Wait for the other station to finish before you press again — while you are transmitting, you cannot hear them.

Only transmit on frequencies your licence allows, and check what is already in use before you press. If you are testing, a dummy load or the lowest gain keeps you out of trouble.

Using a physical PTT switch

As well as the button on the page you can transmit with a switch wired to the Raspberry Pi's header — a hand microphone, a foot switch, or a small box you can hold. Pressing it transmits exactly as the button does, and the RX / TX light follows it, so you can put the browser down and operate normally.

Pin	What it is for
GPIO 11 (header pin 23)	One side of the switch. The other side goes to ground — for example header pin 25 or 9.
GPIO 10 (header pin 19)	An output that goes high while transmitting, to key an amplifier or another radio through a suitable interface.

Ask whoever set the system up before wiring anything to the header: the pins have to match, and the switch must go **to ground**, not to 3.3 V. Use a transistor or a relay for anything that draws real current — these are logic outputs, not a power supply. Note also that GPIO 10 and 11 are the SPI pins, so an SPI display would use them.

Releasing the switch returns you to receive. Releasing it does not cancel a transmission you started from the browser, so the two ways of transmitting do not fight each other.

7. Audio — where your voice comes from and goes

Set this once in the **Audio** panel; it stays set.

Option	What it means	When to use it
Raspberry Pi sound card (direct)	Uses the microphone and speaker plugged into the Pi. Talks to the sound card directly.	**Recommended.** The most reliable choice.
browser microphone / speaker	Uses the microphone and speakers of the computer you are browsing from, sent over the network.	When you are away from the Pi, or the Pi has no sound card. See the note below.
Raspberry Pi sound card (PulseAudio)	The same card, but through the PulseAudio sound service.	Only if something else on the Pi needs to share the card. Direct is more reliable.
browser + Pi sound card	Both at once, listening in two places.	Rarely needed.
mute (no audio)	Silence going out and coming in.	For testing.

A change takes effect at the start of your next transmission; the panel shows **(applying...)** until then.

If the browser refuses your microphone

Browsers only allow microphone access on a secure page. A page opened as **http://<address>:8080/** is not secure, so the microphone may be blocked. Either open **http://localhost:8080/** in a browser on the Pi itself, or use the Pi's sound card option instead — which avoids the problem completely and is what most users want.

Blank frames before voice, and the transmit health line

Next to the audio device there are two things worth knowing about.

blank frames before voice is the amount of silence sent at the start of each transmission, before your speech. It gives the receiving station time to lock onto your signal, so your first word is not clipped. The default is 4 (about 80 thousandths of a second). If people tell you the start of your first word is missing, set it to 6 or 8.

The line beside it — **transmit clean**, or **dropped N samples** — is the health of your transmit audio. **Transmit clean** means the Pi kept up with the radio for the whole transmission. If it reports dropped samples, raise the blank frames a little and try again; if it keeps reporting drops, the Pi is too busy (close other programs) or something needs looking at by whoever maintains the system.

volume and **mute** affect only what you hear in the browser. The small **mic** and **spk** bars show the audio levels going out and coming in — the mic bar should move when you speak.

8. The controls, panel by panel

Station

Control	What it does
my callsign	Your callsign. Sent with every transmission.
destination	Who you are calling. Leave as ALL unless you are calling one specific station.
gateway	Used when linking through a reflector or repeater (advanced).
listen to all	Receive everything on the frequency, whoever it is addressed to.
broadcast (ba)	Address the transmission to everyone (the usual choice on a calling channel).
help / clear log	Lists every command in the log, or empties the log.

Mode

How the station is wired up. **Radio** is the normal voice mode. **Loopback** feeds your own audio straight back, for practice with no radio or aerial. **Gateway** and **client** link the radio, or your audio, to a reflector over the internet.

Setting	What it does
radio (normal)	Radio in, sound out. Use this for contacts on a frequency.
loopback (practice)	Your own voice comes straight back, so you can check the microphone and the settings without transmitting.
gateway	The radio is bridged to a reflector: what you hear on frequency goes out to the reflector, and what comes back from the reflector goes out on frequency.
client	Your voice goes to the reflector over the internet, with no radio involved.

Changing the mode takes effect at once — you do not have to stop and start the program. If you are transmitting when you change it, the transmission stops. The choice is kept, so the same mode is still selected after a restart.

Radio

The receive controls are stacked above the transmit ones.

Control	What it does
RX frequency (Hz)	The frequency you listen on, in hertz (145500000 = 145.5 MHz).
TX frequency (Hz)	The frequency you transmit on. Usually the same as RX.
RX gain / TX gain	Receive and transmit levels. Leave them as they are unless someone asks you to change them.
freq correction	Fine tuning, for when a station sounds slightly off. Change it in small steps.
apply frequencies	Press this after changing a frequency or a gain, or nothing changes.
transmit carrier	Sends a plain carrier with no voice - for tests and alignment only.
receive	Returns to receiving if a transmission is stuck on, or after a test.
noise	Practice mode only: adds noise to the simulated signal.

Reflector

Reflectors link M17 stations over the internet, so you can talk to people out of radio range. Type the reflector's name — they are written like **M17-M17** — or pick one from the list that appears as you type, choose the channel letter (the **module**), and press **connect**. Press **disconnect** when you have finished: it is good manners, and it frees the channel for others.

Watch the log while you do it. It either says which address it is connecting to, or it says that the name is not in the list — in which case check the spelling against the reflector's own web page. The badge next to the buttons shows whether you are linked.

Reflector addresses do change over time. If a reflector that used to work stops working, ask whoever maintains the system to refresh the list: the program reads it from a file on the Pi, and the file has to be brought up to date (there is a tool for it). A stale address looks exactly like a connect button that does nothing. If you only want local radio contacts, ignore this panel.

Position

Your GPS position and Maidenhead locator in large letters, the compass showing where the station you are hearing is, and the tick box that keeps a log of your position in a file. Section 5 explains what each part means.

Audio

Control	What it does
audio device	Where your voice comes from and goes - see section 7.
blank frames before voice	Silence sent before your speech at the start of a transmission. Default 4.
enable browser audio	Must be pressed once (and permission given) before the browser can play or record audio.
volume / mute	What you hear in the browser.
mic / spk bars	Audio levels going out and coming in.

Console

Every setting also has a typed command, and the console is where you type them. You do not need it for normal operation; the help button lists the commands, and section 9 lists them all. The log below it shows what the program is doing — useful when something does not work.

9. Commands

Typed into the Console box, or into the program's own terminal. Type one command per line.

Command	What it does
rf 145500000	Set the receive frequency, in hertz.
tf 145500000	Set the transmit frequency, in hertz.
rg 0.5 / tg 0.5	Set the receive or transmit gain, from 0.0 to 1.0.

Command	What it does
fc 1.0001	Frequency correction, from 0.9 to 1.1.
afc on / off	Automatic frequency control.
tx / rx	Start or stop transmitting (the PTT button does the same).
td / tc	Transmit duplex, or transmit a plain carrier.
sa G4ABC	Source address: your callsign.
da ALL	Destination address: who you are calling.
ga G4ABC G	Gateway address.
ba	Broadcast: call everyone.
la on / off	Listen to all addresses, or only yours.
conn NAME C	Connect to a reflector, on module C.
disc	Disconnect from the reflector.
mode radio	Normal mode: radio in, sound out. Alternatives: **loop** (audio loops back for practice), **gate** (radio to reflector), **client** (sound to reflector). Takes effect at once, and is kept for the next start.
audio alsa	Voice through the Pi sound card. Alternatives: **browser**, **pulse**, **both**, **none**.
lead 4	Blank codec frames sent before the voice - see section 7.
gps	Show the GPS receiver, the fix and your locator. **gps /dev/ttyACM1 38400** uses a different receiver.
gps meta off	Stop sending your position to other stations; **gps meta on** starts again. The receiver keeps running, so the locator, the compass and the log are unaffected - see section 5.
csv on / csv off	Start or stop logging your position to a file - see section 5.
csv 10	Log a row every 10 seconds rather than every 5.
csv status	Show the log file and how many rows it holds.
load FILE	Run a list of commands from a file.
w	Clear the log pane.
b	Break: stop transmitting now.
q	Quit the program.
h	List the commands.

10. If something goes wrong

What you see	What to try
The page will not open at all	Check the address and the port (8080), and that the Pi is switched on and on the network. On the Pi, run **bash tools/pi_m17web.sh status**.
It says **offline** at the top	The page lost contact with the Pi. Reload the page. If it stays offline, check the program is still running on the Pi.

What you see	What to try
Nothing comes out of the speaker	In Audio, make sure the Pi's sound card is selected, the volume is up and mute is off, and that the speaker is plugged into the sound card (not the Pi's headphone socket).
The other station says my audio breaks up, or starts late	Look at the transmit health line in the Audio panel. Raise **blank frames before voice** to 6-8 and try again. If it still reports dropped samples, the Pi is struggling with something else running.
I hear nothing when the other station speaks	Check you are on the same frequency, and that **in frame** appears when they talk. If the signal bar moves but there is no audio, try **afc on**, then nudge **freq correction** slightly.
The browser will not use my microphone	Browsers only allow the microphone on a secure page. Use **http://localhost:8080/** on the Pi itself, or select the Pi's sound card instead (section 7).
The light never goes to TX	If the header says offline, the page cannot reach the Pi. Otherwise something else may be using the radio — stop and start the program.
The sound card is reported as busy	Another program (or an earlier run) is using it. Stop other audio programs, then stop and restart m17web.
The program will not start (port already in use)	An older copy is still running: **bash tools/pi_m17web.sh stop**, wait a moment, then start it again.
I transmit but nobody hears me	Test your own audio first, with no second operator needed: set the **destination** to **PARROT** and transmit for a few seconds. The reflector echoes your voice straight back, so if you hear yourself, your station is fine and the problem is at the far end (a listener on the wrong module, or a browser that has not been allowed to play audio). Set the destination back to **ALL**, or press **broadcast (ba)**, when you have finished.
The reflector will not connect	Type the name exactly as the reflector publishes it (**M17-M17**, not the short form), press connect, and read the log: it says which address it is trying, or that the name is not in the list. If the list is out of date, ask whoever maintains the system to refresh it. Some reflectors only answer on particular modules.
The locator is blank, or there is no position	The GPS receiver has not got a fix yet, or is not plugged in. A fix can take a minute or two outdoors, and from inside a building it may never arrive. Nothing else needs it, so carry on.
The physical PTT switch does nothing	Check the wiring first (section 6). On the Pi, **gpioinfo** should list GPIO 10 and 11 as used by m17web. If it shows something else, or the panel reports no hardware PTT, ask whoever maintains the system.
The radio cannot be found at all	The Pluto re-appears as a USB network interface when it is plugged in, and it needs the address 192.168.2.2. Check it is connected, then ask whoever maintains the system — this is covered in the README.

11. Good practice

- Transmit only on frequencies your licence covers, and at the lowest power that works.
- Listen before you transmit, and give way to a station already in contact.
- Keep your callsign correct in the Station panel — it is how other operators know who is calling.

- When using a reflector, say where you are going and disconnect when you have finished.
- For tests, use a dummy load or a carrier into a low gain rather than transmitting into the antenna.
- If you leave the system running, mute the audio if you do not want your room heard on the air.

12. Quick reference

Start it

```
cd /mnt/hf/shared/projects/m17_sdr_web/m17gismo
RADIO=pluto MODE=radio bash tools/pi_m17web.sh start -a alsa
```

Open it

```
http://10.168.1.33:8080/ (your own Pi's address)
```

Make a contact

Step	Do this
1	Station → my callsign: type your callsign.
2	Radio → RX frequency (Hz): type the agreed frequency, press **apply frequencies**.
3	Listen until you hear the other station (**in frame** appears).
4	Press and hold **PUSH TO TALK** (bottom right), speak, then release.
5	Let the other station finish before pressing again.

The three things that put most people right

If	Then
You cannot hear anything	Check the frequency, and whether **in frame** appears when the other station speaks. Try **afc on**.
Nobody can hear you	Look at the transmit line in the Audio panel. If it reports dropped samples, raise **blank frames before voice** to 6-8.
The page will not reach the Pi	On the Pi: **bash tools/pi_m17web.sh status**, then reload the page.

Your locator and position are in the header at the top of the page; **log to CSV** in the Position panel keeps a track of where you have been. A switch wired to the Pi transmits just as the button does. Settings worth knowing: **audio device** (use the Pi's sound card, direct), **blank frames before voice** (default 4) and **volume** in the Audio panel; **help** in the Station panel lists every command.

13. Where this came from, and further reading

m17web is a modification of **G4GUO/m17_sdr**, with the original terminal interface replaced by the web page described here. The M17 protocol it speaks is an open standard from the M17 Project; the voice coding is Codec2 by David Rowe and the M17 Project's Codec2-mod build. It uses the open-source libiio, ALSA, Codec2 and libgpiod libraries.

For the technical details — building it yourself, the audio back ends, the transmit timing and the rate planning — see **README.md** next to this manual, in the same folder.

The upstream project has no licence file, so this fork adds its own documentation only. Treat the software as you find it: it works, but check it against your own licence conditions before putting it on the air.

Notes

Frequencies in use locally, reflector names, who to call when it breaks: