

FlightGear G91-R Manual

Rick Gruber-Riemer

Table of Contents

1	FlightGear G91-R Documentation	1
1.1	About this Manual	1
1.2	FlightGear Requirements	1
1.3	License.	2

1 FlightGear G91-R Documentation

Welcome to the documentation of the [G91-R](#) for the [FlightGear](#) open source flight simulator.

While there are many variants of the G91, this model is concentrating on the G91-R versions.

There are quite a number of ways to write the name of this plane, like G.91R, G91R, G91-R, G-91R, etc. We have chosen to use G91-R in this documentation and to not mention the original manufacorer Fiat, since the plane was also built under license in Germany by [Dornier](#) and in Portugal by [OGMA-Indústria Aeronáutica de Portugal](#).



1.1 About this Manual

The goal of this manual is to provide information about the systems and operation of the G91-R model in FlightGear. This manual is a companion to the [G91-R4 Flight Manual - 1961.pdf](#) which also can be found in the [Docs](#) folder of the model. Therefore, only what is not in the flight manual and/or is specific to FlightGear is described in this manual.

For handling generic controls in FlightGear like flaps etc. see also the common aircraft keys in the [official FG manual](#).

1.2 FlightGear Requirements

You need at least FlightGear version [2024.1](#) to run this model. ALS should be enabled and your computer should have

a decent graphics card.

1.3 License

This FlightGear G91-R model including its documentation is licensed with [GNU GPL](#) version 2. See the [licence information](#) in the repo.

This document was generated on 2025-09-27 at 18:25.