

AVAILABLE SENSORS & DATA ID MAPPING



ENGINE 1 / ECU 1

Standard IDs + **DIY 50xx**



ENGINE 2 / ECU 2

DIY 51xx IDs

#	FUNCTION	UNIT	ECU 1 / ETHOS NAME	ECU 2 / ETHOS NAME	DESCRIPTION
1	 ECU Current (standard)	A	Standard 0x0200	DIY 510F	Standard current / ECU current equivalent
2	 ECU Battery Voltage	V (0.01V)	Standard 0x0210	DIY 510E	ECU battery voltage
3	 Exhaust Gas Temperature (EGT)	°C	Standard 0x0400	DIY 510C	Exhaust gas temperature
4	 Actual Turbine RPM	RPM	Standard 0x0500	DIY 510D	Actual turbine speed
5	 Remaining Fuel (%)	%	Standard 0x0600	DIY 5110	Remaining fuel percent
6	 Altitude	m	DIY 5000	DIY 5100	Altitude
7	 Fuel Pump Voltage	V (0.01V)	DIY 5001	DIY 5101	Fuel pump voltage
8	 ECU Current (custom high-res)	A (0.01A)	DIY 5002	DIY 5102	Custom ECU current
9	 Battery Capacity Used	mAh	DIY 5003	DIY 5103	Consumed battery capacity
10	 Engine State / Shutdown Code	—	DIY 5004	DIY 5104	State or shutdown condition
11	 Remaining Fuel Volume	ml	DIY 5005	DIY 5105	Remaining fuel volume
12	 Fuel Flow	ml/min	DIY 5006	DIY 5106	Fuel consumption per minute
13	 Thrust	N (0.1N)	DIY 5007	DIY 5107	Turbine thrust
14	 Commanded / Set RPM	RPM	DIY 5008	DIY 5108	Commanded turbine speed
15	 Airspeed	km/h	DIY 5009	DIY 5109	Airspeed
16	 Shaft RPM	RPM	DIY 500A	DIY 510A	Second shaft RPM
17	 Fuel Quality	%	DIY 500B	DIY 510B	Fuel quality



PHYSICAL IDs:

ECU 1 = **0x1B** | ECU 2 = **0x0D**



CUSTOM ID FORMULA:

0x5000 + ((ECU - 1) × 0x0100) + ParameterID



LEGEND / NOTES

- Current demo configuration supports 2 ECUs on one telemetry bus.
- ECU 1 uses FrSky standard IDs for the main basic values.
- ECU 2 uses the 0x51xx custom range to avoid collisions with ECU 1.
- In ETHOS, custom emulator sensors appear as DIY IDs such as DIY 5001, DIY 5004, DIY 5101, DIY 5104.
- This page is adapted for the GIB2A JetCat emulator, not generic JetCat multi-ECU documentation.

