Table 3-9A. 3456A Program Codes.

	Control	Program Cede
FUNCTION	Shift Function Off (Unshifted)	so
	DCV	F1
	ACV	F2 F3
	ACV+DCV 2 Wire K Ohms	F4
	4 Wire K Ohms	F5
	Shift Function On (Shifted)	S1
	DCV/DCV Ratio	F1
	ACV/DCV Ratio	F2
	ACV+DCV/DCV Ratio O.C. 2 Wire K Ohms	F3 F4
	O.C. 4 Wire K Ohms	F5
RANGE	Auto	R1
	100 mV or .1 K Ohms	R2
	1000 mV or 1 K Ohms	R3
	10 V or 10 K Ohms	R4
	100 V or 100 K Ohms 1000 V or 1 M Ohms	R5 R6
	10 M Ohms	R7
	100 M Ohms	R8
	1000 M Ohms	R9
TRIGGER	Internal	T1
	External	T2
	Single	Т3
	Hold	T4
AUTOZERO	On	Z1
	Off	ZO
FILTER	On	FL1
	Off	FLO
TEST	On	TE1
	Off	TEO
REGISTERS	Storing into Registers	ST
	Recalling Registers	RE
	Number of Readings	N
	Number of Digits Displayed Number of Power Line Cyc. Int.	G
	Delay	l b
	Mean Register (Read only)	M
	Varience Register (Read only)	V
	Count Register (Read only)	Ç
	Lower Register R Register	L R
	Upper Register	ľ
	Y Register	Y
	Z Register	Z
MATH	Off	МО
	Pass/Fail	M1
	Statistic (Mean, Variance, Count)	M2
	Null dBm	M3 M4
	Thermistor (°F)	M5
	Thermistor (°C)	M6
	Scale [(X - Z)/Y]	M7
	%Error [(X - Y)/Y x 100]	M8
	dB (20 Log X/Y)	М9
READING STORAGE	On	BC4
SYSTEM OUTPUT MODE	Off	RS1 RSO
	On Off	S01 S00
DISPLAY		
	On Off	D1 D0
OUTPUT FORMAT		1
	Packed Format On Packed Format Off (ASCII Format)	P1 PO
CLEAR-CONTINUE		1
CLEAR-CONTINUE	Active	CL1
NUMERIC SEPARATOR	Separates Numbers (e.g. F1W10STN)	W
HOME COMMAND	Software Reset	н
FRONT/REAR SWITCH SENSE	1 = Front, 0 = Rear	SW1
EOI	Enable	01
	Disable	01
PROGRAM MEMORY	İ	i
THOUSAN MEMORIA	Load Program (Syntax) On Load Program (Syntax) Off	L1 Q
	Execute Program Memory	X1