Drill rod 1–4
Drill rod guide 1–4

Effect of top layer 2–2, 4–8
Emergency procedures D–15
Encapsulation D–8
Exposure, limiting A–6
Extraction tool 1–4
Format
  Serial data B–5

Gamma rays A–4
Gasket, replacing A–11
Gauge
  Measurement geometry 2–3
  Source rod positions 3–4
Geiger-Mueller (G-M) detectors 1–2, 2–2
Geometry, gauge measurement 2–3

Half-value layer (HVL) D–7
Hazmat training B–3
Humidity F–6

Index rod positions 3–4
Inhibit, 15-second count 5–10
Inspection
  Daily 3–5, D–9
  Source rod D–9
  Upon receipt 1–6
International Air Transport Association (IATA) B–1
International Atomic Energy Agency (IAEA) B–1

Keypad 3–2, B–5

Languages 5–3
Leak test D–12
Licensing D–14
Limits
Drift test 5–6
Stat test 5–4
Liquid crystal display (LCD) B–5
Log, standard count E–1

Maintenance
Gasket A–11
Mechanical A–9
Sliding block D–10
Source rod bearing A–10
Malfunction indicators A–6
Marshall value 3–7
Marshall/Proctor (MA/PR) mode 3–7
Measurement
Asphalt mode 3–19
Depth 3–7
Mode 3–7
Site preparation 3–12
Soil mode 3–15
Source rod positions 3–4
Specifications B–2
Thin layer 4–8
Units 3–6
Mechanical
Maintenance A–9
Memory reset 5–10
Mode
Asphalt 3–7
Backscatter 2–2
Direct transmission 2–2
Ready 3–5
Selecting 3–7
Soil 3–7

Moisture
Measurement theory 2–5
Offset 4–2, 4–4
Monitoring personnel D–8

Neutrons A–4

Offset 4–2
Density 4–2, 4–3
Moisture 4–2, 4–4
Trench 4–2, 4–6
Operation
Special functions 5–1
Optional Features 5–1

Parameter setup 3–6
Parts
Gauge 1–4
Replacement A–12
Percent air voids 3–17
Photons A–4
Port
USB B–5
Position
Safe 3–4
Source rod 3–4
Precautions A–17
Precision B–2
Proctor value 3–7
Profile, radiation D–18

Radiation
Dose A–5
Exposure A–6
Monitoring A–8
Profile D–18
Safety A–5
Specifications B–4
Theory A–2
Types A–4
Radioactivity A–3
Reading
Asphalt mode 3–19
Soil mode 3–15
Ready mode 3–5
Recall 5–3
Recharge time B–5
Reference standard block 1–4, 3–9, 4–6, 5–4
Regulations D–14
Canadian shipping B–4
U.S. shipping D–2
Remote start 5–2
Replacement
Gaskets A–11
Parts A–12

Safe position 3–4
Scraper plate 1–4
Self-test 3–5
Serial
Data format B–5
Service A–14
Service Centers ii
Setup, parameters 3–6
Shielding D–7
Shipper's Declaration for Dangerous Goods B–2
Shipping D–1

Canadian requirements B–4
Case F–6
U.S. requirements D–2
Shutdown, automatic 3–3, B–4
Site
Asphalt measurement 3–14
Preparation 3–12
Soil and base course measurement 3–12
Sliding block, cleaning D–10
Soil mode 3–7
Source
Encapsulation D–8
Rod inspection D–9
Shielding D–7
Source rod
Bearing maintenance A–10
Positions 3–4
Special
Functions 5–1
Specific gravity 5–8
Specifications B–1
Measurement B–2
Standard count 3–9
Log E–1
Standards, American Society of Testing and Materials (ASTM) 1–2
Stat test 5–4
Limits 5–4
Storage, data 5–2

Taking a measurement
Asphalt mode 3–19
Soil mode 3–15
Temperature F–6
Test
Drift 5–6
Stat 5–4

Theory
Density measurement 2–2
Moisture measurement 2–5
Radiation A–2
Thermoluminescent dosimeter (TLD) D–8
Thin layer measurements 4–8
Time, count 3–6
Top layer effect 2–2, 4–8
Training D–14
Hazmat B–3
Transport case F–6
Transport Packaging of Radioactive Materials Regulations (TPRM) B–4
Transportation
Canadian requirements B–4
U.S. requirements D–2
Transportation of Dangerous Goods Act and Regulations (TDG) B–4
Trench offset 4–2, 4–6
Troubleshooting A–2

U.S. shipping requirements D–2
Units
Measurement 3–6
Unpacking 1–6
USB port B–5
Compatible devices B–5
USB Port 5–2

View data 5–3
Void ratio 3–17
Voidless density 5–9

TROXLER ELECTRONIC LABORATORIES, INC.

LIMITED WARRANTY

TROXLER ELECTRONIC LABORATORIES, INC., and subsidiary, TROXLER INTERNATIONAL, LTD., hereinafter referred to as "TROXLER," warrants this instrument, Model_____, Serial Number_____, against defects in material and workmanship for a period of twelve (12) months from date of shipment. For products sold through authorized TROXLER representatives, the date of shipment will be as of the transfer from representative to purchaser. During the applicable warranty period, TROXLER's obligation under this warranty shall be limited exclusively to the repair at a TROXLER facility at no charge, except for shipping to and from TROXLER'S plant, of any instrument which may prove defective under normal use and which TROXLER's examination shall disclose to its satisfaction to be thus defective. Normal use is defined for the purpose of this warranty as operation under normal load, usage, and conditions with proper care and maintenance and competent supervision. In no event shall TROXLER be held liable for damages, delays, or losses consequential, incidental, or otherwise attributable to the failure of this instrument. TROXLER's liability being specifically limited to repair as stated hereinabove. This warranty is automatically initiated except where modified by contractual or other written and signed agreement.

THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF, AND THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, AND TROXLER NEITHER ASSUMES, NOR AUTHORIZES ANYONE TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH THE SALE OF THE INSTRUMENT. THIS WARRANTY SHALL NOT APPLY TO THE INSTRUMENT OR ANY PART THEREOF, WHICH HAS BEEN SUBJECTED TO DAMAGE BY ACCIDENT, NEGLIGENCE, ALTERATION, ABUSE, MISUSE, OR SERVICE NOT AUTHORIZED IN WRITING BY TROXLER. SUCH DAMAGE TO INCLUDE BUT NOT BE LIMITED TO BURNING OF CIRCUIT BOARDS AND HARNESS FROM IMPROPER SOLDERING TECHNIQUES AND DAMAGE TO THE INSTRUMENT DUE TO PURCHASER'S FAILURE TO PERFORM MAINTENANCE AS OUTLINED IN THE AUTHORIZED OPERATOR'S MANUAL. DUE TO THE NATURE OF THEIR USE, MECHANICAL ACCESSORY PARTS AND BATTERIES ARE WARRANTED FOR 90 DAYS ONLY FROM DATE OFSHIPMENT.

TROXLER ELECTRONIC LABORATORIES, INC.
3008 E. Cornwallis Road
Post Office Box 12057
Research Triangle Park, NC 27709 USA

NOTICE TO CONSUMERS

Any disclaimer or limitation on the remedies expressed above shall not be effective to the extent prohibited by state or federal law.

NOTE: THIS WARRANTY EXCLUDES DAMAGE INCURRED IN SHIPMENT. IF THIS INSTRUMENT IS RECEIVED IN DAMAGED CONDITION, THE CARRIER SHOULD BE CONTACTED IMMEDIATELY. ALL CLAIMS FOR DAMAGE IN TRANSIT SHOULD BE FILED WITH THE CARRIER. IF REQUESTED, TROXLER WILL AID IN FILING OF CLAIMS AND/OR LOCATING PRODUCTS LOST IN TRANSIT.