



MASERATI

Ghibli

MASERATI TOUCH CONTROL





MASERATI

Maserati Touch Control



The vehicle is equipped with the info-telematics Maserati Touch Control (MTC) System, an advanced user interface which combines innovative and exclusive technical features combining entertainment, user settings, air conditioning, navigation, communication and information functions within a single system.

The Maserati Touch Control system comes equipped with an audio system, acoustically optimized for this vehicle.

The vehicle is provided with this specific add to the Owner's Manual, describing the Maserati Touch Control system fully and listing all warnings and precautions for use, which are essential for safe use of the system. Maserati recommends you to read the add carefully and thoroughly.

The information in this publication is provided by using examples.

Maserati may modify for technical or marketing purposes the specifications of the system described in this publication at any time.



WARNING!

The Navigation System assists the driver while driving, providing advice and suggestions, by means of voice guidance and graphic information, for the best route to take for reaching the set destination. The suggestions provided by the Navigation System do not relieve the driver from full responsibility for the maneuvers made through traffic while driving, or from compliance with road regulations and other provisions regarding road traffic. The person driving the vehicle is always and in any case responsible for safe driving on the road.



Safety Guidelines

1

Devices, controls and buttons

2

Radio mode

3

Player Mode

4

Controls Mode

5

Climate mode

6

Navigation Mode

7

MTC System Phone

8

Settings

9

Index

10





1 – Safety Guidelines

Safety Guidelines	6
Safety references	6
Intended use.	7
Navigation system — Safety precaution and important information	7
System care	8
Gracenote	9
Dolby	11



Safety Guidelines

Ensure that all persons read this manual carefully before using the MTC System. It contains instructions on how to use the system in a safe and effective manner.



WARNING!

Please read and follow these safety precautions. Failure to do so may result in injury or property damage.

- Glance at the screen only when necessary and safe to do so. If prolonged viewing of the screen is necessary, pull over at a safe location.
- Stop use immediately if a problem occurs. Failure to do so may cause injury or damage to the product. Return it to your authorized dealer to repair.
- Make certain that the volume level of the system is set to a level that still allows you to hear outside traffic and emergency vehicles.
- The law in some states prohibits the Front Seat DVD Viewer. As a result, it may be disabled prior to delivery to you. If you move to another state,

you should consult your dealer for the proper enable/disable setting for your new state. Currently all states prohibit front seat video viewers except for: Arkansas, Delaware, Georgia, Hawaii, Idaho, Iowa, Kentucky, Mississippi, Missouri, Montana, North Dakota and Ohio.



WARNING!

This manual contains WARNINGS against operating procedures that could result in an accident or bodily injured. If you do not read the entire manual, you may miss important information. Observe all WARNINGS!

NOTE:

The information given in this manual is subject to change.

Safety references

Before operating this system for the first time, please read this manual carefully. Note the safety precautions described in this manual. If you have any questions, please contact Maserati or your authorized dealer.



Intended use

Generally recognized rules of radio technology were maintained during the development and manufacture of this system. When using this product, be aware of state/province-specific norms and guidelines.

Navigation system — Safety precaution and important information

Read this information carefully before starting to operate the Navigation System and follow the instructions in this manual. Neither Maserati nor Garmin shall be liable for problems or accidents resulting from failure to observe the instructions in this manual.

Failure to avoid the following potentially hazardous situations could result in an accident or collision resulting in death or serious injury.

- Always use your best judgment, and operate the vehicle in a safe manner. Do not become distracted by the Navigation System while driving, and always be fully aware of all driving conditions. Minimize the amount of time spent viewing the Navigation System screen while driving and use voice prompts when possible.
- Do not input destinations, change settings, or access any functions requiring prolonged use of the Navigation System controls while driving. Pull over in a safe and legal manner before attempting such operations.

- When navigating, carefully compare information displayed on the Navigation System to all available navigation sources, including road signs, road closures, road conditions, traffic congestion, weather conditions, and other factors that may affect safety while driving. For safety, always resolve any discrepancies before continuing navigation, and defer to posted road signs and road conditions.
- The Navigation System is designed to provide route suggestions. It is not a replacement for driver attentiveness and good judgment. Do not follow route suggestions if they suggest an unsafe or illegal maneuver or would place the vehicle in an unsafe situation.
- Be careful of the ambient temperature. Using the Navigation System at extreme temperatures can lead to malfunction or damage. Also note that the unit can be damaged by strong vibration, by metal objects, or by water getting inside the unit.



WARNING!

**The Navigation System is designed to
(Continued)**



(Continued)
provide you with route suggestions. It does not reflect road closures or road conditions, weather conditions, or other factors that may affect safety or timing while driving.

Use the Navigation System only as a navigational aid. Do not attempt to use the Navigation System for any purpose requiring precise measurement of direction, distance, location, or topography.

The Global Positioning System (GPS) is operated by the United States government, which is solely responsible for its accuracy and maintenance. The government system is subject to changes that could affect the accuracy and performance of all GPS equipment, including the Navigation System.

System care

Safe usage of the MTC System

Read all instructions in this manual carefully before using your system to ensure proper usage! Your system is a sophisticated electronic device. Do not let young children use your system. Permanent hearing loss may occur if you play your music or the system at loud volumes. Exercise caution when setting the volume on your system. Driving is a complex activity that requires your full attention. If you're engaged in driving or any activity that requires your full attention, we recommend that you do not use your system.

NOTE:

Many features of this system are speed dependent. For your own safety, it is not possible to use the touch screen keyboard while the vehicle is in motion. Keep drinks, rain, and other sources of moisture away from your system. Besides damage to your system, moisture can cause electric shocks as with any electronic device.

Connections

Never force any connector into the ports of your system.

Make sure your connectors are the correct shape and size before you connect.

Any attached cable should be routed so that it will not apply any pressure to the connection.

Touch screen

Do not touch the screen with any hard or sharp objects (pen, USB stick, jewelry, etc.) which could scratch the touch screen surface!

NOTE:

It is possible to use a plastic stylus for press screen enabled devices such as a PDA and Pocket PCs. Do not spray any liquid or caustic chemicals directly on the screen! Use a clean and dry micro fiber lens cleaning cloth in order to clean the touch screen.

If necessary, use a lint-free cloth dampened with a cleaning solution, such as isopropyl alcohol, or an isopropyl alcohol and water solution ratio of 50:50. Be sure to follow the solvent manufacturer's precautions and directions.

CD/DVD Drive

Do not insert any damaged, warped, scratched or dirty CDs or DVDs into the CD/DVD player. Discs that have been modified with an adhesive label should not be used in the CD/DVD player. Do not insert more than one CD/DVD at a time into the drive slot.

GPS Navigation Antenna

The GPS navigation antenna could be installed on different areas of the dashboard (depending on the vehicle model). Do not place items on the dashboard around the GPS antenna location. Objects placed within the line of sight of the antenna will decrease performance. Do not place items directly on or above the antenna.

Satellite Radio Antenna

The satellite radio antenna is mounted on the roof of the vehicle. Do not place items on the roof around the roof top antenna location. Objects placed within the line of sight of the antenna will cause decreased performance.

Larger luggage items should be placed as far from the antenna as possible.

Do not place items directly on or above the antenna.

Other Electronic Devices

You may bring other electronic devices into your vehicle (e.g., PDA, iPod, laptop computer, etc.). Some of these devices may cause electromagnetic interference with the GPS. If a degradation in the Navigation System is observed, turn the devices off, or keep them as far away from the GPS antenna as possible.

Gracenote®

MTC System is equipped with the **Gracenote®** Music Recognition Service fig. 1, with an embedded database to look up album, song title, genre and artist information. Data will be found for most Audio CDs (CDA discs). Data will not be found for DVDs or data discs (those with MP3 or WMA files).



fig. 1

About Gracenote®

Music recognition technology and related data are provided by **Gracenote®**. Gracenote is the industry standard in music recognition technology and related content delivery. For more information visit www.gracenote.com.



Gracenote Proprietary Legends

CD and music-related data from Gracenote, Inc., copyright© 2000 to present Gracenote. Gracenote Software, copyright© 2000 to present Gracenote.

One or more patents owned by Gracenote apply to this product and service. See the Gracenote website for a non-exhaustive list of applicable Gracenote patents. Gracenote, CDDb, MusicID, MediaVOCs, the Gracenote logo and logotype, and the "Powered by Gracenote" logo are either registered trademarks or trademarks of Gracenote in the United States and/or other countries.

NOTE:

Visit www.maserati.com for update information.

Gracenote® End User License Agreement

This application or device contains software from Gracenote, Inc. of Emeryville, California ("Gracenote"). The software from Gracenote (the "Gracenote Software") enables this application to perform disc and/or file identification and obtain music-related information, including name, artist,

track, and title information ("Gracenote Data") from online servers or embedded databases (collectively, "Gracenote Servers") and to perform other functions. You may use Gracenote Data only by means of the intended End-User functions of this application or device.

You agree that you will use Gracenote Data, the Gracenote Software, and Gracenote Servers for your own personal non-commercial use only. You agree not to assign, copy, transfer or transmit the Gracenote Software or any Gracenote Data to any third party. YOU AGREE NOT TO USE OR EXPLOIT GRACENOTE DATA, THE GRACENOTE SOFTWARE, OR GRACENOTE SERVERS, EXCEPT AS EXPRESSLY PERMITTED HEREIN. You agree that your non-exclusive license to use the Gracenote Data, the Gracenote Software, and Gracenote Servers will terminate if you violate these restrictions. If your license terminates, you agree to cease any and all use of the Gracenote Data, the Gracenote Software, and Gracenote Servers. Gracenote reserves all rights in Gracenote Data, the Gracenote Software, and the Gracenote Servers, including all ownership rights. Under no circumstances will Gracenote

become liable for any payment to you for any information that you provide. You agree that Gracenote, Inc. may enforce its rights under this Agreement against you directly in its own name.

The Gracenote service uses a unique identifier to track queries for statistical purposes. The purpose of a randomly assigned numeric identifier is to allow the Gracenote service to count queries without knowing anything about who you are. For more information, see the web page for the Gracenote Privacy Policy for the Gracenote service.

The Gracenote Software and each item of Gracenote Data are licensed to you "AS IS." Gracenote makes no representations or warranties, express or implied, regarding the accuracy of any Gracenote Data from in the Gracenote Servers. Gracenote reserves the right to delete data from the Gracenote Servers or to change data categories for any cause that Gracenote deems sufficient. No warranty is made that the Gracenote Software or Gracenote Servers are error-free or that functioning of Gracenote Software or Gracenote Servers will be uninterrupted. Gracenote is not obligated to provide you with new enhanced or additional



data types or categories that Gracernote may provide in the future and is free to discontinue its services at any time.

GRACENOTE DISCLAIMS ALL WARRANTIES EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE, AND NON-INFRINGEMENT. GRACENOTE DOES NOT WARRANT THE RESULTS THAT WILL BE OBTAINED BY YOUR USE OF THE GRACENOTE SOFTWARE OR ANY GRACENOTE SERVER. IN NO CASE WILL GRACENOTE BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES OR FOR ANY LOST PROFITS OR LOST REVENUES. Copyright© 2000 to present Gracernote.

Dolby®

Dolby and the double-D symbol are registered trademarks of Dolby Laboratories.





2 – Devices, controls and buttons

Overview	14
----------------	----



Overview

MTC System has a series of devices, controls and soft-keys through which it is possible to use external multimedia resources, different audio options, settings changes and other functions. All controls are located in the central part of the instrument panel fig. 2.

1. ON/OFF button & Volume Control knob
2. Enter/Browse button & Tune/Scroll knob
3. USB/AUX port & SD Card slot
4. CD/DVD slot
5. CD/DVD eject button
6. Radio soft-key
7. Player soft-key
8. Controls soft-key
9. Climate soft-key
10. Nav soft-key
11. Phone soft-key
12. Settings soft-key



(1) ON/OFF Button & Volume Control Knob

Press the ON/OFF button to turn the unit ON or OFF.

Rotate the knob to adjust the Volume. When the MTC System is activated, the screen displays the following warnings fig. 3:

“Important: Always obey traffic laws and pay attention to the road. Some features are limited while the vehicle is in motion. Please read the owner’s manual for complete details.”

The system asks for confirmation of warning acknowledgment by using the Accept soft-key.

If the Accept soft-key is not served within a few seconds, the system switches to the main screen anyway.

fig. 2

The system also displays the active settings of the commands, on the lower part of the screen:
Heated Seat (Driver & Passenger),
Vented Seat (Driver & Passenger) and
Heated Wheel.



fig. 3

NOTE:

If the ignition is switched OFF with the MTC System in standby mode, the system memorizes the standby mode when the ignition is turned ON again. Press the ON/OFF button to turn the MTC System ON. It is possible to eject the CD and to display the time if the system is off. The navigation software is always working when the ignition is switched ON, even if the MTC System is in standby mode. It is possible to eject the CD and to display the time if the unit is switched off.

(2) Enter/Browse Button & Tune/Scroll Knob

Press the Enter/Browse button to accept a highlighted selection on the screen.

Rotate the Tune/Scroll rotary knob to scroll through a list or tune a radio station.

(3) USB/AUX Port & SD Card Slot

Insert a USB device or iPod and cable into the USB Port or a SD Card into the slot containing audio media in order to play them through the vehicle sound system.

(4) CD/DVD Slot

When inserting a disc, make sure the label is facing up.

(5) CD/DVD Eject Button

Press the Eject button to eject the disc.

(6) Radio Soft-key

Press the Radio soft-key to enter the Radio Mode. The different tuner modes FM, AM and DAB can be selected by touching the corresponding soft-keys in the Radio Mode.

(7) Player Soft-key

Press the Player soft-key to access media sources such as: Disc, USB Device, AUX Device, SD Card and Bluetooth as long as the requested media is present.

(8) Controls Soft-key

Press the Controls soft-key to access the settings list (refer to your vehicle's Owner's Manual for further details). Controls such as Heated Seat (Driver & Passenger), Vented Seat (Driver & Passenger), Heated Wheel, Rear Sunshade and Screen OFF can be selected, adjusted or turned ON/OFF by touching the corresponding soft-key.

(9) Climate Soft-key (On-Screen Controls)

Refer to Climate Controls in your vehicle's Owner's Manual for further details.

(10) Nav Soft-key

Press the Nav soft-key to access the Navigation feature. Refer to the Navigation section in this manual for further details.



(11) Phone Soft-key

Press the Phone soft-key to access the Phone feature. Refer to the Phone section for further details.

(12) Settings Soft-key

Press the Settings soft-key to access additional options. Options available can be accessed by touching the corresponding soft-key in the Settings Menu.



3 – *Radio mode*

Overview	18
Common radio functions	18
Seek and direct tune functions	19
Setting Presets	20
Audio	24
 VR MTC System Voice Command Button	25
Voice Commands	27
Voice Tree	27



Overview

The Radio is equipped with the following modes:

- FM
- AM
- DAB or SAT (where available)

Touch the Radio Soft Key, bottom left corner, to enter the Radio Mode. The different tuner modes FM, AM (SW, MW, LW), DAB (Digital Audio Broadcasting, fig. 4A) or SAT (SiriusXM™ Satellite Radio, fig. 4B) can then, be selected by touching the corresponding soft-keys in the Radio mode.



fig. 4A



fig. 4B (U.S./CDN Version)

Common radio functions

The following operations offer the same functionality across all Radio Modes, and further instructions are provided where differences exit.

ON/OFF & Volume control

Push the ON/OFF button to turn on the MTC System. Push the ON/OFF button a second time to turn off the system. The electronic volume control turns continuously (360 degrees) in either direction, without stopping. Turning the Volume control knob clockwise increases the volume, and anti-clockwise decreases it. When the audio system is turned on, the sound will be set at the same volume level as last played.

Tune/Scroll & Enter/Browse

Turn the rotary Tune/Scroll control knob clockwise to increase or counterclockwise to decrease the radio station frequency. Push the Enter/Browse button to choose a selection.



Seek and direct tune functions

The Seek Up and Down functions are activated by touching the double arrow soft-keys to the right A fig. 5 and left B of the radio station display, or by pressing the left Steering Wheel Audio Control up or down.



fig. 5

Seek Up

Touch and release the Seek Up soft-key A to tune the radio to the next listenable station or channel. During a Seek Up function, if the radio reaches the starting station after passing through the entire band two times, the radio will stop at the station where it began.

Fast Seek Up

Touch and hold the Seek Up soft-key A to advance the radio through the available stations or channels at a faster rate, the radio stops at the next available station or channel when the soft-key is released.

Seek Down

Touch and release the Seek Down soft-key B to tune the radio to the next listenable station or channel. During a Seek Down function, if the radio reaches the starting station after passing through the entire band two times, the radio will stop at the station where it began.

Fast Seek Down

Touch and hold the Seek Down soft-key B to advance the radio through the available stations or channel at a faster rate, the radio stops at the next available station or channel when the soft-key is released.

Direct Tune

Press the Tune soft-key located at the bottom of the radio screen. The Direct Tune soft-key screen is available in FM, AM and DAB/SAT radio modes and can

be used to direct tune the radio to a desired station or channel. Press the available number soft-key to begin selecting a desired station fig. 6. Once a number has been entered, any numbers that are no longer possible (stations that cannot be reached) will become deactivated/grayed out. Once the last digit of a station has been entered, the DIRECT TUNE screen will close and the system will automatically tune to that station. The selected Station or Channel number is displayed in the Direct Tune text box.



fig. 6



Setting Presets

Presets are available for all Radio Modes, and are activated by touching any of the six Preset soft keys A fig. 7, located at the top of the screen. On touch screen soft-keys not stored with radio station, the following message will display: "HOLD to Set". When you are receiving a station that you wish to commit into memory, press and hold the desired numbered soft-key for more than 2 seconds or until you hear a confirmation beep. When storing a radio station on a soft-key which was already set, the last will be deleted and replaced by the new setting.

The Radio stores up to 12 presets in each of the Radio modes. A set of 6 presets are visible at the top of the radio screen.

You can switch between the two radio presets by touching the arrow soft key B located in the upper right of the radio screen.



fig. 7

Browse in FM/AM/DAB

When in FM, AM or DAB, the Browse Screen provides a means to edit the Presets List and is entered by touching the browse soft key fig. 7.

Scrolling Preset List

Once in the Browse Presets screen, you can scroll the preset list by rotation of the Tune knob, or by touching the Up and Down arrow keys A fig. 8, located on the right of the screen.



fig. 8

Preset Selection from List

A Preset can be selected by touching any of the listed Presets, or by pressing the Enter/Browse button on the Tune Knob to select the currently highlighted Preset.

When selected, the radio tunes to the station stored in the Preset and returns to the main radio screen.

Deleting Presets

A Preset can be deleted in the Presets Browse screen by touching the Trash Can Icon B fig. 8 for the corresponding Preset.

Return to Main Radio Screen

You can return to the Main Radio Screen, by touching the X soft key C fig. 8 when in the Browse Presets screen.



SiriusXM™ Satellite Radio Mode



fig. 8A (U.S./CDN Version)

SiriusXM™ Satellite radio uses direct satellite-to-receiver broadcasting technology to provide clear digital sound, coast to coast. The subscription service provider is SiriusXM™ Satellite Radio. This service offers over 130 channels of music, sports, news, entertainment, and programming for children, directly from its satellites and broadcasting studios. A one-year SiriusXM™ Satellite Radio subscription is included.

SiriusXM™ and all related marks and logos are trademarks of SiriusXM™ Radio Inc. and its subsidiaries. SiriusXM™ Radio requires a subscription, sold separately after trial subscription included with vehicle

purchase. Prices and programming are provided by SiriusXM™ and are subject to change. Subscriptions governed by Terms & Conditions available at sirius.com/serviceterms. SiriusXM™ Radio U.S. service only available to those at least 18 years of age in the 48 contiguous United States, D.C., and PR. Service available in Canada; see www.siriuscanada.ca. This functionality is only available for radios equipped with a Satellite receiver. In order to receive satellite radio, the vehicle needs to be outside with a clear view to the sky. If the screen shows Acquiring Signal, you might have to change the vehicle's position in order to receive a signal. In most cases, the satellite radio does not receive a signal in underground parking garages or tunnels.

No Subscription

Radios equipped with a Satellite receiver, require a subscription to the SiriusXM™ Service. When the Radio does not have the necessary subscription, the Radio is able to receive the Traffic/Weather channel only.

Acquiring SiriusXM™ Subscription

To activate the SiriusXM™ subscription, call the toll free number on the Weather channel. You will need to provide the Sirius ID (SID) located at the bottom of the Channel 0 screen.

The SiriusXM™ Satellite Mode is activated by a touch of the SAT soft-key.

When in SiriusXM™ Satellite mode:

- The SAT button is highlighted.
- The SiriusXM™ Presets are displayed at the top of the screen.
- The Genre is displayed below the Presets Bar.
- The SiriusXM™ Channel Number is displayed in the center.
- The Program Information is displayed at the bottom of the Channel Number.
- The SiriusXM™ function soft-keys are displayed below the Program Information.

Tuning is done by operating the Tune Knob or by Direct Tune, similar to other Radio Bands, see Presets, browse, Tune Knob, and Direct Tune. In addition to the tuning Operation functions common to all Radio modes, the replay, Traffic/Weather Jump, and



fav soft-key functions are available in SiriusXM™ Mode.

Replay

The replay function provides a means to store and replay up to 22 minutes of music audio and 48 minutes of talk radio.

Touch the replay soft-key. The play/pause, rewind/forward and live soft-keys will display at the top of the screen, along with the replay time. Replay can be exited by touching the replay soft-key, any time during the Replay mode.

Play/Pause

Touch the Pause or Play soft-key to pause playing of the content at any time that the content is playing live or rewound content. Play can be resumed again by touching of the Pause/Play soft-key.

Rewind

Touch the RW soft-key to rewind the content in steps of 5 seconds. Touching the RW soft-key for more than 2 seconds rewinds the content. The Radio begins playing the content at the point at which the touch is released.

Forward

Each touch of the FW soft-key forwards the content in steps of 5 seconds. Forwarding of the content can only be done when the content is previously rewound, and therefore, can not be done for live content. A continuous touch of the FW soft-key also forwards the content. The Radio begins playing the content at the point at which the touch is release.

Live

Touch the Live soft-key to resume playing of Live content.

Favorites

Touch the fav. soft-key to activate the favorites menu, which will time out in 5 seconds in absence of user interaction.

You can exit the Favorites Menu by a touch of the X in the top right corner. The favorites feature enables you to set a favorite artist, or song that is currently playing. The Radio then uses this information to alert you when either the favorite song, or favorite artist are being played at any time by any of the SiriusXM™ Channels. The maximum number of favorites that can be stored in the Radio is 50.

Fav. Artist While the song is playing to set a Favorite Artist, touch the fav.

soft-key and then the Fav. Artist soft-key.

Fav. Song While the song is playing to set a Favorite Song, touch the fav. soft-key and then the Fav Song soft-key.

Traffic & Weather

Touch the Traffic & Weather soft-key to tune to a SiriusXM™ Traffic & Weather channel. To set a Traffic & Weather alert for any one of the cities in the Browse list, see Browse in SAT. When the Traffic & Weather soft-key is touched, the Jump Traffic & Weather channel is tuned.

If the Traffic & Weather alert City is not set, you are presented with a pop up to allow you to select the favorite city using the Browse Screen.

Browse in SAT

Touch the browse soft-key to edit Presets, Favorites, Game Zone, and Jump settings, along with providing the SiriusXM™ Channel List. This Screen contains many sub menus. You can exit a sub menu to get back to a parent menu by a touch of the ◀ arrow.



All

Touch the All soft-key at the left of the Browse Screen.

Channel List

Touch the Channel List to display all the SIRIUS Channel Numbers along with the corresponding Genre. You can scroll the Channel list by touching the up and down arrows, located on the right side of the screen. Scrolling can also be done by operating the Tune/Scroll Knob.

Genre

Touch the Genre button to display a list of Genres. You can select any desired Genre by touching the Genre list, at which point, the Radio tunes to a channel with the content in the selected Genre.

Presets

Touch the Presets soft-key located at the left of the Browse screen. You can scroll the Presets list touching the up and down arrows, located at the right side of the screen. Scrolling can also be done by operating the Tune/Scroll Knob as well.

Preset Selection

A Preset can be selected by touching any of the listed Presets, or by pressing the ENTER/BROWSE button on the

Tune Knob to select the currently highlighted Preset. When selected, the Radio tunes to the station stored in the Preset, and returns to the main Radio screen.

Deleting a Preset

A Preset can be deleted in the Presets Browse screen by touching the Trash Can Icon for the corresponding Preset.

Favorites

Touch the Favorites soft-key, located at the left of the Browse screen. The Favorites menu provides a means to Edit the Favorites list and to configure the Alert Settings, along with providing a list of Channels currently airing any of the items in the Favorites list. You can scroll the Favorites list touching the up and down arrows, located at the right side of the screen. Scrolling can also be done by operating the Tune/Scroll Knob as well.

On Air

Touch the On-Air tab at the top of the screen. The On-Air list provides a list of Channels currently airing any of the items in the Favorites list, and touching any of the items in the list tunes the radio to that channel.

Remove Favorites

Touch the Remove Favorites tab at the top of the screen. Touch the Delete All soft-key to delete all of the Favorites or touch the Trash Can icon next to the Favorite to be deleted.

Alert Settings

Touch the Alert Setting tab at the top of the screen. The Alert Settings menu allows you to choose from a Visual alert or Audible and Visual alert when one of your favorites is airing on any of the SIRIUS channels.

Game Zone

Touch the Game Zone soft-key, located at the left of the Browse screen. This feature provides you with the ability to select teams, edit the selection, and set alerts.

On Air

Touch the On-Air tab at the top of the screen. The On-Air list provides a list of Channels currently airing any of the items in the Selections list, and touching any of the items in the list tunes the radio to that channel.

Select Teams

Touch the Select Teams soft-key to activate the League Scroll list. Touch the chosen league and a scroll list of all teams within the league will



appear, then you can select a team by touching the corresponding box. A check mark appears for all teams that are chosen.

Remove Selection

Touch the Remove Selection tab at the top of the screen. Touch the Delete All soft-key to delete all of the Selections or touch the Trash Can icon next to the Selection to be deleted.

Alert Settings

Touch the Alert Setting tab at the top of the screen. The Alert Settings menu allows you to choose from “Alert me to on-air games upon start” or “Alert upon score update” or both when one or more of your selections is airing on any of the SIRIUS channels.

Traffic & Weather

Touch the Traffic & Weather soft-key to tune to a SiriusXM™ Traffic & Weather channel.

Touch the Up and Down arrows to the right side of the list to view all the available cities. This operation can also be done with operation of the Scroll/Tune Knob.

Touch the check box next to the desired City. A check mark appears besides the selected City.

Audio

Touch of the audio soft-key fig. 9 to activate the Audio settings screen to adjust Balance/Fade, Equalizer, Speed Adjusted Vol., Music Info Cleanup and Surround Sound fig. 10. You can return to the Radio screen by touching the X located at the top right.



fig. 9



fig. 10

Balance/Fade

Touch the Balance/Fade soft-key fig. 10 to balance audio between the front speakers or fade the audio between the rear and front speakers.

Touching the Front, Rear, Left, or Right soft-keys or touch and drag the blue Speaker Icon to adjust the Balance/Fade.

Equalizer

Touch the Equalizer soft-key fig. 11 to activate the Equalizer screen.

Touch the + or - soft-keys, or by touching and dragging over the level bar for each of the equalizer bands. The level value, which spans between ± 9 , is displayed at the bottom of each of the Bands.



fig. 11



Speed Adjusted Volume

Touch the Speed Adjusted Vol. soft-key fig. 12 to activate the Speed Adjusted Volume screen. The Speed Adjusted Volume is adjusted by touching of the Off, 1, 2 or 3 soft-keys. This alters the automatic adjustment of the audio volume with variation to vehicle speed.



fig. 12

Music Info Cleanup

Touch the Music Info Cleanup soft-key fig. 13 to activate the information screen.

Touch the On soft-key to activate the Music Info Cleanup. Touch Off to deactivate this feature. When Music Info Cleanup is On, the radio uses the Gracenote® database to display standard normalized

information for song title, artist, album, etc.



fig. 13

Surround Sound

Touch the Surround Sound soft-key fig. 14 to activate the Surround Sound screen. This feature is not available in all modes.

Touch the On soft-key to activate Surround Sound.

Touch Off to deactivate this feature. When Surround Sound is On, you can hear audio coming from every direction as in a movie theatre or when using a home theatre system. The different Sound Surround functions can be activated by touching the related soft keys:

- Stereo
- Audience
- On Stage



fig. 14

VR MTC System Voice Command Button

The MTC Voice Command allows you to control the Radio, Disc Player, SD Card, and USB/iPod/AUX/Bluetooth devices.

NOTE:

Remember to speak in a normal and peaceful way by turning to the microphone of the voice command system located in the front dome courtesy light group. The ability of the system voice control to recognize the user's voice commands can be invalidated if you speak quickly or loud.



WARNING!

Any voice-controlled system should be used only in safe driving conditions according to local regulations.

Maintain constant attention to driving. Failure to observe these precautions may result in an accident causing serious injury and even fatal outcome.

By pressing the MTC Voice Command System  button, a beeping sound will invite you to impart a voice command. If no voice command is imparted, the system will respond:

- "I didn't understand"
- "I didn't get that", ecc.

If no subsequent voice command is imparted, the system responds with an error message and provides some guidance on what may have been imparted according to the context in which you operate. After three attempts with a negative result, the voice commands session ends.

Pressing the MTC Voice Command System  button, while the system is reproducing is called "intrusion". The reproduction system is stopped and after the beep you may impart a voice

command. This will be useful once you start to learn the options.

NOTE:

At any time, you can impart "Cancel" or "Help". These commands are general and can be used from any menu. All other commands can be used depending on the currently active application.

When using the voice command system you should speak clearly and with a normal voice volume. The system recognizes words better if the windows are closed and the fan of the air conditioning set to minimum.

At any time, if the system does not recognize a voice command it will ask you to repeat.

To replay the available voice commands list, press the MTC Voice Command System  button and impart "Help", to listen to the available commands displayed on the screen.

Natural Speech

The natural speech allows the operator to impart commands or complete sentences. The system eliminates the expressions without words and sounds like "ah" and "eh" and manages complete words as:

- "I would like to".

The system handles multiple commands in the same sentence as "Make a phone call" and "to Kelly Smith." For multiple commands in the same sentence, the system identifies the subject or context, and requires confirmation as "Who do you want to call?" if being asked to make a call but the system has not recognized the specific name.

The system uses a continuous dialogue, when requiring more information from the user it will ask a question that can be answered without pressing the voice MTC control system button.



Voice Commands

The MTC Voice Command System is able to comprise two types of commands. The universal commands are always available. The local controls are available if the supported radio mode is active.

To start a dialogue press the MTC Voice Command System VR button.

Volume Setting

1. Start a dialogue by pressing the MTC Voice Command System VR button.
2. Impart a command (ex. "Help").
3. While the Voice Command speaks, use the VOL control knob to adjust the volume to the optimum level. Note that the volume setting of the Voice Command system is independent from the sound system.

Vocal Recognition (VR) start session in Radio/Player mode

In these modes you can impart voice commands listed in the section Voice Tree.

NOTE:

It is possible to impart commands from any screenshot, when there is no ongoing a call and after pressing the MTC Voice Command System VR button.

Change source to Disc mode

To switch to the disc mode, say "Change source to Disc". It is possible to use this command in any mode or screenshot.

To change track, impart "Track".

Voice Tree

Radio/Player commands

General commands can be entered from any screenshot, as long as there is no ongoing phone call, after pushing the VR button on the steering wheel.

- Say "Go to AM Radio" to switch to AM radio band (see Note 1).
- Say "Change Source to iPod" to switch player source to iPod (see Note 2).
- Say "Tune to 950 AM" to select radio frequency 950 to AM (see Note 3).



NOTE:

1. It is possible to switch "AM" to "FM" or if available, to impart "SW" or "LW".
2. It is possible to replace "iPod" with any other "USB", "SD Card", "AUX" or "Bluetooth" player's source.
3. It is possible to switch "950 AM" to any other AM or FM frequency, such as "98.7".
4. Available voice commands are displayed in bold and shaded.

Available radio commands in AM/FM mode

These commands can be entered while the radio is in AM/FM mode after pressing the  VR on the steering wheel.

Commands only available in AM/FM mode

- Say "950 AM" to select the 950 frequency in AM (see Note 1).

NOTE:

1. It is possible to switch "950 AM" to any other AM or FM frequency, such as "98.7". It is as well possible to select "SW", "MW" e "LW" frequencies.
2. Available voice commands are displayed in bold and shaded.

Available commands in AM/FM mode

- Say "Go to Preset 5" to switch AM or FM frequency set in position 5.



4 – *Player Mode*

Overview	30
Disc Mode	30
USB/iPod Mode	32
SD Card Mode	34
AUX Mode	36
Bluetooth Mode	37
Voice Command	38



Overview

The Player mode is equipped with the following sources:

- Disc
- USB/iPod
- SD Card
- AUX
- Bluetooth

Player Mode is entered by touching the Player soft-key located on the bottom of the display or by inserting a Disc or a SD Card or by connecting an USB/iPod/AUX device or by pairing a Bluetooth device.

To change the mode, once in Player Mode, touch the Source soft-key fig. 15.



fig. 15

Disc Mode

Disc Mode is entered by either inserting a Disc or by touching the Player soft-key located on the bottom of the display. Once in Player Mode, touch the source soft-key and select Disc fig. 15.

A "No Disc" message will be displayed on the screen in the Disc mode when a Disc is not present in the MTC System.

Inserting Compact Disc

Gently insert one Disc into the Disc player with the Disc label facing up. The Disc will automatically be pulled into the player and the Disc icon will illuminate on the MTC System display. If a Disc does not go into the slot more than 1.0 in (2.5 cm), a disc may already be loaded and must be ejected before a new disc can be loaded.

If you insert a disc with the ignition ON and the MTC System ON, the unit will switch from to Disc mode and begin to play when you insert the disc. The display will show the track number, and index time in minutes and seconds. Play will begin at the start of track 1.



WARNING!

- **This Disc player will accept 4-3/4 in (12 cm) discs only. The use of other sized discs may damage the Disc player mechanism.**
- **Do not use adhesive labels. These labels can peel away and jam the player mechanism.**
- **The MTC System is able to operate a single Disc player. Do not attempt to insert a second Disc if one is already loaded.**

EJECT Button - Ejecting a Disc

Press the EJECT button to eject the Disc.

If you have ejected a disc and have not removed it within 10 seconds, it will be reloaded. If the Disc is not removed, the MTC System will reinsert the Disc but will not play it.

A disc can be ejected with the MTC System and ignition OFF.

Seek Up/Down

Touch and release the right arrow soft-key for the next selection on the Disc. Touch and release the left arrow soft-key to return to the beginning of the current selection, or return to the



beginning of the previous selection if the Disc is within the first second of the current selection.

Fast Seek Up

Touch and hold the right arrow soft-key and the Disc player will begin to fast forward through the current track until the soft-key is released.

Fast Seek Down

Touch and hold the left arrow soft-key and the Disc player will begin to rewind through the current track until the soft-key is released.

Browse

Touch the browse soft-key to display the browse window. The left side of the browse window displays a list of ways you can browse through the contents of the Disc. If supported by the device, you can browse by Folders, Artists, Playlists, Albums, Songs, etc. Touch the desired soft-key on the left side of the screen. The center of the browse window shows items and it's sub-functions, which can be scrolled by touching the Up and Down soft-keys to the right. The Scroll/Tune knob can also be used to scroll.

Source

Touch the Source soft-key to select the desired audio source, Disc, USB/iPod, SD Card, AUX or Bluetooth fig. 15. This screen will time out after a few seconds and return to the main radio screen if no selection is made.

Repeat

Touch the repeat soft-key to toggle the repeat functionality. The repeat soft-key is highlighted when active. The Player will continue to play the current track, repeatedly, as long as the repeat is active.

Shuffle

Touch the shuffle soft-key to play the selections on the compact disc in random order to provide an interesting change of pace. Touch the soft-key a second time to turn this feature off. The shuffle soft-key is highlighted when active.

Info

Touch the info soft-key to display the current track information. Touch the info soft-key a second time to cancel this feature.

Tracks

Touch the trks soft-key to display a pop up with the Song List. The currently playing song is indicated by an arrow and lines above and below the song title. Touching the trks soft-key while the pop up is displayed will close the pop up.

Audio

Refer to Audio in Radio Mode section for adjusting the audio settings.



USB/iPod Mode

USB/iPod Mode is entered by either inserting a USB device or iPod and cable into the USB Port or by touching the Player soft-key located on the bottom of the display. Once in Player Mode, touch the source soft-key and select USB fig. 15.

Inserting USB/iPod Device

Gently insert the USB/iPod device into the USB Port.

If you insert a USB/iPod device with the ignition ON and the MTC System ON, the unit will switch to USB/iPod mode and begin to play when you insert the device.

The display will show the track number, and index time in minutes and seconds. Play will begin at the start of track 1.

Seek Up/Down

Touch and release the right arrow soft-key for the next selection on the USB device/iPod. Touch and release the left arrow soft-key to return to the beginning of the current selection, or return to the beginning of the previous selection if the USB/iPod device is within the first second of the current selection.

Fast Seek Up

Touch and hold the right arrow soft-key and the USB/iPod device will begin to fast forward through the current track until the soft-key is released.

Fast Seek Down

Touch and hold the left arrow soft-key and the USB/iPod device will begin to rewind through the current track until the soft-key is released.

Browse

Touch the browse soft-key to display the browse window. The left side of the browse window displays a list of ways you can browse through the contents of the USB/iPod device. If supported by the device, you can browse by Folders, Artists, Playlists, Albums, Songs, etc. Touch the desired soft-key on the left side of the screen. The center of the browse window shows items and it's sub-functions, which can be scrolled by touching the Up and Down soft-keys to the right. The Scroll/Tune knob can also be used to scroll.

ABC Jump

Touch the ABC Jump soft-key tab at the top of the screen to search an alpha numeric keypad used to search by letter/number for a certain Folder, Artist, Song, Album, or Genre. Touch one letter to select all contents that start with that letter. Touch the 123 soft-key to display all contents that start with numbers. Touch the 123 soft-key again to return to letters. Touch the X soft-key to exit the ABC Jump feature.

NOTE:

Many features of this system are speed dependent. For your own safety these features may be grayed out and not accessible while the vehicle is in motion. Pull over at a safe location to complete your task.

Search

Touch the Search soft-key tab at the top of the screen to display the Keyboard fig. 16. This allows you to enter a folder or file name to be searched.



Up Arrow

Touch the Up Arrow soft-key to toggle between Upper Case and Lower Case keys.

ABC, ÅÖÜ and 1234!&#@

Touch the ABC key to activate a keyboard with Alphabetic characters, or touch the ÅÖÜ to activate a keyboard with accented characters or touch the 1234!&#@ key to activate a keyboard with Numeric plus Special characters.



fig. 16

Folders (for versions/markets, where provided)

Touch the Folders soft-key on the left side of the screen to display the Folders scroll menu. The Folders list consists of folders and files sorted alphanumerically, followed by a list of files sorted similarly. You can Browse

the contents of a subfolder by touching the Folder Name in the list. Touch the Back Arrow soft-key to return or back up to a previous folder level.

Artist

Touch the Artist soft-key on the left side of the screen to display the Artists list in which you can Scroll, Search, and Jump to operations.

Playlists (for versions/markets, where provided)

Touch the Playlists soft-key on the left side of the screen to display the current playlist information.

Songs

Touch the Songs soft-key on the left side of the screen to display the Songs list in which the user can Scroll, Search, and Jump to operations. The currently playing song is displayed with a black background, and lines both above and below the title.

Albums

Touch the Albums soft-key on the left side of the screen to display the Albums list in which you can Scroll, Search, and Jump to operations.

Genres

Touch the Genres soft-key to display the Albums list in which you can Scroll, Search, and Jump to operations.

Source

Touch the Source soft-key to select the desired audio source, Disc, USB/iPod, SD Card, AUX or Bluetooth fig. 15. This screen will time out after a few seconds and return to the main radio screen if no selection is made.

Repeat

Touch the repeat soft-key to toggle the repeat functionality. The repeat soft-key is highlighted when active. The Player will continue to play the current track, repeatedly, as long as the repeat is active.

Shuffle

Touch the shuffle soft-key to play the selections on the USB/iPod device in random order to provide an interesting change of pace. Touch the soft-key a second time to turn this feature off. The shuffle soft-key is highlighted when active.



Info

Touch the info soft-key to display the current track information. Touch the info soft-key a second time to cancel this feature.

Tracks

Touch the trks soft-key to display a pop up with the Song List. The currently playing song is indicated by an arrow and lines above and below the song title.

When in the Tracks List screen you can rotate the Tune/Scroll knob to highlight a track (indicated by the line above and below the track name) and then press the Enter/Browse button to start playing that track.

Touching the trks soft-key while the pop up is displayed will close the pop up.

Audio

Refer to Audio in Radio Mode section for adjusting the audio settings.

SD Card Mode

SD Card Mode is entered by inserting a SD Card containing music into the SD Card slot above the Disc slot on the Instrument Panel or by touching the Player soft-key located at the bottom of the display fig. 15. Once in Player Mode, touch the source soft-key and select SD Card.

Inserting SD Card

Gently insert the SD Card into the SD Card slot. If you insert a SD Card with the ignition ON and the MTC System ON, the unit will switch to SD Card mode and begin to play when you insert the card. The display will show the track number, and index time in minutes and seconds. Play will begin at the start of track 1.

Seek Up/Down

Touch and release the right arrow soft-key for the next selection on the SD Card.

Touch and release the left arrow soft-key to return to the beginning of the current selection, or return to the beginning of the previous selection if the SD Card is within the first second of the current selection.

Fast Seek Up

Touch and hold the right arrow soft-key and the SD Card will begin to fast forward through the current track until the soft-key is released.

Fast Seek Down

Touch and hold the left arrow soft-key and the SD Card will begin to rewind through the current track until the soft-key is released.

Browse

Touch the browse soft-key to display the browse window. The left side of the browse window displays a list of ways you can browse through the contents of the SD Card. If equipped, you can browse by Folders, Artists, Playlists, Albums, Songs, etc. Touch the desired soft-key on the left side of the screen. The center of the browse window shows items and it's sub-functions, which can be scrolled by touching the Up and Down soft-keys to the right. The Scroll/Tune knob can also be used to scroll.

ABC Jump

Touch the ABC Jump soft-key tab at the top of the screen to display a alpha numeric keypad used to search by



letter/number for a certain Folder, Artist, Song, Album, or Genre. Touch one letter to select all contents that start with that letter. Touch the 123 soft-key to search all contents that start with numbers. Touch the 123 soft-key to return to letters. Touch the X soft-key to exit the ABC Jump feature.

NOTE:

Many features of this system are speed dependent. For your own safety these features may be grayed out and not accessible while the vehicle is in motion. Pull over at a safe location to complete your task.

Search

Touch the Search soft-key tab at the top of the screen to display the Keyboard. This allows you to enter a folder or file name to be searched.

Up Arrow

Touch the Up Arrow soft-key to toggle between Upper Case and Lower Case keys.

ABC, ÅÖÜ and 1234!&#@

Touch the ABC key to activate a keyboard with Alphabetic characters, or touch the ÅÖÜ to activate a

keyboard with accented characters or touch the 1234!&#@ key to activate a keyboard with Numeric plus Special characters.

Folders (for versions/markets, where provided)

Touch the Folders soft-key on the left side of the screen to display the Folders scroll menu. The Folders list consists of folders, and files sorted alphanumerical, followed by a list of files sorted similarly.

You can Browse the contents of a sub-folder by touching the Folder Name in the list. Touch the Back Arrow soft-key to return or back up to a previous folder level.

Artist

Touch the Artist soft-key on the left side of the screen to display the Artists list in which you can Scroll, Search, and Jump to operations.

Playlists (for versions/markets, where provided)

Touch the Playlists soft-key on the left side of the screen to display the current playlist information.

Songs

Touch the Songs soft-key on the left side of the screen to display the Songs list in which the user can Scroll, Search, and Jump to operations. The currently playing song is displayed with a black background, and blue lines both above and below the title.

Albums

Touch the Albums soft-key on the left side of the screen to display the Albums list in which you can Scroll, Search, and Jump to operations.

Genres

Touch the Genres soft-key to display the Albums list in which you can Scroll, Search, and Jump to operations.

Source

Touch the source soft-key to select the desired audio source, Disc, USB/iPod, SD Card, AUX or Bluetooth.

This screen will time out after a few seconds and return to the main radio screen if no selection is made.

Repeat

Touch the repeat soft-key to toggle the repeat functionality. Touch the



soft-key a second time to turn this feature off.
The MTC System will continue to play the current track, repeatedly, as long as the repeat is active. The repeat soft-key is highlighted when active.

Shuffle

Touch the shuffle soft-key to play the selections on the SD Card in random order to provide an interesting change of pace. Touch the soft-key a second time to turn this feature off. The shuffle soft-key is highlighted when active.

Info

Touch the info soft-key to display the current track information.
Touch the info soft-key a second time to cancel this feature.

Tracks

Touch the trks soft-key to display a pop up with the Song List.
The currently playing song is indicated by an arrow and lines above and below the song title.
When in the Tracks List screen you can rotate the Tune/Scroll knob to highlight a track (indicated by the line above and below the track name) and

then press the Enter/Browse button to start playing that track.
Touching the trks soft-key while the pop up is displayed will close the pop up.

Audio

Refer to Audio in Radio Mode section for adjusting the audio settings.

AUX Mode

AUX Mode is entered by inserting an AUX device using a cable with a 3.5 mm audio jack into the AUX port or by touching the Player soft-key located at the bottom of the display. Once in Player Mode, touch the source soft-key and select AUX fig. 15.

Inserting Auxiliary Device

Gently insert the Auxiliary device cable into the AUX Port. If you insert an Auxiliary device with the ignition ON and the MTC System ON, the unit will switch to AUX mode and begin to play when you insert the device cable.

Controlling the Auxiliary Device

The control of the auxiliary device (e.g., selecting playlists, play, fast forward, etc.) cannot be provided by the MTC System; use the device controls instead.
Adjust the volume with the MTC Volume tuner, or with the volume of the attached device.



NOTE:

The MTC System is acting as the amplifier for audio output from the Auxiliary device. Therefore if the volume control on the Auxiliary device is set too low, there will be insufficient audio signal for the MTC System to play the music on the device.

Source

Touch the source soft-key to select the desired audio source, Disc, USB/iPod, SD Card, AUX or Bluetooth fig. 15. This screen will time out after a few seconds and return to the main radio screen if no selection is made.

Audio

Refer to Audio in Radio Mode section for adjusting the audio settings.

Bluetooth Mode

Bluetooth Streaming Audio (BTSA) or Bluetooth Mode is entered by pairing a Bluetooth device, containing music, to the MTC System. Once the Bluetooth device is paired to the MTC System, touch the Player soft-key located on the bottom of the display. Once in Player Mode, touch the source soft-key and select Bluetooth fig. 15. Before proceeding, the Bluetooth device needs to be paired through system Phone in order to communicate with the MTC System fig. 17.



fig. 17

NOTE:

See the pairing procedure in this add and in the Phone Owner's Manual for further details.

Bluetooth

Touch and release the Bluetooth soft-key to select the Bluetooth device fig. 18.

Touch the X soft-key to exit the Bluetooth device feature.



fig. 18

Seek Up/Down

Touch and release the right arrow soft-key for the next selection on the Bluetooth device. Touch and release the left arrow soft-key to return to the beginning of the current selection, or return to the beginning of the previous selection if the Bluetooth device is within the first second of the current selection.

Fast Seek Up

Touch and hold the right arrow soft-key and the Bluetooth device will



begin to fast forward through the current track until the soft-key is released.

Fast Seek Down

Touch and hold the left arrow soft-key and the Bluetooth device will begin to rewind through the current track until the soft-key is released.

Source

Touch the source soft-key to select the desired audio source, Disc, USB/iPod, SD Card, AUX or Bluetooth. This screen will time out after a few seconds and return to the main radio screen if no selection is made.

Repeat

Touch the repeat soft-key to toggle the repeat functionality. Touch the soft-key a second time to turn this feature off.

The MTC System will continue to play the current track, repeatedly, as long as the repeat is active.

The repeat soft-key is highlighted when active.

Shuffle

Touch the shuffle soft-key to play the selections on the Bluetooth device in random order to provide an

interesting change of pace. Touch the soft-key a second time to turn this feature off.

The shuffle soft-key is highlighted when active.

Info

Touch the info soft-key to display the current track information.

Touch the info soft-key a second time to cancel this feature.

Tracks

Touch the trks soft-key to display a pop up with the Song List.

The currently playing song is indicated by a blue arrow and lines above and below the song title.

Touching the trks soft-key while the pop up is displayed will close the pop up.

Audio

Refer to Audio in Radio Mode section for adjusting the audio settings.

Voice Command

Refer to Voice Command in the Radio Mode section.

Voice Command Tree

Refer to Voice Tree in the Radio Mode section.

General commands

The general commands can be entered from any screenshot, as long as there is no ongoing phone call, after pressing the  button on the steering wheel (see Note 1, 2).

- Say "Help" to listen all available voice commands.
- Say "Cancel" to cancel the listening of available voice commands.
- Say "Go to Player" to display the home screen of the player.

NOTE:

1. *It is possible to replace "Player" with "Radio", "Navigation", "Phone", "Climate" or "Settings".*
2. *The available voice commands are in bold and shaded.*



Music control in Player mode

These commands can be entered while the system plays music from your USB device/iPod, SD card or CD after pressing the  VR button on the steering wheel.

- Say "Play the album Ragtime Favourites" to start your radio playing the album "Ragtime Favourites" (see Note 1, 4).
- Say "Play the artist Scott Joplin" to start your radio playing the artist "Scott Joplin" (see Note 1, 4).
- Say "Play the song Maple Leaf Rag" to start your radio playing the track "Maple Leaf Rag" (see Note 1).
- Say "Play the genre Rock" to start your radio playing "Rock" genre (See Note 1, 4).
- Say "Play the playlist Party Tunes" to start your radio playing the playlist "Party Tunes" (See Note 1, 3).
- Say "Play the podcast Weekly Auto Podcast" to start your radio playing the podcast "Auto Podcast" (See Note 1, 3).
- Say "Play the audio book Dr. Jekyll and Mr. Hyde" to start your radio playing the audiobook "Dr. Jekyll and Mr. Hyde" (See Note 1, 3).

- Say "Play track 8" to start your radio playing track "8" (See Note 2).

NOTE:

1. *It is possible to replace names albums, song title, artist, genre, play list, podcast and audio book with any other name available on the current active device.*
2. *It is possible to replace "8" with any other track on the CD. The command is available only while the CD is playing.*
3. *The playlist commands of podcast and audio book are available only if connected to an iPod during playback.*
4. *Voice commands, names of albums, artists and genres of music are based on the Gracenote music database.*
5. *The available voice commands are displayed in bold and shaded.*





5 – Controls Mode

Overview	42
Heated Seat (Driver & Passenger)	42
Vented Seat (Driver & Passenger)	42
Heated Wheel.	43
Rear Sunshade	43
Screen OFF	43



Overview

Press the Controls soft-key to access the settings list fig. 19. Controls such as Heated Seat (Driver & Passenger), Vented Seat (Driver & Passenger), Heated Wheel, Rear Sunshade and Screen OFF can be selected, adjusted or turned ON/OFF by touching the corresponding soft-key.



fig. 19

Heated Seat (Driver & Passenger)

Refer to SEATS section in your vehicle Owner's Manual for details.

Vented Seat (Driver & Passenger)

Refer to SEATS section in your vehicle Owner's Manual for details.



Heated Wheel

Refer to STEERING WHEEL section in your vehicle Owner's Manual for details.

Rear Sunshade

Touch the Rear Sunshade soft-key to raise the rear sunshade. Touch the soft-key a second time to lower the rear sunshade.

Refer to REAR SUNSHADE section in your vehicle Owner's Manual for details.

Screen OFF

Press the Screen OFF soft-key to turn the touch-screen OFF. To turn the screen back ON, just touch the screen.





6 – *Climate mode*

Overview	46
On-Screen Controls	46



Overview

Press the Climate soft-key located on the bottom centre of the display to access the climate on-screen controls fig. 20.

To turn the Climate system ON press the ON soft-key.

The Climate icon indicates the current mode of the system: OFF (disabled), A (automatic) air distribution symbol (air distribution manual setting).

Press the soft-key located on the centre of the display to access the settings list such as: Heated Seat (Driver & Passenger), Vented Seat (Driver & Passenger) and Heated Wheel. Refer to Climate Controls in your vehicle's Owner's Manual for further details.



fig. 20

On-Screen Controls

Front Climate (fig. 21)

- A. AUTO function activation (automatic operation).
- B. Driver side set temperature.
- C. Passenger side set temperature.
- D. Air distribution.
- E. Settings list: Heated Seat (Driver & Passenger), Vented Seat (Driver & Passenger) and Heated Wheel.
- F. OFF for canceling air flow exiting the vents.
- G. Fan speed adjustment.



fig. 21

- H. SYNC function activation (driver/passenger temperature alignment).
- I. MAX A/C for activating/deactivating max air conditioner.
- J. A/C for activating/deactivating air conditioner.
- K. For activating/deactivating internal air recirculation.
- L. Quick demisting/defrosting of windscreen, front glasses, heated mirrors and heated rear window.
- M. Activating/deactivating heated rear window and heated mirrors.
- N. Rear climate control screen.

- E. REAR OFF for canceling rear air flow exiting the vents.
- F. Fan speed adjustment.
- G. SYNC function activation (left/right passenger temperature alignment).
- H. A/C for activating/deactivating air conditioner.

- I. REAR LOCK for deactivating rear climate control.
- J. Front climate control screen.

Rear Climate (fig. 22)

- A. REAR AUTO function activation (automatic operation).
- B. Passenger left side set temperature.
- C. Passenger right side set temperature.
- D. Air distribution.



fig. 22





7 – *Navigation Mode*

Overview	50
Getting started	50
Where To? (finding locations)	52
Viewing the map pages	56
Using the Tools	58
Settings (customizing the Navigation System)	59
Voice Commands	61
Voice Command Tree	62
Appendix	63
Important Information	64



WARNING!

Read **NAVIGATION SYSTEM- SAFETY PRECAUTIONS AND IMPORTANT INFORMATION** in the **SAFETY GUIDELINES** section carefully before starting to operate the Navigation System and follow the instructions in this manual.

Overview

This Navigation System can be used when the ignition key is turned to **RUN** or **ACC**. To preserve the battery, however, it should be used with the engine running whenever possible. Using the Navigation System for a long time with the engine switched off can cause the battery to run down.

Map Data Information

Garmin uses a combination of governmental and private data sources. Virtually all data sources contain some inaccurate or incomplete data. In some countries, complete and accurate map information is either not available or is prohibitively expensive.

Getting started

To access the Navigation System, touch the Nav soft-key on bottom of the screen fig. 23.



fig. 23

Setting the System

When using your Navigation System for the first time, complete the following tasks.

1. Acquire satellites.
2. Understand the main menu.

Acquiring Satellites

Go to an open area, away from tall buildings and trees. Acquiring satellite signals can take a few minutes.



Main Menu (fig. 24)

- A. The bars indicate satellite strength.
- B. Touch to find a destination.
- C. Touch to view the map.
- D. Touch to stop a route.
- E. Touch to detour a route.
- F. Touch to open the menu of tools.
- G. Touch to open the menu of settings.



fig. 24

Using the on-screen Soft-keys

- Touch and hold to quickly return to the main menu.
- Touch and to see more choices.

- Touch and hold and to scroll faster.

Using the on-screen Keyboard

- Touch a character on the keyboard to enter a letter or number.
- Touch to select the keyboard language mode.
- Touch to activate a keyboard with Alphabetic characters.
- Touch to activate a keyboard with Numeric plus Special characters.
- Touch to toggle between Upper Case and Lower Case keys.
- Touch to add a space.
- Touch to delete a character.
- Touch and hold to erase the entire entry.
- Touch to return or back up to a previous folder level.

Finding a Point of Interest

The detailed maps loaded in your Navigation System contain points of interest, such as restaurants, hotels, and auto services.

1. From the main menu, touch Where To? B fig. 24.
2. Touch Points of Interest.
3. Select a category.
4. If necessary, select a subcategory.
5. Select a destination.
6. Touch Go!

Finding a Location by Spelling the Name

1. From the main menu, touch Where To?
2. Touch Points of Interest.
3. Touch Spell Name.
4. Enter all or part of the name.
5. Touch Done.
6. Select a destination.
7. Touch Go!



Adding Points to the Active Route

1. While navigating a route, touch  to return to the main menu.
2. From the main menu, touch Where To?
3. Select a category.
4. If necessary, select a subcategory.
5. Select a destination.
6. Touch Go!
7. Touch Add as a Via Point.

Changing Destination of the Active Route

Before you can change destinations, you must be navigating a route.

1. Touch  to return to the main menu.
2. Touch Where To?
3. Search for the location.
4. Touch Go!
5. Touch Set as a New Destination.

Taking a Detour

While navigating a route, you can use detours to avoid obstacles ahead of you, such as construction zones. If the route you are currently taking is the only reasonable option, the Navigation System might not calculate a detour.

1. While navigating a route, touch .
2. From the main menu, touch Detour E fig. 24.

Stopping the Route

1. While navigating a route, touch .
2. From the main menu, touch Stop D fig. 24.

Where To? (finding locations)

The Where To? menu B fig. 24 provides several different categories you can use to search for locations. To perform a simple search, see the Getting Started section.

Touch Where To? to find a destination.

- A. Touch to access the list fig. 25.
- B. Touch to see previous choices. Touch and hold to scroll faster.
- C. Touch to see more choices. Touch and hold to scroll faster.
- D. Touch and hold to quickly return to the main menu.



fig. 25



Finding an Address

Depending on the version of the built in map data on your Navigation System, the button names and the order of steps could be different than the steps below.

1. From the main menu, touch Where To?
2. Touch Address.
3. If necessary, change the state, the country, or the province.
4. Touch Spell City.
5. Enter the city/postal code. If you are unsure of the city/postal code, touch Search All.
6. Touch Done.
7. If necessary, select the city/postal code. Not all map data provides postal code searching.
8. Enter the number of the address.
9. Touch Done.
10. Enter the street name.
11. Touch Done.
12. If necessary, select the street.

13. If necessary, select the address.

14. Touch Done.

Using the Go! page

The Go! page opens when you select a location to navigate to.

- Touch  to call the selected location when your device is connected to phone, or to save the location to your favorites.
- Touch  to switch between 2-D and 3-D view.
- Touch  to rotate the view.
- Touch the name of the location to view more information.
- Touch  or  to zoom in and out.
- Touch  to return to the previous page.
- Touch and hold  to return to the main menu.
- Touch Go! to create a turn-by-turn route to this location.

Going Home (setting a home location)

Before you can navigate to home, you must set a home location.

You can set your home location for the location you return to most often.

1. From the main menu, touch Where To?
2. Touch Go Home.
3. Select Enter My Address, Use My Current Location, or Recently Found.

Resetting Home Location

1. From the main menu, touch Where To? then .
2. Select Set Home Location.
3. Select an option to change your address.

Editing Home Location

1. From the main menu, touch Where To? then Favorites.
2. Touch Home.
3. Touch  then Edit.
4. Enter your changes.
5. Touch Done.



Viewing a List of Recently Found Locations

Your navigation system stores the last 50 locations you have found.

1. From the main menu, touch Where To?
2. Touch Recently Found.

Clearing List of Recently Found Locations

1. From the main menu, touch Where To?
2. Touch Recently Found.
3. Touch  then Clear.
4. Enter Yes.

About Favorites

You can save locations in your Favorites so you can quickly find them and create routes to them. Your home location is also stored in Favorites.

Saving Current Location to Favorites

1. From the map, touch the vehicle icon.
2. Touch Save.
3. Enter a name.
4. Touch Done.

The location is saved in Favorites.

Saving Locations to Favorites

1. Search for the location.
2. From the Go! page, touch  then Save.
3. Enter OK.

Finding Favorites

1. From the main menu, touch Where To?
2. Touch Favorites. If necessary, select a category.
3. Select a saved location.

Editing Favorites

1. From the main menu, touch Where To?
2. Touch Favorites.
3. Select a category.
4. Select a favorite.
5. Touch the information box.
6. Touch  then Edit.
7. Select an option:
 - Name
 - Phone Number
 - Categories
 - Change Map Symbol
8. Edit the information.
9. Touch Done.

Planning a Trip

You can use Trip Planner to create and save a trip with multiple destinations.

1. From the main menu, touch Where To?
2. Touch Trip Planner.
3. Touch .
4. Touch Select Start Location.



5. Search for a location.
6. Touch Select.
7. Touch  to add an additional location.
8. Touch Select.
9. Repeat steps 5–7 to add additional locations to your trip.
10. Touch Next.
11. Enter a name.
12. Touch Done.

Navigating to a Saved Trip

1. From the main menu, touch Where To?
2. Touch Trip Planner.
3. Select a saved trip.
4. Touch Go!

Editing a Saved Trip

1. From the main menu, touch Where To?
2. Touch Trip Planner.
3. Select a saved trip.
4. Touch .

5. Select an option:
 - Touch Rename Trip to edit the trip name.
 - Touch Edit Destinations to add or delete locations.
 - Touch Delete Trip to delete the entire trip.
 - Touch Optimize Order to arrange your trip locations in the most efficient order.

Browsing the Map

1. From the main menu, touch Where To?
2. Touch Browse Map.
3. Touch anywhere on the map.
 - Touch  or  to zoom in and out.
 - Touch  to switch between 2D and 3D views.
 - Touch  to rotate the view.

Browsing the Map by touching the Screen

- Touch an area on the map to select a location.
- An information box appears next to the location.

- Touch and drag the map to view different parts of the map.
- Tap the map twice to zoom in and center on a location.

Finding a Location by using the Map

1. From the main menu, touch Where To?
2. Touch Browse Map.
3. Touch a location. An information box appears next to the location.
4. Touch the information box.
5. To select an option touch  then Save.
6. Touch Go!

Setting a Simulated Location

You can use the GPS simulator to select another location, near which you can search for and save points of interest. This may be helpful when planning trips.

1. From the main menu, touch Settings then System, GPS Simulator, On and Save.
2. From the main menu, touch Where To? then Browse Map.
3. Touch an area on the map.



4. Touch  then Set Location.

Entering Coordinates

If you know the geographic coordinates of your destination, you can use your navigation system to navigate to the destination using the latitude and longitude coordinates.

1. From the main menu, touch Where To?
2. Touch Coordinates.
3. Touch a field to enter the latitude and longitude data.
4. Touch View on Map.
5. Touch Go!

Changing the Map Coordinate Format

1. From the main menu, touch Where To?
2. Touch Coordinates then  and Format.
3. Select a format.
4. Enter OK.

Viewing the map pages

Notice

In no event shall Maserati or Garmin be liable for any incidental, special, indirect, or consequential damages, including, without limitation, damages for any traffic fines or citations, whether resulting from the use, misuse, or inability to use the product or from defects in the product. Some states do not allow the exclusion of incidental or consequential damages, so the above limitations may not apply to you.

Your route is marked with a magenta line. A checkered flag marks your destination.

As you travel, your navigation system guides you to your destination with voice prompts, arrows on the map, and directions at the top of the map. If you depart from the original route, your navigation system recalculates the route and provides new directions. A speed limit icon displaying the current speed limit may appear as you travel on major roadways.

Using the Navigation Map

Touch View Map C fig. 24 to open the map menu fig. 26.



fig. 26

- The vehicle icon shows your current location.
- Touch an area of the map to see additional information.
- Touch  to view the next turn. The turn indicator also tells you which lane you should be in to prepare for your next maneuver, when available.
- Touch the text bar on the top of the map page A fig. 26 to view the turn list.
- Touch  to zoom in.
- Touch  to zoom out.
- Touch  to return to the main menu.
- Touch B to display a different data field.
- Touch C to view information for the location.
- Touch D to view trip information.



About myTrends™

When myTrends™ feature is enabled, your estimated time of arrival and traffic information for your frequent destinations, like your workplace, automatically appear in the navigation bar at the top of the map. When myTrends™ information appears in the navigation bar, you can touch the navigation bar to view route options for the suggested destination.

Enabling myTrends™

- From the main menu touch Settings.
- Touch Navigation and select myTrends™.
- Enter Enabled.

Driving

From the map, touch the B fig. 26 Driving field. This function allows to select travel data to display:

- Travel direction.
- Altitude.
- Day time.

Viewing Trip Information

The trip information page fig. 27 displays your present speed and provides statistics about your trip. If

you make frequent stops, leave the navigation system turned on so it can accurately measure elapsed time during the trip. From the map, touch the D fig. 26 Speed field. If you want accurate trip information, reset the trip information before beginning a trip.



fig. 27

Resetting Trip Information

1. From the map, touch the Speed field.
2. Touch
3. Select an option:
 - Touch Reset Trip Mileage to reset the information on the trip computer.
 - Touch Reset Max. Speed to reset the maximum speed.

Viewing the Turn List

When you are navigating a route, you can view all of the turns for your entire route and the distance between turns.

1. From the map, touch the text bar on the top of the map.
2. Select an option:
 - Select a turn on the list to view the next turn.
 - Touch then Map to view the entire route on the map.

Viewing the Next Turn

Before you can view the next turn, you must be navigating a route. The next turn shows the turn on the map and the distance and time left before you reach the turn. Touch the turn indicator in the top left corner of the map.

Viewing the Junction View

Before you can view the junction view, you must be navigating a route. The junction view displays a view of some upcoming junctions and in which lane you should be driving.



Using the Tools

From the main menu, touch Tools F fig. 24 to access the list fig. 28.



fig. 28

Where Am I? (current location information)

Use the Where Am I? page to view information about your current location fig. 28. This feature is helpful if you need to tell emergency personnel your location.

Finding Nearby Services

1. From the main menu, touch Tools then Where Am I?
2. Touch Hospitals, Police Stations, or Fuel to view the nearest locations in that category.

Using Help

From the main menu, touch Tools then Help to view information about using your navigation system.

Searching Help Topics

From the main menu, touch Tools then Help.

My Data

Use My Data page to set or delete personal travel data. From the main menu, touch Tools then My Data.

- Set Home position.
- Delete My Positions.
- Delete travel record.
- Delete Personal points of Interest.

Trip Planner

You can use Trip Planner to create and save a trip with multiple destinations. From the main menu, touch Tools then Trip Planner. See Planning a Trip in the Where To? section.

Using the World Clock

1. From the main menu, touch Tools then World Clock.
2. Select a city name fig. 29.
3. Enter a new city name.

4. Touch Done.
5. If necessary, select a city.

Viewing the World Map

1. From the main menu, touch Tools then World Clock.
2. Touch .
3. Nighttime hours appear in the shaded area.



fig. 29

Using the Calculator

From the main menu, touch Tools then Calculator.



Using the Unit Converter

1. From the main menu, touch Tools then Unit Converter.
2. Touch the box with a unit of measure listed.
3. Select a unit of measure.
4. Touch Save. Two units of measure are listed.
5. Touch a unit of measure to change.
6. Select a unit of measure.
7. Touch Done.
8. Repeat steps 5–6, if necessary.
9. Enter a value.
10. Touch Done.

Settings (customizing the Navigation System)

1. From the main menu, touch Settings G fig. 24 to access the list fig. 30.
2. Touch a setting category.
3. Touch the setting to change it.



fig. 30

Restoring all Original Settings

1. From the main menu, touch Settings.
2. Touch  then Restore.
3. Enter Yes.

System Settings

From the main menu, touch Settings then System.

- GPS Simulator - stops the navigation system from receiving a GPS signal, and saves battery power.
- About - displays the software version number, the unit ID number, and information on several other software features.

You need this information when you update the system software or purchase additional map data.

Restoring the System Settings

1. From the main menu, touch Settings then System.
2. Touch  then Restore.

Changing the Map Settings

From the main menu, touch Settings then Map.

- Map Detail - sets the level of detail on the map. More detail may result in slower map drawing.
- Map View - sets the perspective on the Map page.
- Map Theme - changes the color of the map data.



- Vehicle - changes the icon to represent your position on the map.
- Trip Log
 - Show on Map - displays the path of your travels on the map.
 - Clear Trip Log.
- Map Data Layout - changes the amount of data visible on the map.

Changing the Map Perspective

1. From the main menu, touch Settings then Map.
2. Select Map View. Select an option:
 - Touch Track Up to display the map in two dimensions (2-D), with your direction of travel at the top.
 - Touch North Up to display the map in 2-D with North at the top.
 - Touch 3-D to display the map in three dimensions.

Route Preferences

1. From the main menu, touch Settings then Navigation.
2. Select Route Preference.

The route calculation is based on road speeds and vehicle acceleration data for a given route.

 - Faster Time - calculates routes that are faster to drive but can be longer in distance.
 - Shorter Distance - calculates routes that are shorter in distance but can take more time to drive.
 - Prompted - select the faster time and shorter distance for your route.

Avoiding Road Features

1. From the main menu, touch Settings then Navigation.
2. Select Route Avoidances.
3. Select the road features to avoid on your routes.
4. Touch Save.

About trafficTrends™

When the trafficTrends™ feature is enabled, your navigation system uses historic traffic information to calculate more efficient routes. Different routes may be calculated based on traffic trends for the day of the week or based on the time of day.

Enabling trafficTrends™

1. From the main menu, touch Settings then Navigation.
2. Select trafficTrends™.
3. Enter Enabled.

Restoring the Original Navigation Settings

1. From the main menu, touch Settings then Navigation.
2. Select Restore.

About Traffic Subscriptions

You can purchase additional subscriptions or a renewal if your subscription expires. Go to www.garmin.com/fmtraffic.



Viewing traffic Subscriptions

1. From the main menu, touch Settings then Traffic.
2. Select Subscriptions.

Restoring the Original Traffic Settings

1. From the main menu, touch Settings then Traffic.
2. Touch  then Restore.

Language Settings

From the main menu, touch Settings then Language.

- Keyboard - sets the language for your keyboard.
- Keyboard Layout - sets the keyboard layout.

Restoring the Original Language Settings

1. From the main menu, touch Settings then Language.
2. Touch  then Restore.

Voice Commands

About Voice Commands

The voice command feature is not available for all languages or regions. The voice commands allow you to use your navigation system by speaking the words you see on the screen or by speaking certain commands.

Activating Voice Commands

- Press the  VR button on the steering wheel.
- The navigation system enters voice command.

About Icons and Tones

- The navigation system sounds two tones when it enters and exits voice recognition mode.
- The  red icon appears in the upper-right corner of the screen when the navigation system is not ready for your command.
- Wait until the  icon is green to speak your command.

Tips for using Voice Commands

- Speak in a normal voice directed at the navigation system.
- Speak commands as they appear on the screen.

- Respond to voice prompts from the navigation system as needed.
- Speak "Exit" to exit voice command.

Navigating to a Popular Location using Voice Commands

You can speak the names of very popular, well-known locations.

1. Press the voice command button on the steering wheel.
2. Speak "Find by Name".
3. Listen for the voice prompt and speak the name of the location. A list of locations appears.
4. Speak the line number.
5. Speak an option:
 - Speak "Go!" to navigate to the location.
 - Speak "Call" to call the location when connected to a compatible mobile phone.

Imparting an Address

1. Say "Voice Command".
2. Say "Find Address".
3. Follow the on-screen prompts.



Navigation Voice Commands List

Following, a list of main voice commands:

"Where To?" (Main Menu command)
 "View Map" (Main Menu command)
 "Repeat guidance"
 "Cancel Route"
 "Detour" (During a Route Guidance)
 "Where Am I?"
 "Find Address"
 "Go Home"
 "Find Place by Category"
 "Find Place by Name"
 "Find Recently Found"
 "Find Favorite"
 "Find City"
 "Find Nearest Restaurant"
 "Find Nearest Fuel"
 "Find Nearest Transit"
 "Find Nearest Lodging"
 "Find Nearest Shopping"
 "Find Nearest Bank"
 "Find Nearest Parking"
 "Find Nearest Entertainment"
 "Find Nearest Recreation"
 "Find Nearest Attractions"
 "Find Nearest Hospitals"
 "Find Nearest Community"
 "Find Nearest Auto Services"
 "Find Nearest Airport"
 "Find Nearest Police Stations"

"Find Nearest Fire Stations"
 "Find Nearest Auto Dealers"

Voice Command Tree

General commands

General commands can be issued from any screenshot, as long as there is no call in progress, after pushing the  VR button on the steering wheel (see Note 1, 2).

- Say "Help" to listen all available voice commands.
- Say "Cancel" to cancel the listening of voice available commands.
- Say "Repeat Guidance" to repeat driving tip of the navigation system.
- Say "Go to Player" to display the initial screen of the player.

NOTE:

1. *It is possible to replace "Player" with "Radio", "Navigation", "Phone", "Climate" or "Settings".*
2. *Available voice commands are displayed in bold and shaded.*

General navigation commands

General navigation commands can be issued from any screenshot, as long as there is no call in progress after



pushing the VR button on the steering wheel (see Note 1, 2).

- Say "View Map" to view the map.
- Say "Where am I?" to view the map indicating the current position.
- Say "Detour" to allow the navigation system to select an alternative route that will be excluded the upcoming time.
- Say "Cancel Route" to cancel the current route. The system requires confirmation of cancellation of the route: say "Yes" to cancel the current route or say "No" to maintain.
- Say "Repeat Guidance" to repeat the guide suggestion of the navigation system.
- Say "Find Address" to display the guided dialog box to enter an address.
- Say "Find Nearest Restaurant" to display the dialog box of searching restaurants in the proximity of the current location.

NOTE:

1. *It is also possible to impart "Find City", "Find Favorite", "Find Place by Category", "Find Place by Name", "Find Recently Found", "Where to?" or "Go Home".*
2. *You may also impart "Find Nearest" according to "Restaurant", "Fuel", "Transit", "Lodging", "Shopping", "Bank", "Entertainment", "Recreation", "Attractions", "Community", "Auto Services", "Hospitals", "Parking", "Airport", "Police Stations", "Fire Stations" or "Auto Dealers".*

Appendix

About GPS Satellite Signals

The navigation system must acquire satellite signals in order to navigate. When the navigation system has acquired satellite signals, the signal strength bars on the main menu are full . When it loses satellite signals, the bars are clear .

For more information about GPS, go to www.garmin.com/aboutGPS.

Updating the Software and the Map Data

To update the navigation system software and the map data, refer to the website www.maserati.com

Current Map Data

To view your current version of Map Data:

- Touch the Settings soft-key.
- Touch the Map soft-key, then touch Info.



Important Information

Garmin and Maserati are not responsible for the accuracy of, or the consequences of using, a safety camera database.

Safety camera information is available in some locations. Go to <http://my.garmin.com> for availability. For these locations, the navigation system includes the locations of hundreds of safety cameras. Your navigation system alerts you when you are approaching a safety camera and can warn you if you are driving too fast. The data is updated at least weekly, so you always have access to the most up-to-date information.

You can purchase a new region or extend an existing subscription at any time. Each region that you purchase has an expiration date.

Custom POI (Points of Interest)

Custom POI files must be named "poi.gpi". and located on the USB storage device in a folder named 'POI' within a folder named "Garmin" (Garmin/POI/).

You can manually load custom points of interest (POI) databases, available from various companies on the Internet. Some custom POI databases

contain alert information for points such as safety cameras and school zones. The navigation system can notify you when you approach one of these points. You are responsible for ensuring that your use of safety camera information is lawful in your area.



WARNING!
Garmin and Maserati are not responsible for the consequences of using custom POI databases, or for the accuracy of custom POI databases.

After downloading your POI database, use the Garmin POI Loader to install the POI onto a USB mass storage device. Use the USB mass storage device to load the POI. The POI Loader is available at www.garmin.com/products/poiloader. Refer to the POI Loader Help file for more information; click Help to open the Help file. The file name can only be POI.gpi. No other file name or extension should be used.

Each time you load custom POI to the navigation system, any other custom POI already saved in the system will be overwritten.

Find Custom POI

You can view a list of the custom POI loaded in your navigation system.

1. Touch Where To? then Extras.
2. Select Custom POI.

Delete Custom POI

1. Touch Tools then My Data.
2. Delete Custom POI.
3. Touch Yes to confirm.

All custom POI will be deleted from your navigation system.

Saving Trip Logs

Trip logs are recorded while you navigate a route.

SiriusXM™ Travel Link (where available)

Now, in addition to delivering over 130 channels of the best sports, entertainment, talk and 100% commercial-free music, SiriusXM™ now offers premium infotainment services that work in conjunction with compatible navigation systems. To access SiriusXM™ Travel Link, press the MENU hard-key then touch the



Travel Link soft-key. SiriusXM™ Travel Link brings a wealth of useful information into your vehicle and right to your fingertips:

Fuel Prices

- Check detailed price information for fuel stations near your current location.
- Sort the list of closest fuel stations by price, distance or alphabetically.
- Route to selected fuel station.
- Store a favorite fuel station for quick access to pricing.

Movie Listings

- Check which movies are playing at theaters near your current location.
- Sort the list of theaters by distance or alphabetically.
- Show movie titles, start times, ratings, run length, and summaries.
- Store a favorite theater for quick access to schedules.

Ski Info

- View ski and snowboarding conditions at ski resorts.
- Store a favorite location for quick access to snow conditions.

Sports Scores

- View scores and upcoming events for all major sports.
- Store your favorite teams for quick access to the scores and schedules.

SIRIUS Travel Link data services subscription is separate from your SIRIUS Satellite Radio (audio) subscription.

NOTE:

Neither SIRIUS nor Maserati is responsible for any errors in accuracies in the SIRIUS data services or its use in vehicles.

SiriusXM™ and all related marks and logos are trademarks of SiriusXM™ Radio Inc. and its subsidiaries. SiriusXM™ Radio requires a subscription, sold separately after trial subscription included with vehicle purchase. Prices and programming are provided by SiriusXM™ and are subject to change. Subscriptions governed by Terms & Conditions available at sirius.com/serviceterms. SiriusXM™ Radio U.S. service only available to those at least 18 years of age in the 48 contiguous United States, D.C., & PR. Visit www.sirius.com/TravelLink for more information on SIRIUS Travel Link.

Weather

- View detailed current conditions at your current location.
- Check extended 12-hour and 5-day forecasts.
- Store a favorite location for quick access to weather conditions and forecasts.

End-User License Agreements

Software License Agreement

BY USING THE NAVIGATION SYSTEM, YOU AGREE TO BE BOUND BY THE TERMS AND CONDITIONS OF THE FOLLOWING SOFTWARE LICENSE AGREEMENT. PLEASE READ THIS AGREEMENT CAREFULLY.

Garmin Ltd. and its subsidiaries ("Garmin") grant you a limited license to use the software embedded in this device (the "Software") in binary executable form in the normal operation of the product. Title, ownership rights, and intellectual property rights in and to the Software remain in Garmin and/or its third-party providers.

You acknowledge that the Software is the property of Garmin and/or its third-party providers and is protected under the United States of America



copyright laws and international copyright treaties. You further acknowledge that the structure, organization, and code of the Software, for which source code is not provided, are valuable trade secrets of Garmin and/or its third-party providers and that the Software in source code form remains a valuable trade secret of Garmin and/or its third-party providers. You agree not to decompile, disassemble, modify, reverse assemble, reverse engineer, or reduce to human readable form the Software or any part thereof or create any derivative works based on the Software. You agree not to export or re-export the Software to any country in violation of the export control laws of the United States of America or the export control laws of any other applicable country.

NAVTEQ® End-User License Agreement

The software embedded in your Garmin product (the "Software") is owned by Garmin Ltd. or its subsidiaries ("Garmin"). The third-party map data embedded in or accompanying your Garmin product (the "Map Data") is owned by NAVTEQ North America LLC and/or its affiliates

("NAVTEQ") and is licensed to Garmin. Garmin also licenses information, text, images, graphics, photographs, audio, video and other applications and data from third-party data providers ("Third-Party Content Data"). The Map Data and Third-Party Content Data are collectively the "Data".

Both the Software and Data are protected under copyright laws and international copyright treaties. The Software and Data are licensed, not sold. The Software and Data are provided under the following licence and are subject to the following terms and conditions which are agreed to by the End User ("you" or "your"), on the one hand, and Garmin and its licensors (including their licensors and suppliers) and affiliated companies on the other hand.

IMPORTANT: READ THIS LICENCE CAREFULLY BEFORE USING THIS PRODUCT. INSTALLING, COPYING OR OTHERWISE USING THIS PRODUCT INDICATES YOUR ACKNOWLEDGEMENT THAT YOU HAVE READ THIS LICENCE AND AGREE TO ITS TERMS. IF YOU DO NOT AGREE, RETURN THE COMPLETE PRODUCT WITHIN 7 DAYS OF THE DATE YOU ACQUIRED IT (IF PURCHASED NEW) FOR A FULL REFUND TO THE DEALER

FROM WHICH YOU PURCHASED THIS PRODUCT.

Licence Terms and Conditions

Garmin ("we" or "us") provides you with storage media containing the computer Software (the "Software") and the embedded or accompanying Data, including any "online" or electronic documentation and printed materials (together called the "Product" for purposes of this Licence Agreement), and grants you a limited, nonexclusive licence to use the Product in accordance with the terms of this Agreement. You agree to use this Data together with the Garmin product solely for personal use, or if applicable, for use in your business' internal operations and not for service bureau, time-sharing, resale or other similar purposes. Accordingly, but subject to the restrictions set forth in the following paragraphs, you may copy this Data only as necessary for your use to (i) view it and (ii) save it, provided that you do not remove any copyright notices that appear and do not modify the Software or Data in any way. You agree not to otherwise reproduce, copy, modify, decompile, disassemble, reverse engineer or create derivative works of any portion of the Product



and you may not transfer or distribute it in any form, for any purpose, except to the extent permitted by mandatory laws. Garmin also reserves the right to discontinue offering any Data supplied by any third-party supplier if such supplier ceases to supply such content or Garmin's contract with such supplier terminates for any reason.

Restrictions

Except where you have been specifically licensed to do so by Garmin and without limiting the preceding paragraph, you may not use this Data with any products, systems or applications installed or otherwise connected to or in communication with vehicles and which are capable of dispatch, fleet management or similar applications where the Data is used by a central control centre in dispatching a fleet of vehicles. In addition, you are prohibited from renting or leasing the Data or the Garmin products containing the Data to any other person or third party. Only those hire car companies that are specifically authorized by Garmin in writing to rent Garmin products containing the Data to their rental customers are permitted to rent out such products.

nüMaps™ Lifetime

If you purchase a nüMaps™ Lifetime subscription (sold separately), you will receive up to four (4) Map Data updates per year, when and as such updates are made available on Garmin's website, for one (1) compatible Garmin product until your product's useful life expires or Garmin no longer receives Map Data from NAVTEQ, whichever is shorter. The updates you receive under the subscription will be updates to the same geographic Map Data originally included with your Garmin product when originally purchased. In some instances, your Garmin product might not have sufficient memory remaining for you to load an update to the same Map Data originally included with your Garmin product, in which case you will need to either (a) select reduced Map Data coverage for your updates or (b) purchase separately a microSD card or an SD card (as applicable to your Garmin product) and load all or a portion of the Map Data coverage for your updates to the card and insert the card into the microSD card or SD card slot contained in your Garmin product. Garmin may terminate your nüMaps™ Lifetime subscription at any time if you violate

any of the terms of this Agreement or your subscription. Your nüMaps™ Lifetime subscription may not be transferred to another person or another Garmin product.

No Warranty

This Product (including the Data) is provided to you "as it is" and you agree to use it at your own risk. Garmin and its licensors (and their licensors and suppliers) make no guarantees, representations or warranties of any kind, express or implied, arising by law or otherwise, including but not limited to, content, quality, accuracy, completeness, effectiveness, reliability, merchantability, fitness for a particular purpose, usefulness, use or results to be obtained from the Product or that the Data or server will be uninterrupted or error-free.

Disclaimer of Warranty

GARMIN AND ITS LICENSORS (INCLUDING THEIR LICENSORS AND SUPPLIERS) DISCLAIM ANY WARRANTIES, EXPRESS OR IMPLIED, OF QUALITY, PERFORMANCE, MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NONINFRINGEMENT. NO ORAL OR WRITTEN ADVICE OR INFORMATION



PROVIDED BY GARMIN OR ITS SUPPLIERS AND LICENSORS SHALL CREATE A WARRANTY AND YOU ARE NOT ENTITLED TO RELY ON ANY SUCH ADVICE OR INFORMATION. THIS DISCLAIMER OF WARRANTIES IS AN ESSENTIAL CONDITION OF THIS AGREEMENT.

Some States, Territories and Countries do not allow certain warranty exclusions, so to that extent the above exclusion may not apply to you.

Disclaimer of Liability

GARMIN AND ITS LICENSORS (INCLUDING THEIR LICENSORS AND SUPPLIERS) SHALL NOT BE LIABLE TO YOU: IN RESPECT OF ANY CLAIM, DEMAND OR ACTION, IRRESPECTIVE OF THE NATURE OF THE CAUSE OF THE CLAIM, DEMAND OR ACTION ALLEGING ANY LOSS, INJURY OR DAMAGES, DIRECT OR INDIRECT, WHICH MAY RESULT FROM THE USE OR POSSESSION OF THE INFORMATION; OR FOR ANY LOSS OF PROFIT, REVENUE, CONTRACTS OR SAVINGS, OR ANY OTHER DIRECT, INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF YOUR USE OF OR INABILITY TO USE THIS INFORMATION, ANY DEFECT IN THE DATA OR

INFORMATION, OR THE BREACH OF THESE TERMS OR CONDITIONS, WHETHER IN AN ACTION IN CONTRACT OR TORT OR BASED ON A WARRANTY, EVEN IF GARMIN OR ITS LICENSORS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. GARMIN'S AND ITS LICENSORS' TOTAL AGGREGATE LIABILITY WITH RESPECT TO ITS OBLIGATIONS UNDER THIS AGREEMENT OR OTHERWISE WITH RESPECT TO THE GARMIN PRODUCT OR THE DATA SHALL NOT EXCEED \$1.00. Some States, Territories and Countries do not allow certain liability exclusions or damages limitations, so to that extent the above may not apply to you.

Disclaimer of Endorsement

Reference to any products, services, processes, hypertext links to third parties or other Data by trade name, trademark, manufacturer, supplier or otherwise does not necessarily constitute or imply its endorsement, sponsorship or recommendation by Garmin or its licensors. Product and service information are the sole responsibility of each individual vendor.

The NAVTEQ name and logo, the NAVTEQ and NAVTEQ ON BOARD

trademarks and logos and other trademarks and trade names owned by NAVTEQ North America LLC may not be used in any commercial manner without the prior written consent of NAVTEQ.

Export control

You agree not to export from anywhere any part of the Data provided to you or any direct product thereof except in compliance with, and with all licences and approvals required under, applicable export laws, rules and regulations.

Indemnity

You agree to indemnify, defend and hold Garmin and its licensors (including their respective licensors, suppliers, assignees, subsidiaries, affiliated companies and the respective officers, directors, employees, shareholders, agents and representatives of each of them) free and harmless from and against any liability, loss, injury (including injuries resulting in death), demand, action, cost, expense or claim of any kind or character, including but not limited to lawyer's fees, arising out of or in connection with any use or possession by you of the Product (including the Data).



Canadian Map Data

The Map Data for Canada may include or reflect data of licensors, including Her Majesty and Canada Post. Such data is licensed on an “as it is” basis. The licensors, including Her Majesty and Canada Post, make no guarantees, representations or warranties respecting such data, either express or implied, arising by law or otherwise, including but not limited to, effectiveness, completeness, accuracy or fitness for a particular purpose. The licensors, including Her Majesty and Canada Post, shall not be liable in respect of any claim, demand or action, irrespective of the nature of the cause of the claim, demand or action alleging any loss, injury or damages, direct or indirect, which may result from the use or possession of the data or the Map Data. The licensors, including Her Majesty and Canada Post, shall not be liable in any way for loss of revenues or contracts, or any other consequential loss of any kind resulting from any defect in the data or the Map Data. You shall indemnify and save harmless the licensors, including Her Majesty the Queen, the Minister of Natural Resources of Canada and Canada Post and their officers, employees and

agents from and against any claim, demand or action, irrespective of the nature of the cause of the claim, demand or action, alleging loss, costs, expenses, damages or injuries (including injuries resulting in death) arising out of the use or possession of the data or the Map Data. The terms contained in this Section are in addition to all of the rights and obligations of the parties under the Agreement. To the extent that any of the provisions of this Section are inconsistent with, or conflict with, any other provisions of the Agreement, the provisions of this Section shall prevail.

United States Map Data

NAVTEQ holds a nonexclusive licence from the United States Postal Service® to publish and sell ZIP+4® information. ©United States Postal Service® 2010. Prices are not established, controlled or approved by the United States Postal Service®. The following trademarks and registrations are owned by the USPS: United States Postal Service, USPS and ZIP+4.

Canadian Map Data

Map Data for Canada includes information taken with permission from Canadian authorities, including

©Her Majesty, ©Queen’s Printer for Ontario, ©Canada Post, GeoBase®, ©Department of Natural Resources Canada. All rights reserved.

Australian Map Data

Map Data for Australia is based on data NAVTEQ has licensed from PSMA Australia Limited (www.psmalimited.com.au). In addition, the Product incorporates data which is ©2010 Telstra Corporation Limited, GM Holden Limited, Intelematics Australia Pty Ltd, Sentinel Content Pty Limited and Continental Pty Ltd. If your Product uses RDS-TMC Codes contained in the Map Data, the traffic location codes are ©2010 Telstra Corporation Limited and its licensors.

Term

This Agreement is effective until such time as (i) if applicable, your subscription term is either terminated (by you or by Garmin) or expires, or (ii) Garmin terminates this Agreement for any reason, including, but not limited to, if Garmin finds that you have violated any of the terms of this Agreement. In addition, this Agreement shall terminate immediately upon the termination of an agreement between Garmin and



any third party from whom Garmin licenses the Data.

Entire Agreement

These terms and conditions constitute the entire agreement between Garmin (and its licensors, including their licensors and suppliers) and you pertaining to the subject matter hereof and supersedes in their entirety any and all written or oral agreements previously existing between us with respect to such subject matter.

Governing Law

(a) For European Union NAVTEQ Data
The above terms and conditions shall be governed by the laws of the Netherlands, without giving effect to (i) its conflict of laws provisions, or (ii) the United Nations Convention for Contracts for the International Sale of Goods, which is explicitly excluded. You agree to submit to the jurisdiction of the Netherlands for any and all disputes, claims and actions arising from or in connection with the NAVTEQ Data provided to you hereunder.

(b) For North American NAVTEQ Data and other non-European Union NAVTEQ Data

The above terms and conditions shall be governed by the laws of Illinois, without giving effect to (i) its conflict of laws provisions, or (ii) the United Nations Convention for Contracts for the International Sale of Goods, which is explicitly excluded. You agree to submit to the jurisdiction of Illinois for any and all disputes, claims and actions arising from or in connection with the NAVTEQ Data provided to you hereunder.

(c) For disputes, claims and actions not related to the NAVTEQ Data

The above terms and conditions shall be governed by the laws of Kansas, without giving effect to (i) its conflict of laws provisions, or (ii) the United Nations Convention for Contracts for the International Sale of Goods, which is explicitly excluded. You agree to submit to the jurisdiction of Kansas for any and all disputes, claims and actions arising from or in connection with the Data provided to you hereunder.

Government End Users

If the End User is an agency, department or other entity of the United States Government, or funded in whole or in part by the U.S. Government, then use, duplication, reproduction, release, modification,

disclosure or transfer of the Product and accompanying documentation is subject to restrictions as set forth in DFARS 252.227-7014(a)(1) (JUN 1995) (DOD commercial computer software definition), DFARS 27.7202-1 (DOD policy on commercial computer software), FAR 52.227-19 (JUN 1987) (commercial computer software clause for civilian agencies), DFARS 252.227-7015 (NOV 1995) (DOD technical data – commercial items clause); FAR 52.227-14 Alternates I, II and III (JUN 1987) (civilian agency technical data and non-commercial computer software clause); and/or FAR 12.211 and FAR 12.212 (commercial item acquisitions), as applicable. In case of conflict between any of the FAR and DFARS provisions listed herein and this Licence, the construction that provides greater limitations on the Government's rights shall control. The contractor/ manufacturer is Garmin International, Inc., 1200 East 151st Street, Olathe, KS 66062, USA and NAVTEQ North America LLC, 425 West Randolph Street, Chicago, Illinois 60606 USA.
Garmin® is a trademark of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. These



trademarks may not be used without the express permission of Garmin. NAVTEQ is a trademark in the U.S. and other countries. All other company names and trademarks mentioned or referenced in this documentation are the properties of their respective owners. All rights reserved.

DMTI Spatial, Inc. End User License Agreement

The software embedded in your Garmin product is owned by Garmin Ltd. or its subsidiaries ("Garmin"). The third-party postal code data (the "Licensed Product") embedded in or accompanying your Garmin product is owned by DMTI Spatial, Inc. and is licensed to Garmin. Both the software and Licensed Product are protected under copyright laws and international copyright treaties. THIS is a legal Agreement between you, the end user, and DMTI Spatial, Inc. BY LOADING THE PRODUCT(S) WITH THIS AGREEMENT YOU ARE AGREEING TO BE BOUND BY THE TERMS OF THIS AGREEMENT. IF YOU DO NOT AGREE TO THE TERMS OF THIS AGREEMENT, PROMPTLY (within 7 days of purchase) RETURN THE PRODUCTS AND ANY ACCOMPANYING ITEMS (including

written materials) TO Garmin INTERNATIONAL, INC. CUSTOMER SERVICE, 1200 EAST 151ST STREET, OLATHE, KANSAS 66062, FOR A REFUND.

DMTI Spatial hereby grants to you a non-exclusive, non-transferable license to use the data contained on the media in this package (the "Licensed Product") solely for personal non-commercial use or internal use in your business, on a single computer, Pocket PC, or Palm device in conjunction with Garmin software, and with compatible Garmin products that you personally own. Your use of the data is subject to the following terms and conditions:

You acknowledge that the Licensed Product(s) belong to DMTI Spatial and its third party supplier, and that the Licensed Product(s) are copyrighted. Unauthorized copying of the Licensed Product(s), is expressly forbidden and you may be held legally responsible for copyright infringement which is caused or encouraged by your failure to abide by the terms of this agreement. You may make one archival copy of the Licensed Product(s), solely for your own use, subject to the following restrictions: (1) The archival copy must be treated

in the same way as the original copy; (2) No copy may be used while any other copy is in use. If you make an archival copy of the Licensed Product(s), you must include on it the copyright notice that is on the original media.

You may not reproduce, sell, rent, lease, loan, distribute or sublicense the Licensed Product(s) or otherwise transfer the Licensed Product(s) to any third party, use the Licensed Product for commercial purposes except for internal use in your business, decompile, disassemble, reverse-engineer the Licensed Product(s), or use the Licensed Product to create any derived product for any of these prohibited purposes. You may not place the Licensed Product(s) on the Internet without a prior written agreement with DMTI Spatial. In no event shall DMTI Spatial or its third party supplier(s) be liable to you or your organization for any indirect damages including any lost profits, lost savings, interruption of business, loss of business opportunities or other incidental or consequential damages, arising out of your possession, use of, or inability to use the Licensed Product(s), even if DMTI Spatial, its third party supplier(s), or any



authorized dealer, has been advised of the possibility of the damages, or for any claim by any other party. In no event shall DMTI Spatial have any liability for damage in excess of the license fee paid for the Licensed Product(s).

You shall indemnify and hold DMTI Spatial, its third party supplier(s) and their officers, employees and agents, harmless from and against any claim, demand or action, irrespective of the nature of the claim, demand or action, alleging loss, costs, damages, expenses, or injury (including injury from death) resulting from your authorized or unauthorized, use, possession, modification, or alteration of the Licensed Product(s).

THE LICENSED PRODUCT(S) AND THE ASSOCIATED WRITTEN MATERIALS IN CONNECTION THERE-WITH ARE PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, ARISING BY LAW OR OTHERWISE, INCLUDING BUT NOT LIMITED TO WARRANTIES OF EFFECTIVENESS, COMPLETENESS, ACCURACY, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE LICENSED PRODUCT(S) IS WITH YOU, THE END

USER. NO ORAL OR WRITTEN ADVICE GIVEN BY DMTI SPATIAL OR ITS DEALERS, DISTRIBUTORS, AGENTS OR EMPLOYEES CREATES A WARRANTY OR IN ANYWAY INCREASES DMTI SPATIAL'S LIABILITY AND YOU MAY NOT RELY ON ANY SUCH INFORMATION OR ADVICE.

No statement or recommendation made or assistance given by DMTI Spatial or by its representatives or employees shall constitute a waiver by DMTI Spatial or any of the provisions herein. Nor does or will DMTI Spatial warrant any services it may provide in connection with the use of the Licensed Product(s), to include any assistance, training, or other consultation with you.

This license is effective until terminated. This license will terminate automatically without notice from DMTI Spatial if you fail to comply with any provision of this License Agreement. Upon termination, you shall destroy or return the Licensed Product(s) including any written materials and all copies of the Licensed Product(s) and any written materials in connection therewith have been destroyed or returned to DMTI Spatial. This Agreement shall be governed by the laws of the Province of Ontario.

©2007 DMTI Spatial Inc. (except for data licensed from third parties). DMTI Spatial is an authorized user and distributor of selected Statistics Canada Computer files under Licensing Agreement 6230.

© Copyright, HER MAJESTY THE QUEEN IN RIGHT OF CANADA, as represented by the Minister of Industry, Statistics Canada 1996.

Digital Topographic Data produced under license from Her Majesty the Queen in Right of Canada, with permission of Natural Resources Canada.

NAVTEQ Traffic™ End User License Agreement

Your Garmin product may be equipped to receive traffic data. If it is so equipped, the following terms and conditions apply to your use of your Garmin product.

NAVTEQ North America LLC and/or its affiliates including Traffic.com ("NAVTEQ") holds the rights to the traffic event data ("Traffic Data") and, if you receive RDS/TMC or HD Radio™ Traffic Data, the RDS/TMC or HD Radio networks through which it is delivered to your Garmin product. By subscribing to, receiving or otherwise accessing the Traffic Data, you acknowledge that



you have read this Agreement, that you understand it, that you agree to be bound by the terms and conditions of this Agreement, and that you are at least 18 years of age. If you do not agree to the terms and conditions of this Agreement, decline the subscription or, if the subscription is bundled as part of your Garmin product, return the product within 7 days for a full refund to the dealer from which you purchased the product.

You agree to use the Traffic Data together with your Garmin product solely for personal, non-commercial purposes, and not for service bureau, time-sharing or other similar purposes. You may not modify, copy, scan, decompile, disassemble or reverse engineer any portion of the Traffic Data, or use any other method to reproduce, duplicate, republish, transmit, or distribute in any way any portion of the Traffic Data. You agree to indemnify, defend, and hold harmless NAVTEQ (and its affiliates) and Garmin Ltd. (and its subsidiaries) against any and all claims, damages, costs, or other expenses that arise directly or indirectly out of (a) your unauthorized use of the Traffic Data or the RDS/TMC or HD Radio

networks, (b) your violation of this Agreement, and/ or (c) any unauthorized or unlawful activities by you in connection herewith. The Traffic Data is informational only. You assume all risk of use. NAVTEQ (and its affiliates), Garmin Ltd. (and its subsidiaries), and their suppliers make no representations about content, traffic and road conditions, route usability, or speed. The Traffic Data is provided to you “as is”, and you agree to use it at your own risk. NAVTEQ (and its affiliates) and Garmin Ltd. (and its subsidiaries) make no warranty of fitness or compatibility of the Traffic Data with the Garmin product and no warranty that the Traffic Data will operate properly as integrated and interfaced with the Garmin product. In addition, NAVTEQ (and its affiliates) and Garmin Ltd. (and its subsidiaries) make no warranty with regard to the reliability, accuracy, exhaustiveness, and completeness of the Traffic Data, which may contain inaccuracies and/or errors from time to time. To the maximum extent permitted by applicable law, any and all warranties of any kind whatsoever with regard to the Traffic Data are hereby expressly waived and excluded, including, but

not limited to, those of merchantability, fitness for a particular purpose, accuracy or completeness of the Traffic Data, and/or a lack of viruses.

NAVTEQ (and its affiliates), Garmin Ltd. (and its subsidiaries), and their suppliers disclaim all liability for any loss, injury, or damage resulting from use of or inability to use the Garmin product and the Traffic Data as a result of weather difficulties, the destruction of transmitters and/or broadcasting infrastructures, a natural disaster, and/or a lack of reliability, completeness, or accuracy of the Traffic Data. In no event shall NAVTEQ (and its affiliates), Garmin Ltd. (and its subsidiaries), and their suppliers be liable to you or any other party for any compensatory, direct, indirect, incidental, special, or consequential damages (including, without limitation, indirect, direct, special, punitive, or exemplary damages for loss of business, loss of profits, business interruption, or loss of business information) arising out of the use of or inability to use the Garmin product or the Traffic Data, even if NAVTEQ or Garmin have been advised of the possibility of such damages.



Traffic

This If you purchase or your Garmin product is pre-loaded with “lifetime” or “one-time” traffic, you will receive Traffic Data for the useful life of your Garmin traffic receiver (as long as you own a compatible Garmin GPS) or as long as Garmin receives Traffic Data from its third party content supplier, whichever is shorter. Garmin may terminate your traffic subscription immediately if you violate any of the terms of this Agreement. Your traffic subscription may not be transferred to another person or another Garmin product.

Governing Law

The above terms and conditions shall be governed by the laws of the State of Illinois, without giving effect to (i) its conflict of Law provisions, or (ii) the United Nations Convention for Contracts for the International Sale of Goods, which is explicitly excluded. You agree to submit to the jurisdiction of the State of Illinois for any and all disputes, claims and actions arising from or in connection with the Traffic Data provided to you hereunder.

Government End Users

If the Traffic Data is being acquired by or on behalf of the United States government or any other entity seeking or applying rights similar to those customarily claimed by the United States government, this Data is a “commercial item” as that term is defined at 48 C.F.R. (“FAR”) 2.101, is licensed in accordance with this Agreement, and the Traffic Data delivered or otherwise furnished shall be marked and embedded as appropriate with the following “Notice of Use,” and shall be treated in accordance with such Notice:

Notice of Use

Contractor (Manufacturer/ Supplier)
Name: NAVTEQ Contractor
(Manufacturer/supplier) Address: 425
West Randolph Street, Chicago, Illinois
60606.

This Data is a commercial item as defined in FAR 2.101 and is subject to the NAVTEQ Traffic™ End User License Agreement under which this Data was provided.

©2011 NAVTEQ; ©2011 Traffic.com – All rights reserved.

If the Contracting Officer, federal government agency, or any federal official refuses to use the legend

provided herein, the Contracting Officer, federal government agency, or any federal official must notify NAVTEQ prior to seeking additional or alternative rights in the Traffic Data. NAVTEQ and Traffic.com are trademarks in the U.S. and other countries. ©2011 NAVTEQ; ©2011 Traffic.com. All rights reserved. HD Radio Technology manufactured under license from iBiquity Digital Corporation. U.S. and Foreign Patents. HD Radio™ and the HD, HD Radio, and 9Arc9 logos are proprietary trademarks of iBiquity Digital Corp. Garmin® is a trademark of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. This trademark may not be used without the express permission of Garmin. All other company names and trademarks mentioned or referenced in this documentation are the properties of their respective owners. All rights reserved.



8 – *MTC System Phone*

Operating instructions	76
Operation	77
Phone call features	82
MTC System Phone features	85
Advanced phone connectivity	87
Things you should know about your MTC System	
Phone	87
Voice command tree	89
General information	92



Operating instructions

MTC System Phone is a voice-activated, hands-free, in-vehicle communications system.

MTC System Phone allows you to dial a phone number with your mobile phone.

MTC System Phone supports the following features:

Voice Activated Features

- Hands Free dialing via Voice ("Call John Smiths Mobile" or, "Dial two four eight five five five one two one two" (248 555-1212).
- Automatic reading of incoming SMS text messages using speaker phone.
- Sending text messages using speaker phone ("Send a message to John Smiths Mobile").
- Redialing last dialed numbers ("Redial").
- Calling Back the last incoming call number ("Call Back").
- View Call logs on screen ("Show incoming calls", "Show Outgoing calls", "Show missed Calls", "Show Recent Calls").
- Searching Contacts phone number ("Search for John Smith Mobile").

Screen Activated Features

- Dialing via Keypad using touch screen.
- Viewing and Calling contacts from Phonebooks displayed on the touch screen.
- Setting Favorite Contact Phone numbers so they are easily accessible on the Main Phone screen.
- Viewing and Calling contacts from Recent Call logs.
- Re-reading of recently received SMS.
- Sending a text message with touch screen.
- Listen to Music on your Bluetooth® Device via touch screen.
- Pairing up to 10 phones/audio devices for easy access to connect to them quickly.



fig. 31

NOTE:

To work properly, your mobile phone must have the sending SMS via Bluetooth® function.

Your mobile phone's audio is transmitted through your vehicle's audio system; the system will automatically mute your radio when using the MTC System Phone.

For customer support, visit your local authorized dealership.

If your mobile phone supports a different profile (e.g., Headset Profile) you may not be able to use any MTC System Phone features. Refer to your mobile service provider or the phone manufacturer for details.

MTC System Phone allows you to transfer calls between the system and your mobile phone as you enter or exit your vehicle and enables you to mute the system's microphone for private conversation.



WARNING!

Any voice commanded system should be used only in safe driving conditions following local laws and phone use. All attention should be kept on the

(Continued)



(Continued)
roadway ahead. Failure to do so may result in an accident causing serious injury or death.

MTC System Phone is driven through your Bluetooth® “Hands-Free Profile” mobile phone. MTC System features Bluetooth® technology – the global standard that enables different electronic devices to connect to each other without wires or a docking station, so MTC System Phone works no matter where you stow your mobile phone (be in your purse, pocket, or briefcase), as long as your phone is turned on and has been paired to the vehicle’s MTC System Phone. The MTC System Phone allows up to ten mobile phones or audio devices to be linked to the system. Only one linked (or paired) mobile phone and one audio device can be used with the system at a time. The system is available in English, Spanish, and French languages.

MTC System Phone Button

The MTC System Phone  button is used to get into the phone mode and make calls, show recent, incoming, outgoing calls, view phone book etc.. When you press the button you will

hear a BEEP. The beep is your signal to give a command.

MTC System Voice Command Button

The MTC System Voice Command  button is only used for “barge in” and when you are already in a call and you want to send Tones or make another call.

The  button is also used to access the voice commands feature of the MTC system. The MTC System Phone is fully integrated with the vehicle’s audio system. The volume of the MTC System Phone can be adjusted either from the radio volume control knob or from the steering wheel radio control (right switch).

Operation

Voice commands can be used to operate the MTC System Phone and to navigate through the MTC System Phone menu structure. Voice commands are required after most MTC System Phone prompts. There are two general methods for how Voice Command works:

1. Say compound commands like “Call John Smith mobile”.
2. Say the individual commands and allow the system to guide you to complete the task.

You will be prompted for a specific command and then guided through the available options.

- Prior to giving a voice command, one must wait for the beep, which follows the “Listen” prompt or another prompt.
- For certain operations, compound commands can be used. For example, instead of saying “Call” and then “John Smith” and then “mobile”, the following compound command can be said: “Call John Smith mobile”.



- For each feature explanation in this section, only the combined form of the voice command is given. You can also break the commands into parts and say each part of the command when you are asked for it. For example, you can use the combined form voice command "Search for John Smith", or you can break the combined form command into two voice commands: "Search Contact" and when asked "John Smith". Please remember, the MTC System Phone works best when you talk in a normal conversational tone, as if speaking to someone sitting a few meters away from you.

Natural Speech

Your MTC System Phone Voice system uses a Natural Language Voice Recognition (VR) engine. Natural speech allows the user to speak commands in phrases or complete sentences. The system filters out certain non-word utterances and sounds such as "ah" and "eh". The system handles fill-in words such as "I would like to". The system handles multiple inputs in the same phrase or sentence such as "make a phone call" and "to Kelly Smith". For multiple inputs in the same

phrase or sentence, the system identifies the topic or context and provides the associated follow-up prompt such as "Who do you want to call?" in the case where a phone call was requested but the specific name was not recognized.

The system utilizes continuous dialog; when the system requires more information from the user it will ask a question to which the user can respond without pressing the  VR button.

Voice Command Tree

Refer to "Voice Command Tree" in this section.

Help Command

If you need assistance at any prompt, or if you want to know your options at any prompt, say "Help" following the beep.

To activate the MTC System Phone from idle, simply press the  button and say a command or say "help". All MTC System Phone sessions begin with a press of the  button.

Cancel Command

At any prompt, after the beep, you can say "Cancel" and you will be returned to the main menu. You can also press

the  or  VR buttons when the system is listening for a command and be returned to the main or previous menu.

NOTE:

Pressing the  or  VR buttons while the system is playing is known as "Barging In", refer to "Barge In - Overriding Prompts" for further information.

Pair (Link) MTC System Phone to a Mobile Phone

To begin using your MTC System Phone, you must pair your compatible Bluetooth® enabled mobile phone. To complete the pairing process, you will need to reference your mobile phone Owner's Manual. The MTC System website may also provide detailed instructions for pairing.

NOTE:

- You must have Bluetooth® enabled on your phone to complete this procedure.
- The vehicle must be in Park.



1. Press the Phone soft-key.
2. If there is no phone currently paired with the system, a pop-up will appear fig. 32.



fig. 32

3. Select Yes to begin the pairing process. Then, search for available devices on your Bluetooth® enabled mobile phone. When prompted on the phone, enter the name and PIN shown on the MTC System Touch screen.
 - If No is selected, touch the settings soft-key from the MTC System Phone main screen.
 - Touch the Add Device soft-key.
 - Search for available devices on your Bluetooth® enabled mobile phone. When prompted on the phone, enter the name and PIN shown on the MTC System Touch screen.
4. MTC System Phone will display an in process screen while the system is connecting.
5. When the pairing process has successfully completed, the system will prompt you to choose whether or not this is your favorite phone. Selecting Yes will make this phone the highest priority. This phone will take precedence over other paired phones within range.

NOTE:

For phones which are not made a favorite, the phone priority is determined by the order in which it was paired. the latest phone paired will have the higher priority.

You can also use the following VR commands to bring up the Paired Phones screen from any screen on the radio:

- “Show Paired Phones” or
- “Connect My Phone”.

Pair a Bluetooth® Streaming Audio Device

- Enter Player Mode by touching the Player soft-key located on the bottom of the display.
- To change the mode, once in Player Mode, touch the Source soft-key fig. 33.
- Change the Source to Bluetooth®.
- Touch the Add Device soft-key.



NOTE:

If no device is currently connected to the system, a related message will display.

- Search for available devices on your Bluetooth® enabled audio device. When prompted on the device, enter the name and PIN shown on the MTC System Touch screen.
- MTC System Phone will display an in process screen while the system is connecting.
- When the pairing process has successfully completed, the system will prompt you to choose whether or not this is your favorite device. Selecting Yes will make this device the highest priority. This device will take precedence over other paired devices within range.



fig. 33

NOTE:

If No is selected, device priority is determined by the order in which it was paired. The latest device paired will have the higher priority.

You can also use the following VR command to bring up a list of paired audio devices:

- “Show Paired Audio Devices”.

Connecting to a Particular Mobile Phone or Device

MTC System Phone will automatically connect to the highest priority paired phone within range. If you would need to choose a particular phone or device follow the steps:

- Touch the Settings soft-key located on the bottom of the display.
- Touch the Phone/Bluetooth soft-key.

- Touch to select the particular phone or device and touch Connect Device.
- Touch the X soft-key to exit the Settings screen.

Disconnecting a Mobile Phone or a Device

- Touch the Settings soft-key located on the bottom of the display.
- Touch the Phone/Bluetooth soft-key.
- Touch **+** to select the Mobile Phone or the device.
- Touch the Disconnect Device soft-key.
- Touch the X soft-key to exit the Settings screen.

Delete a Mobile Phone or a Device

- Touch the Settings soft-key located on the bottom of the display.
- Touch the Phone/Bluetooth soft-key.
- Touch **+** to select the Mobile Phone or the device to delete.
- Touch the Delete Device soft-key.
- Touch the X soft-key to exit the Settings screen.

Making a Mobile Phone or a Device a Favorite

- Touch the Settings soft-key located on the bottom of the display.



- Touch the Phone/Bluetooth soft-key.
- Touch **+** to select the Mobile Phone or the device to make a Favorite.

NOTE:

You will see the chosen device move to the top of the list.

- Touch the Make Favorite soft-key.
- Touch the X soft-key to exit the Settings screen.

Phonebook Download - Automatic Phonebook Transfer From Mobile Phone

Where provided and specifically supported by your phone, MTC System Phone automatically downloads names (text names) and number entries from the mobile phone's phonebook. Specific Bluetooth® Phones with Phone Book Access Profile may support this feature. See MTC System website for supported phones.

- To call a name from a downloaded mobile phonebook, follow the procedure in "Call by Saying a Name" section.
- Automatic download and update, if supported, begins as soon as the Bluetooth® wireless phone

connection is made to the MTC System Phone, for example, after you start the vehicle.

- A maximum of 1000 or 2000 (for versions/markets, where provided) entries per phone will be downloaded and updated every time a phone is connected to the MTC System Phone.
- Depending on the maximum number of entries downloaded, there may be a short delay before the latest downloaded names can be used. Until then, if available, the previous downloaded phonebook is available for use.
- Only the phonebook of the currently connected mobile phone is accessible.
- This downloaded phonebook cannot be edited or deleted on the MTC System Phone. These can only be edited on the mobile phone. The changes are transferred and updated to MTC System Phone on the next phone connection.

Favorites index management

There are three ways to add an entry to the favorites index.

1. During an active call of a number to be bookmarked, press and hold the button of favorites on the upper part of the main screen of the phone.
2. After loading the phone contacts, select index from the main screen of the phone, then select the number you want to add.

Press **+** beside the selected number in order to display the dialog box options, select Add to Favorites in the dialog box.

NOTE:

If your list of favorites is full, you will be required to remove an existing entry.



3. From the phone screen, select List. On the list screenshot, select the electronic key "Favorites", then press the electronic **+** on the left side of the list. Select an empty entry and press **+** on the selected entry. When the Options dialog box is displayed, select "Add from Mobile". You are then asked to enter the contact and number from the phone book. Once selected, the new entry will display.

Delete a favorite contact

- To remove a favorite contact, select List from the main screenshot Phone. Then, select Favorites on the left side of the screen and press the electronic + Options.
- Press **+** beside the favorite contact to be removed.
- When the Options dialog box will display, click Remove from Favorites.

Emergency and Towing Assistance

The Help numbers can only be altered. These cannot be deleted or the names cannot be changed.

To change the Help number follow these steps.

- Touch the phonebook soft-key from the Phone main screen.
- Touch the Favorites soft-key. Touch the appropriate listing to alter, Emergency for example.
- Touch the + Options soft-key.
- Press **+** beside the favorite number to be modified.
- The Options dialog box will display in order to choose whether to recall or modify the favorite number.

Phone call features

The following features can be accessed through the MTC System Phone if the feature(s) are available on your mobile service plan and supported over Bluetooth®. For example, if your mobile service plan provides three-way calling, this feature can be accessed through the MTC System Phone. Check with your mobile service provider for the features that you have.

Ways to Initiate a Phone Call

Listed below are all the ways you can initiate a phone call with MTC System Phone.

- Redial
- Dial by touching in the number
- Voice Command Dial (Digital, Contact, Redial, or Call Back)
- Favorite Phonebook
- Mobile Phonebook
- Recent Call Log
- SMS Message Viewer.

NOTE:

All of the above operations except Redial can be done with 1 call or less active.



Dial by Saying a Number

- Press the  button to begin.
- After the "Listening" prompt and the following beep, say "Dial 248-555-1212".
- The MTC System Phone will dial 248-555-1212.

Call by Saying a Name of the Phonebook

- Press the  button to begin.
- After the "Listening" prompt and the following beep, say "Call John Doe Mobile".
- The MTC System Phone will dial the number associated with John Doe, or if there are multiple numbers it will ask which number you want to call for John Doe.

Call Controls

The touch-screen allows you to control the following call features:

- Answer
- End
- Ignore
- Hold/unhold
- Mute/unmute
- Transfer the call to/from the phone
- Swap 2 active calls

- Conference/join 2 active calls together.

Touch-Tone Number Entry

- Touch the Phone soft-key.
- Touch the Dial soft-key.
- The Touch-Tone screen will be displayed.
- Use the numbered soft-keys to enter the number and touch Call.

For example: to send a touch tone using Voice Recognition (VR), press the  VR button while in a call and say "1234#" or you can say "Send Voicemail Password" if Voicemail password is stored in your mobile phonebook.

Recent Calls

You may browse up to 34 of the most recent of each of the following call types:

- Incoming Calls
- Outgoing Calls
- Missed Calls
- All Calls

These can be accessed by touching the recent calls soft-key on the Phone main screen. You can also press the  button and say "Show my incoming

calls" from any screen and the Incoming calls will be displayed.

NOTE:

Incoming can also be replaced with "Outgoing", "Recent" or "Missed".

Answer or Reject an Incoming Call - No Call Currently in Progress

When you receive a call on your mobile phone, the MTC System Phone will interrupt the vehicle audio system, if on, and will display a pop up on-screen showing Answer or Ignore. Press the Answer soft-key or the  button on the steering wheel to accept the call. Press the Ignore soft-key to reject the call. You may also select the blue box of the caller ID.

Answer or Reject an Incoming Call - Call Currently in Progress

If a call is currently in progress and you have another incoming call, you will hear the same network tones for call waiting that you normally hear when using your mobile phone. Press the  button or the Answer soft-key or the blue box of the caller ID to



place the current call on hold and answer the incoming call.

NOTE:

The MTC System Phone compatible phones in the market today do not support rejecting an incoming call when another call is in progress. Therefore, the user can only answer an incoming call or ignore it.

Making a Second Call while Current Call in Progress

To make a second call while you are currently on a call, press the  button and say "Dial" or "Call" followed by the phone number or phonebook entry you wish to call. The first call will be on hold while the second call is in progress. Or you can place a call on hold by touching the Hold soft-key on the Phone main screen, then dial a number from the dial pad, recent calls, SMS received or from the phonebooks. To go back to the first call, refer to "Toggling Between Calls" in this section. To combine two calls, refer to "Conference Call" in this section.

Put on hold or resume a call waiting

During an active call, select the electronic Hold soft-key the main screenshot of the Phone.

Toggling between Calls

If two calls are in progress (one active and one on hold), you can switch the active and hold status of the two calls by pressing the Swap soft-key on the Phone main screen. Also, you can press the  button until you hear a single beep, indicating that the active and hold status of the two calls have switched. Only one call can be placed on hold at a time.

Join calls

If two calls are in progress (one active and one on hold), touch the electronic "Join Calls" soft-key on the Phone main screenshot in order to join all phone calls in a conference call.

Call Termination

To end a call in progress, momentarily press the End soft-key or the  button. Only the active call(s) will be terminated and if there is a call on hold, it will become the new active call. If the active call is terminated by

the far end, a call on hold may not become active automatically. This is cell phone-dependent.

Redial

- Press the Redial soft-key.
- After the "Listening" prompt and the following beep, say "Redial".
- Or press the  button and after the "Listening" prompt and the following beep, say "Redial".
- The MTC System Phone will call the last number that was dialed from your mobile phone.

Call continuation

Call continuation is the progression of a phone call on the MTC System Phone after the vehicle ignition key has been switched to OFF.

NOTE:

After the ignition key is switched to OFF, a call can continue on the MTC System Phone either until the call ends, or until the vehicle battery condition dictates cessation of the call on the MTC System Phone and transfer of the call to the mobile phone.



MTC System Phone features

Emergency Assistance

If you are in an emergency and the mobile phone is reachable:

- Pick up the phone and manually dial the emergency number for your area.

If the phone is not reachable and the MTC System Phone is operational, you may reach the emergency number as follows:

- Press the  button to begin.
- After the "Listening" prompt and the following beep, say "Call Emergency" or "Dial Emergency" and the MTC System Phone will instruct the paired mobile phone to call the emergency number. This feature is supported in the U.S., Canada, and Mexico.

NOTE:

- The emergency call can also be initiated using the touch screen.
- The emergency number dialed is based on the country where the vehicle is purchased. The number dialed may not be applicable with

(Continued)

(Continued)

the available mobile service and area.

- The MTC System Phone does slightly lower your chances of successfully making a phone call as to that for the mobile phone directly.



WARNING!

Your phone must be turned on and paired to the MTC System Phone to allow use of this vehicle feature in emergency situations, when the mobile phone has network coverage and stays paired to the MTC System Phone.

Towing Assistance

If you need towing assistance:

- Press the  soft-key to begin.
- After the "Listening" prompt and the following beep, say "Towing Assistance".

NOTE:

- The emergency roadside assistance call can also be initiated using the touch screen.

(Continued)

(Continued)

- The towing assistance number dialed is based on the country where the vehicle is purchased.

Voice Mail Call

To learn how to access your voice mail, refer to "Working with Automated Systems".

Working with Automated Systems

This method is used in instances where one generally has to press numbers on the mobile phone keypad while navigating through an automated telephone system.

You can use your MTC System Phone to access a voice mail system or an automated service, such as a paging service or automated customer service line. Some services require immediate response selection. In some instances, that may be too quick for use of the MTC System Phone.

When calling a number with your MTC System Phone that normally requires you to enter in a touch-tone sequence on your mobile phone keypad, you can utilize the touch-screen or press the  button and say the word "Send" then the sequence you wish to



enter. For example, if required to enter your PIN followed with a pound, (3 7 4 6 #), you can press the  VR button and say, "Send 3 7 4 6 #". Saying "Send" followed by a number, or sequence of numbers, is also to be used for navigating through an automated customer service center menu structure, and to leave a number on a pager.

You can also send stored mobile phonebook entries as tones for fast and easy access to voice mail and pager entries. To use this feature, dial the number you wish to call and then press the  VR button and say for example, "Send Voicemail password". The system will prompt you to enter the name or number and say the name of the phonebook entry you wish to send. The MTC System Phone will then send the corresponding phone number associated with the phonebook entry, as tones over the phone.

NOTE:

- *The first number encountered for that contact will be sent. All other numbers entered for that contact will be ignored.*

(Continued)

(Continued)

- *You may not hear all of the tones due to mobile phone network configurations. This is normal.*
- *Some paging and voice mail systems have system time out settings that are too short and may not allow the use of this feature.*
- *Pauses, wait or other characters that are supported by some phones are not supported over Bluetooth®. These additional symbols will be ignored in the dialing a numbered sequence.*

Barge in - Overriding Prompts

The  VR button can be used when you wish to skip part of a prompt and issue your voice command immediately. For example, if a prompt is asking "There are 2 numbers with the name John. Say the full name" you could press the  VR button and say, "John Smith" to select that option without having to listen to the rest of the voice prompt.

Voice Response Length

It is possible for you to choose between Brief and Detailed Voice Response Length.

- Touch the Settings soft-key.

- Touch the Display soft-key, then scroll down to Voice Response Length.
- Select either Brief or Detailed by touching the box next to the selection. A check-mark will appear to show your selection.

Phone and Network Status Indicators

MTC System Phone will provide notification to inform you of your phone and network status when you are attempting to make a phone call using MTC System Phone. The status is given for roaming, network signal strength and phone battery strength.

Dialing using the Mobile Phone Keypad

You can dial a phone number with your mobile phone keypad and still use the MTC System Phone (while dialing via the mobile phone keypad, the user must exercise caution and take precautionary safety measures). By dialing a number with your paired Bluetooth® mobile phone, the audio will be played through your vehicle's audio system. The MTC System Phone will work the same as if you dial the number using voice command.

**NOTE:**

Certain brands of mobile phones do not send the dial ring to the MTC System Phone to play it on the vehicle audio system, so you will not hear it. Under this situation, after successfully dialing a number the user may feel that the call did not go through even though the call is in progress. Once your call is answered, you will hear the audio.

Mute/Un-Mute (Mute OFF)

When you mute the MTC System Phone, you will still be able to hear the conversation coming from the other party, but the other party will not be able to hear you. In order to mute the MTC System Phone simply touch the Mute soft-key on the Phone main screen.

Advanced phone connectivity**Transfer Call to and from Mobile Phone**

The MTC System Phone allows ongoing calls to be transferred from your mobile phone to the MTC System Phone without terminating the call. To transfer an ongoing call from your MTC System Phone paired mobile phone to the MTC System Phone or vice versa, press the Transfer soft-key on the Phone main screen.

Connect or disconnect link between the MTC System Phone and Mobile Phone

If you would like to connect or disconnect the Bluetooth® connection between a MTC System Phone paired mobile phone and the MTC System Phone, follow the instructions described in your mobile phone User's Manual.

Things you should know about your MTC System Phone**Voice Command mode**

- For best performance, adjust the rearview mirror to provide at least 1 cm gap between the overhead console (for versions/markets, where provided) and the mirror.
- Always wait for the beep before speaking.
- Speak normally, without pausing, just as you would speak to a person sitting a few meters away from you.
- Make sure that no one other than you is speaking during a voice command period.
- Performance is maximized under:
 - low-to-medium blower setting
 - low-to-medium vehicle speed
 - low road noise
 - smooth road surface
 - fully closed windows
 - dry weather condition
- Even though the system is designed for users speaking with North American English, French, and Spanish accents, the system may not always work properly.



- When navigating through an automated system such as voice mail, or when sending a page, at the end of speaking the digit string, make sure to say "Send".
- Storing names in your favorites phonebook when the vehicle is not in motion is recommended.
- Phonebook (Downloaded and MTC System Phone Local) name recognition rate is optimized when the entries are not similar.
- You can say "O" (letter "O") for "0" (zero).
- Even though international dialing for most number combinations is supported, some shortcut dialing number combinations may not be supported.
- In a convertible vehicle, system performance may be compromised with the sunroof down.
- On versions with opening sunroof, performance may be impaired when the roof is open.
- smooth road surface
- fully closed windows
- dry weather conditions
- operation from the driver's seat.
- Performance, such as audio clarity, echo, and loudness to a large degree rely on the phone and network, and not the MTC System Phone.
- Echo at the far end can sometimes be reduced by lowering the in-vehicle audio volume.
- In a convertible vehicle, system performance may be compromised with the sunroof down.
- In versions with opening sunroof, performance may be impaired when the roof is open.

Sms function

MTC Phone can read or send new messages from the phone. To use this function, the phone must support the sending SMS via Bluetooth®. If MTC phone detects that the phone does not support sending SMS via Bluetooth®, the function will not be available and the Messaging electronic soft-key will result inactive.

Far end audio performance

- Audio quality is maximized under:
 - low-to-medium blower setting
 - low-to-medium vehicle speed
 - low road noise

NOTE:

For safety reasons, the SMS function is available only when the vehicle is stationary.

Reading messages

If you receive a new text message while the phone is connected to the MTC Phone system, the screen will display the corresponding message. Once received a message viewed and listened, following options are available:

- Send a Reply
- Forward
- Call

Sending messages with electronic soft-keys

With MTC Phone it is possible to send SMS messages. To send a new message:

- Select the Phone electronic soft-key.
- Select the Messaging electronic soft-key, then New Message.
- Select one of the 18 preset messages and the person to whom you want to send the message.
- If more than one number is available for the receiver, select the number to which you want to send the message.
- Press Send or Cancel.



Voice controlled messaging

Press the  soft-key.

- After the Listening message and following beep, say "Send message to John Smith mobile".
- When the system indicates the message to be send, deliver the desired message, or List. There are 18 preset messages.

While reading the list of decided messages, you may interrupt the system by pressing the  VR soft-key and deliver the message you wish to send.

After the system has confirmed that you want to send the message to John Smith, it will proceed with the sending.

List of preset messages:

1. Yes
2. No
3. Okay
4. I can't talk right now
5. Call me
6. I'll call you later
7. I'm on my way
8. Thanks

9. I'll be late
10. I will be (number) minutes late
11. See you in (number) minutes
12. Stuck in traffic
13. Start without me
14. Where are you?
15. Are you there yet?
16. I need directions
17. I'm lost
18. See you later

Bluetooth® communication link

Mobile phones have been found to lose connection to the MTC System Phone.

When this happens, the connection can generally be reestablished by switching the phone OFF/ON.

Your cellular phone is recommended to remain in Bluetooth® ON mode.

Power-Up

After switching the ignition key from **OFF** to either the **RUN** or **ACC** position, or after a language change, you must wait at least 15 seconds prior to using the system.

Voice command tree

General commands

The general commands can be entered from any screenshot, as long as there is no ongoing phone call, after pushing the  VR button on the steering wheel (see Note 1, 2).

- Say "Help" to listen all available voice commands.
- Say "Cancel" to cancel the listening of available voice commands.
- Say "Go to Phone" to view initial phone screenshot on the display.

NOTE:

1. *Available voice commands are displayed in bold and shaded.*
2. *It is possible to replace "Phone" with "Player", "Radio", "Navigation", "Climate" or "Settings".*

General commands for phone management

Commands for general phone management can be entered from any screenshot, after pressing the



 button on the steering wheel (see Note 1).

- Say “Help” to listen all available voice commands.
- Say “Cancel” to cancel the listening of available voice commands.
- Say “Connect my Phone” to view Bluetooth® phone settings on the. The connecting process is completed by touch controls on the screen.
- Say “Show paired audio sources” to view currently connected Bluetooth® paired audio sources list on the screen.
- Say “Show paired Phones” to view the paired phones list on the screen.

NOTE:

1. *Available voice commands are displayed in bold and shaded.*

MTC System Hands-Free Calling

The commands can be spoken from any screen after pushing the MTC Phone button  on the steering wheel.

Call John Smith Mobile

Number associated with entry is dialed (see Note 1, 2, 5, 8, 9).

Redial

Last number called is redialed (see Note 5).

Call Back

Last incoming call is dialed (see Note 5).

Show My Incoming calls

Incoming call list will be shown (see Note 3, 5, 8).

Show My Contacts

Phonebook screen will be shown (see Note 5, 8).

Search for John Smith

Shows the phonebook entry for John Smith with all stored numbers (see Note 1, 8).

Dial 248 555 1212

Number is dialed (see Note 4, 5).

MTC System Hands-Free Calling (available commands while phone call is in progress)

The commands can be spoken from any screen while a call is active after pushing the voice command button  on the steering wheel.

Send 1234#

Dial Tones for “1234#” are sent (see Note 6).

Send “Voicemail Password”

Dial Tones for numbers stored in “Voicemail Password” are sent (see Note 6, 7).

NOTE:

1. You can replace “John Smith” with any name in your mobile or favorite phone book. You can also say “Send a message to John Smith” and the system will ask you which phone number you want to send a message to for John Smith.
2. You can replace “Mobile” with “Home”, “Work” or “Other”.
3. You can replace “Incoming Calls” with “Outgoing Calls” or “Missed Calls”.
4. Messaging commands only work if the MTC System is equipped with this feature and the mobile phone supports messaging over Bluetooth.
5. You can replace “248 555 1212” with any phone number supported by your Mobile phone.
6. You can replace “4” with any message number shown on the screen.

(Continued)



(Continued)

7. *If your phone does not support phonebook download or call log download over Bluetooth® than these commands will return a response that the contact does not exist in the phonebook.*
8. *Available Voice Commands are shown in bold face and underlined in the gray shaded boxes.*

Managing text messages with MTC System

The commands can be imparted from any screenshot after pushing the MTC Phone button  on the steering wheel.

Send a message to 248 555 1212

- Insert message from the preset list of the MTC or impart "List" to listen all 18 preset messages.
- Say "Yes" to send the selected message.
- The message is sent to the number linked to the receiver (see Note 4, 5).

Send a message to John Smith Mobile

- Insert the message from the MTC system preset list or impart "List" to listen all 18 preset messages.
- Say "Yes" to send selected message.
- The message is sent to the number linked to the receiver (see Note 1, 2, 5, 8, 9).

Show Messages

Displays box of incoming messages downloaded from your phone (see Note 4, 6).

- Say "Listen to number 4".
- The MTC system reads the message by using the car's audio system.
- After reading the message the following commands are automatically available:
 - Read (reads the message by using the car's audio system). After reading the message it is possible to read, reply or forward the message.
 - Send a Reply (insert the message from the MTC System or impart "List" to listen all 18 preset messages).
 - Forward (insert receiver name and phone type imparting subsequently "Yes" to send the selected message. The message is

sent to the number linked to the receiver name.

- Call (dials the number linked to the message).

or

- Say "View number 4".
- The MTC System displays the message on the screen.
- While displaying the message, following commands will be available after pressing the  soft-key:
 - Read (reads the message using the car's audio system. After reading the message it is possible to read again, reply or forward the message).
 - Send a Reply (insert the message from the MTC System or impart "List" to listen all 18 preset messages).
 - Forward (insert receiver name and phone type imparting "Yes" to send the selected message. The message is sent to the number linked to the receiver name).
 - Call (dials the number linked to the message).



NOTE:

1. You can replace “John Smith” with any name in your mobile or favorite phone book. You can also say “Send a message to John Smith” and the system will ask you which phone number you want to send a message to for John Smith.
2. You can replace “Mobile” with “Home”, “Work” or “Other”.
3. You can replace “Incoming Calls” with “Outgoing Calls” or “Missed Calls”.
4. Messaging commands only work if the MTC System is equipped with this feature and the mobile phone supports messaging over Bluetooth®.
5. You can replace “248 555 1212” with any phone number supported by your Mobile phone.
6. You can replace “4” with any message number shown on the screen.

(Continued)

7. *If your phone does not support phonebook download or call log download over Bluetooth® than these commands will return a response that the contact does not exist in the phonebook.*
8. *Available Voice Commands are shown in bold face and underlined in the gray shaded boxes.*

General information

The current device complies with Part 15 of FCC rules and RSS 210 of Canada Industry. The device functioning is subject to following conditions:

- changes or modifications not expressly approved by the authority relevant for conformity could void the possibility of use of the equipment by the user;
- the device may not cause harmful interference;
- must beat any interference, including interference that can cause its malfunction.

(Continued)



9 – *Settings*

Settings Main Menu	94
--------------------------	----



Settings Main Menu

Touch the Settings soft-key to display the list of available settings fig. 34.



fig. 34

- Display
- Clock & Date
- Safety & Driving Assistance
- Lights
- Doors & Locks
- Auto-On Comfort & Remote Start
- Engine Off Options
- Audio
- Phone/Bluetooth
- Radio Setup or SIRIUS Setup (where available)

Display

Your MTC System display can be customized by following the steps:

1. Press the Settings soft-key on the bottom of the screen.
2. Press the Display soft-key to enter the Display Menu fig. 35.



fig. 35

3. The Display Menu shows the following options for you to customize your display.
 - Display Mode
 - Display Brightness with Headlights On
 - Display Brightness with Headlights Off
 - Set Language
 - Units
 - Voice Response Length
 - Touchscreen Beep
 - Control Screen Time-Out
 - Navigation Turn-by-Turn Displayed on Cluster
4. Touch the + or – soft-key to change the Brightness. Or touch the check mark or empty box to change a selection.

NOTE:

The check-mark indicates the current selection is active.

5. Touch the left arrow soft-key to return to the Display Menu.
6. Touch the X soft-key to exit from the Display Menu and Settings.



Display Mode

The display lighting can be set in Day, Night, or Auto mode (automatic switching from Day to Night).

Display Brightness with Headlights On

This mode allows you to adjust display brightness by headlights on.

Display Brightness with Headlights Off

This mode allows you to adjust display brightness by headlights off.

Set Language

This mode allows to select the display language fig. 36.



fig. 36

The available languages are:

- English
- Français
- Español

- Deutsch
- Italiano
- Nederlands

Units

This mode allows you to select the measurement units:

- US
- Metric

Voice Response Length

This mode allows you to select the voice response length:

- Brief
- Detailed

Touchscreen Beep

This mode allows you to select whether to enable or disable the Beep sound every time you operate a soft-key on the touch screen.

Control Screen Time-Out

This mode allows you to enable or disable the delay of the monitor screen display.

Navigation Turn-by-Turn displayed on Cluster

This mode allows you to turn on or off, turn-by-turn pictograms on the instrument panel during navigation.

Clock & Date

1. Press the Settings soft-key on the bottom of the screen.

NOTE:

The Clock Setting Menu can also be accessed by touching the time as it is displayed on the screen.

2. Press the Clock soft-key to enter the Clock Menu fig. 37.



fig. 37



3. In the Set Time screen, press the + or – soft-keys to adjust the hours or minutes.
4. Other options available:
 - Sync Time with GPS Time, Radio Time or Off.
 - Time Format (12 or 24 hours).
 - Set Date in Cluster (DD/MM/YY).
5. Touch the check mark or empty box to change a selection.

NOTE:

The check-mark indicates the current selection is active.

6. Touch the left arrow soft-key to return to the Main Menu.
7. Touch the X soft-key to exit from the Clock Menu and Settings.

Safety & Driving Assistance

1. Press the Settings soft-key on the bottom of the screen.
2. Press the Safety & Driving Assistance soft-key to enter the Menu.
3. The available options are:
 - Park Assist (Off, Sound or Sound + Display).
 - Tilt Side Mirrors in Reverse (On or Off).
 - Parkview Backup Camera (On or Off).
 - Rain Sensing Auto Wipers (On or Off).
4. Touch the check mark or empty box to change a selection.

NOTE:

The check-mark indicates the current selection is active.

5. Touch the left arrow soft-key to return to the Main Menu.
6. Touch the X soft-key to exit from the Safety & Driving Assistance Menu and Settings.

Lights

1. Press the Settings soft-key on the bottom of the screen.
2. Press the Lights soft-key to enter the Menu.
3. The options available are:
 - Headlight Off Delay.
 - Headlight Illumination on Approach.
 - Headlights with Wipers.
 - Auto Dim High Beams.
 - Steering Directed Headlights.
 - Headlight Dip (Traffic Changeover) (condition responsive automatically adjusted headlamp beam).
 - Flash Lamps with Lock.
4. Press the + or – soft-keys to adjust the time in seconds.
5. Touch the check mark or empty box to change a selection.

NOTE:

The check-mark indicates the current selection is active.



6. Touch the left arrow soft-key to return to the Main Menu.
7. Touch the X soft-key to exit from the Lights Menu and Settings.

Doors & Locks

1. Press the Settings soft-key on the bottom of the screen.
2. Press the Doors & Locks soft-key to enter the Menu.
3. The options available are:
 - Auto Door Locks.
 - Auto Unlock on Exit.
 - Flash Lamps with Lock.
 - 1st Press of Key Fob Unlocks (Driver Door only or All Doors).
 - Passive Entry.
 - Personal Settings Linked to Key Fob.
4. Touch the check mark or empty box to change a selection.

NOTE:

The check-mark indicates the current selection is active.

5. Touch the left arrow soft-key to return to the Main Menu.
6. Touch the X soft-key to exit from the Doors & Locks Menu and Settings.

Auto-On Comfort & Remote Start

1. Press the Settings soft-key on the bottom of the screen.
2. Press the Auto-On Comfort & Remote Start soft-key to enter the Menu:
 - Auto-on Driver Heated/Vented Seat & Steering Wheel with Vehicle Start (On or Off).
3. Touch the check mark or empty box to change the selection.

NOTE:

The check-mark indicates the selection is active.

4. Touch the left arrow soft-key to return to the Main Menu.
5. Touch the X soft-key to exit from the Auto-On Comfort & Remote Start Menu and Settings.

Engine Off Options

1. Press the Settings soft-key on the bottom of the screen.
2. Press the Engine Off Options soft-key to enter the Menu.
3. The options available are:
 - Easy Exit Seat
 - Engine Off Power Delay
 - Headlight Off Delay
4. Press the + or – soft-keys to adjust the time in seconds.
5. Touch the check mark or empty box to change a selection.

NOTE:

The check-mark indicates the current selection is active.



6. Touch the left arrow soft-key to return to the Main Menu.
7. Touch the X soft-key to exit from the Engine Off Options Menu and Settings.

Audio

1. Press the Settings soft-key on the bottom of the screen.
2. Press the Audio soft-key to enter the audio setting Menu.

Refer to Audio in Radio Mode section for adjusting the audio settings.

Phone/Bluetooth

1. Press the Settings soft-key on the bottom of the screen.
2. Press the Phone/Bluetooth soft-key to enter the Menu.

Refer to MTC System Phone section in this manual for the Phone/Bluetooth settings.

Radio Setup

1. Press the Settings soft-key on the bottom of the screen.
2. Press the Radio Setup soft-key to enter the Menu:
 - FM
 - DAB
3. Press the FM soft-key to enter the options available:
 - Traffic Announcement
 - Alternative Frequency
 - Regional
4. Press the DAB soft-key to enter the option available:
 - Alternative Frequency
5. Touch the check mark or empty box to change a selection.

NOTE:

The check-mark indicates the current selection is active.

6. Touch the left arrow soft-key to return to the Main Menu.
7. Touch the X soft-key to exit from the Radio Setup Menu and Settings.

SIRIUS Setup (where available)

1. Press the Settings soft-key on the bottom of the screen.
2. Press the SIRIUS Setup soft-key to enter the following Menu.

Channel Skip

SIRIUS can be programmed to designate a group of channels that are the most desirable to listen to or to exclude undesirable channels while scanning. To make your selection, touch the Channel Skip soft-key, select the channels you would like to skip followed by pressing the ◀ arrow soft-key.

Subscription Information

New vehicle purchasers or lessees will receive a free limited time subscription to SIRIUS Satellite Radio with your radio. Following the expiration of the free services, it will be necessary to access the information on the Subscription Information screen in order to re-subscribe.

Touch the Subscription Info soft-key to access the Subscription Information screen.

Write down the SIRIUS ID numbers for your receiver. To reactivate your



service, either call the number listed on the screen or visit the provider online.

NOTE:

SIRIUS Travel Link is a separate subscription.



10 – Index



Antenna	Gracenote	9	About GPS Satellite Signals	63
GPS Navigation Antenna		9	Custom POI (Points Of Interest)	64
Satellite Radio Antenna		9	Main Menu	51
Assistance	Lights	96	Navigation System Safety	7
Emergency and Towing	MTC System Phone	3	Settings	59
Assistance	Bluetooth Communication link	89	Updating the Map Data	63
Safety and Driving Assistance	Emergency and Towing		Using the Tools	58
Audio	Assistance	82	Viewing the map pages	56
Auto-On Comfort and Remote Start	Hands-Free Calling	90	Voice Commands	61
Aux Mode	Managing Text Messages with MTC		Where To? (Finding Location)	52
	System	91		
Bluetooth	MTC System Voice Command		Pair a Bluetooth Streaming Audio	
Bluetooth Communication link	Button	77	Device	79
Pair a Bluetooth Streaming Audio	MTC System Phone Button	77	Pair (Link) MTC System Phone to a	
Device	Pair a Bluetooth Streaming Audio		Mobile Phone	78
Phone/Bluetooth	Device	79	Phone/Bluetooth	98
Bluetooth Mode	Pair (Link) MTC System Phone to a		Phone Call Features	82
	Mobile Phone	78	Player Mode	3
Care, System	Phonebook Download - Automatic		Aux Mode	36
Climate Mode	Phonebook Transfer From Mobile		Bluetooth Mode	37
Front Climate	Phone	81	Disc Mode	30
Rear Climate	Phone Call Features	82	SD Card Mode	34
Clock	Screen Activated Features	76	USB/iPod Mode	32
Controls Mode	Sms Function	88		
	Transfer Call to and from Mobile		Radio Mode	3
Devices, Controls, Buttons	Phone	87	Audio	24
Doors and Locks	Voice Command Mode	87	MTC System Voice Command	
	Voice Mail Call	85	Button	25
Emergency and Towing Assistance	MTC System Voice Command		Radio Functions	18
Engine Off Options	Button	25	Radio Setup	98
	MTC System Phone Button	77	Setting Preset	20
GPS Satellite Signals	Navigation Mode	3	Voice Commands	27



Safety and Driving Assistance	.96	Voice Commands	.27
Safety Guidelines	.6	Voice Mail Call	.85
CD/DVD Drive	.9		
GPS Navigation Antenna	.9		
Gracenote	.9		
Navigation System Safety	.7		
Other Electronic Devices	.9		
Satellite Radio Antenna	.9		
System Care	.8		
SD Card Mode	.34		
Settings	.3		
Audio	.98		
Auto-On Comfort and Remote			
Start	.97		
Clock	.95		
Doors and Locks	.97		
Engine Off Options	.97		
Lights	.96		
Phone/Bluetooth	.98		
Radio Setup	.98		
Safety and Driving Assistance . . .	.96		
Settings Main Menu	.94		
SIRIUS Setup (where available) . .	.98		
SiriusXM™ Satellite Radio Mode . . .	.21		
SiriusXM™ Travel Link (where			
available)	.64		
Sms/Text Messages			
Managing Text Messages with MTC			
System	.91		
Sms Function	.88		
USB/iPod Mode	.32		

Maserati S.p.A. & Maserati North America, Inc. reserve the right to make changes and/or modifications to the content and all technical information and specifications without prior notification.

Therefore, the user is not entitled to any claims based on the contents (texts, data, illustrations, explanations and regulations) in this manual, which are based on the data known at the time of going to print.

© 2013. Maserati S.p.A. All rights reserved.

Publication 1st Edition - 04/2013

This document may not be reproduced, printed or translated, even partially, without the written consent of MASERATI S.p.A.



WWW.MASERATI.COM



MASERATI SPA · VIALE CIRO MENOTTI, 322 · I-41121 MODENA