

Fridge - Quick Settings

OPTIMIZED SETTINGS & TIPS

■ Ideal temperature:	Fridge +4 C, Freezer -18 C.
■ Super Cool / Power Cool:	Use after grocery shopping to quickly cool new food.
■ Super Freeze / Power Freeze:	To quickly freeze fresh food and preserve quality.
■ Vacation / Holiday Mode:	Activate when you're away. The fridge uses less power, the freezer runs normally.
■ Delicate foods:	Bottom shelf (the coldest spot) for meat and fish.
■ Door alarm:	If it beeps, check that it's closed properly or hasn't been open too long.