



Arduino_0		Arduino_48
Arduino_1	\rightarrow	Arduino_50
Arduino_2	\rightarrow	Arduino_52
Arduino_3	\rightarrow	Arduino_5

OBUF4





Replace DUO_SW1 with a Pulldown if you want the ATmega32U4 chip to run when this circuit is loaded. Replace DUO_SW1 with a Pullup if you want to disable the ATmega32U4 chip when this circuit is loaded.

Papilio DUO Reset