



Gnd**D**─

Ctrl1D Ctrl2
Ctrl2D Ctrl2
Ctrl3D Ctrl3
Ctrl4D Ctrl4
Ctrl5D Ctrl5
Ctrl6D Ctrl6
Ctrl7D Ctrl7
Ctrl8D Ctrl8
Ctrl9D Ctrl9
Ctrl1D Ctrl10
Ctrl1D Ctrl11
Ctrl11D Ctrl11
Ctrl12D Ctrl12
Ctrl12D Ctrl12
Ctrl13D Ctrl13
Ctrl14D Ctrl14
Ctrl15D Ctrl15
Ctrl16D Ctrl16
Ctrl16D Ctrl16
Ctrl16D Ctrl16
Ctrl17D Ctrl17

Drv1a ☐ Drv1a
Drv2a ☐ Drv2a
Drv3a ☐ Drv3a
Drv4a ☐ Drv4a
Drv5a ☐ Drv5a
Drv6a ☐ Drv7a
Drv8a ☐ Drv7a
Drv8a ☐ Drv9a
Drv10a ☐ Drv10a
Drv11a ☐ Drv11a
Drv12a ☐ Drv13a
Drv15a ☐ Drv15a
Drv16a ☐ Drv15a

 Drv1bQ
 Drv1b

 Drv2bQ
 Drv2b

 Drv3bQ
 Drv3b

 Drv4bQ
 Drv4b

 Drv4bQ
 Drv5b

 Drv6bQ
 Drv6b

 Drv7bQ
 Drv7b

 Drv8bQ
 Drv8b

 Drv9bQ
 Drv9b

 Drv10bQ
 Drv10b

 Drv11bQ
 Drv11b

 Drv12bQ
 Drv11b

 Drv12bQ
 Drv13b

 Drv14bQ
 Drv13b

 Drv15bQ
 Drv15b

 Drv15bQ
 Drv15b

 Drv16bQ
 Drv16b

https://github.com/GadgetReboot/Low_Side_Switch https://www.youtube.com/gadgetreboot

Gadget Reboot

Sheet: /Driver 1-16/ File: Driver.sch

Title: Low Side Drivers

 Size: A3
 Date: 2022-08-30
 Rev: 1.0

 KiCad E.D.A. kicad (5.1.2-1)-1
 Id: 2/4



