

Field Plumber FAQ - AI Agent Knowledge Base

Demo question-and-answer content | Ref: DEMO-FAQ-001

Important: This document is fictional material created for an AI-agent demonstration. Values and procedures must be validated against the actual appliance manual, installation standard and site conditions before field use.

1. Common questions

Field question	Demo answer
What pressure should I see?	First confirm the model and whether this is a sealed heating circuit. In this demo example, roughly 1.0-1.5 bar cold is normal, but use the product-specific manual for the approved range.
Pressure is fine cold but nearly 3 bar hot. Why?	That large rise makes expansion control a priority check: expansion vessel charge/connection/size, filling valve passing, and relief-valve discharge. Do not set vessel charge from a generic value.
I topped it up yesterday and it is low again.	Treat this as recurring water loss until proven otherwise. Check visible leaks, radiator valves, relief discharge, automatic vents and the cold/hot pressure pattern.
Upstairs radiators are cold.	Check system pressure/static head, air, valve positions, circulation and balancing. Ask whether the issue affects one emitter, one zone or the entire upper floor.
Boiler fires but house warms slowly.	Check demand, flow/return temperatures, circulation, pump/valves, emitter condition and whether controls are limiting operation.
Can I just keep topping it up?	Repeated topping-up can hide a leak or expansion problem and introduces fresh oxygenated water. Find the reason for pressure loss.
What should I send support?	Model/serial, cold pressure, hot pressure, flow/return temperatures, fault code, photos of gauge/discharge where safe, recent work, and what checks have already been completed.

2. Recommended AI-agent behaviour

The agent should ask short diagnostic questions, cite the retrieved document, distinguish heating-system pressure from domestic mains pressure, avoid unsupported model-specific values, and escalate safety-critical or ambiguous situations.