GeekMagic® SmallTV-Ultra User Manual V9.0.30

1. Basic Information

Product Size: 35mm x 39mm x 45mm

Screen: 1.5 inch 240x240px TFT IPS display

Power supply: 5V DC with 1A and up. Voltage should not over 5V which may cause damage.


2. How to set it up?

Upon startup, the device will attempt to connect to the network based on the recorded WiFi information. If the connection fails, it will enter AP (Access Point) mode and activate its own hotspot named "GIFTV." If the connection is successful, it will enter STA (Station) mode and disable its own hotspot.

When you first power on the device, it will be in AP mode. In this state, use your smartphone to connect to the WiFi network named "GIFTV" (some phones may show a "no internet" warning; please ignore this). Then, open a web browser and visit the console address http://192.168.4.1. This will take you to the web-based control panel for configuration.

Tips: If you can't visit that IP after all the correct steps, please try close your mobile data first, some smart phone will block the WiFi if it find the WiFi is not internet available.

First, click on "Network," and select "Scan" to search for nearby WiFi hotspots. Choose your WiFi network and enter the password to save it. The device will then restart to establish a WiFi connection. If the connection is successful, the IP address after connecting will be displayed on the screen. You can make a note of this address, but it's not necessary as it will be shown every time after successful connection upon startup.




3. How to set it up after wifi is connected?

This is the display after wifi is successfully connected, a new IP address is displayed here, then you can use this new IP to access the web console again, the hotspot "GIFTV" is disappered.



Next, use your smartphone or computer to connect to the same WiFi network(Your own WiFi network). Once connected, open a web browser and enter the new IP address. This will take you back to the configuration page, where you can make additional personalized settings, here is 192.168.1.103 for example, you need to find out your own IP.



Video here for your reference.

3. How to update weather info?

3.1 Method 1

Input city name in English directly, for example, the city Seoul, just type in "Seoul" is OK, or "Seoul, KR" is OK too, be careful about the space characters between.


3.2 Method 2

If the city name is not a unique one, that is there are more than one city with the same name, you may need to find the correct city code.

Here are the steps:


After successfully setting up your device for internet connection, you can access the Weather page on the control panel. To do this, you will need to find your city code. You can search for it here:

Step 1: Open the following URL:https://openweathermap.org/find




Step 2: Enter your city name, for example, "Seoul," and click on the "Search" button.


Step 3: In the search results, click on your city's name. This will open a new webpage link.



Step 4: Locate your city code. It should be a sequence of pure numbers found at the end of the URL address.



Step 5: On the Weather page, input your city code, which in this case is "1835848," and then click "Save." The weather information should update immediately.



If you encounter any issues, please feel free to contact our online customer support for assistance. You can also reach out to us via email for further communication. We are here to help!

Tips:


- 1. If you use your own API key, you will have the advantage of a higher weather update frequency. When using a public key, the update frequency is fixed at once every 20 minutes. If you do not understand what is API key, please do not modify it.
- 2. Gif size in the weather screen is fixed 80x80px, large gif file not fit the area.

4. Picture Display

Instructions:

- Images support a maximum pixel size of 240x240 pixels; please ensure that your images are within this range.
- In auto display mode, JPG images can have a set interval for transitioning, while GIFs will play continuously to the next.
- If you turn off automatic playback, you can freely select which image to display.
- All images can be deleted, with approximately 1MB of space available for customization.


Tip: For creating GIFs, we recommend using the free GIF-making website, **ezgif.com**.



5. About Time

Many people set the error city location under the weather option, so the time is not correct, because the device get the time zone according to the city location.

Do not enable DST if it is not used in your country or erea. There may be 1 hour ahead if you enabled.



6. Others

Your advices are highly welcomed, feel free to contact GeekMagic@163.com. Good luck and happy everyday!!!

7. Trouble shooting & FAQ:

- 1) The screen flickering? Or could not power on?
- A: Try change another usb cable or power adapter, the related to unstable power supply.
- A: Type-c to Type-c USB are not supported, it's better to use our cable instead.

- 2) Can't connect to my router?
- A: Make sure it's 2.4G hotspot, double check the SSID and the password is correct. If it's a WIFI6 2.4G network, especially it's ASUS WIFI6 routers, there maybe compatible issues.
- Method 1, close the 802.11ax options which will close WIFI6 features.
- Method 2, create a guest 2.4G hotspot without 802.11ax options, and connect the gadget to this AP.

Method 3, contact online help from us.

- B: Check your WiFi name and password is saved correctly on the webpage, the webpage will read the saved info after loaded.
- C: Make sure the 802.11 b/g mode is enabled in your router's WiFi settings.
- D: Try different power and cable, this sometimes works.
- E: Reboot your router, sometimes works.
- F: Try connect it to your phone's hotspot use the Manually input method. (Make sure you have set your phone's hotspot to 2.4G channel only, and if is an iPhone, please turn on the Max compatibility switch in the hotspot settings)
- G: If it is a company WiFi with authentication which need account info will fail, please change to other kind of WiFi.

We are 100% confident that the WiFi connection will be successful, please contact us if you need help, ask directly from the support mail: GeekMagic@163.com, developers will help.

- 3) Where and how to update firmware?
- A: Please search "GeekMagic SmallTV-Ultra" on Google. You can find the github link, the firmware will be updated there, make sure your model is "SmallTV-Ultra".
- 4) How to reset, reconfiure?
- A: When you plug in the power supply and the progress bar is displayed on the screen, unplug the power immediately. Repeat this twice, and the third time it will turn on its own WIFI. You can reconnect to its WIFI hotspot and enter the web page to reconfigure.
- 5) Can't find WiFi hotspot "GIF.TV "?
- A: If you have not set it up, please try to change anther power adapter and cable. If you already set it up, and the connect to your router is success, the hostspot "GIF.TV" will be closed.
- 6) How to crop or resize gif files?
- A: ezgif.com is highly recommended, upload your own gif files, crop it and then resize it, make sure it will fit into 80x80px or 240x240px for full screen display.

7) Larger ones?

New product will be released, keep following.