

nRF Connect SDK - 2.9.2

Contents

Zigbee error handler 3

1. Zigbee error handler

Note

Support for Zigbee R22 has been deprecated in nRF Connect SDK v2.8.0 and it will be removed in one of the future releases, following the [deprecation policy](#). As a result, the nRF52833, nRF52840, and nRF5340 SoCs are not recommended for new Zigbee designs. Experimental support for Zigbee R23 is available for the nRF54L Series as an [nRF Connect SDK Add-on](#).

The Zigbee error handler library provides a set of macros that can be used to assert on nrfxlib's ZBOSS Zigbee stack API return codes. The assertion is implemented by a call to the `zb_osif_abort()` function. Additionally, you can enable the library to log the error code name before the assertion.

Functions that resolve the numeric error code to printable string are defined in the `zb_error_to_string.c` source file in nrfxlib.

Configuration

To use this library, include its header in your application and pass the error code that should be checked using its macros.

Additionally, if you want the error code to be printed to log, enable the `CONFIG_LOG` and `CONFIG_ZBOSS_ERROR_PRINT_TO_LOG` Kconfig options. The `CONFIG_ZBOSS_ERROR_PRINT_TO_LOG` option automatically enables the `CONFIG_ZIGBEE_ERROR_TO_STRING_ENABLED` Kconfig option, which obtains the ZBOSS error code name.

The library also provides a macro for checking the value returned by the `bdb_start_top_level_commissioning()` function.

API documentation

Header file: `include/zigbee/zigbee_error_handler.h`

Source file: `../nrfxlib/zboss/src/zb_error/zb_error_to_string.c`

ZBOSS error handling utilities