

99 Washington Street Melrose, MA 02176 Phone 781-665-1400 Toll Free 1-800-517-8431









Φ40mm

CLAMP ON LEAK HITESTER 3283-20

True RMS

Analyze breaker operation

Activate the FILTER mode to check the current value with the same frequency level as a breaker's operational frequency band, without any effects from the high-frequency components of a switching power source or inverter equipment.







off an exceedingly analysis of breake high value including operation can be high-frequency performed components is displayed

Record the maximum current

By specifying MAX in the REC (recording) mode, the current value on the display will be updated every time a maximum value is measured. You can then check the transformer capacity, and record the maximum load current.





Double insulation for greater safety

The clamp jaw is double-insulated to prevent shocks even if the metallic core tip comes in contact with metal objects. Safely clamp a bus har to measure its current.







CLAMP ON LEAK HITESTER 3283-20 (All includes CARRYING CASE 9399, HAND STRAP)

Record CT 5A or 1A rated output current

Precisely record the current of the secondary side of CTs rated 5A or 1A and below. With ordinary clamp-on meters, large measurement errors result from inputs of only a few amps, and values are displayed inaccurately or simply suppressed to "OA".





Currents of 5A 1A and below accurately measured and displayed

Record the average current

Specify AVE in the REC (recording) mode to constantly calculate the average current, and to update the current value on the display. This is useful for recording fluctuating current values.





Specifications

(Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year)

Function	Range	Accuracy	Notes
AC current (AC A)	10 00 mA	±1 0% rdg ±5 dgt (45 to 66 Hz) ±2 0% rdg ±5 dgt (40 to 45 Hz 66 to 2 kHz)	Maximum allowable current 20 Arms cont.
	100 0 mA		
	1 000 A		
	10 00 A		
	200 O A	±1 5% rdg ±5 dgt (45 to 66 Hz) ±2 0% rdg ±5 dgt (40 to 45Hz 66 to 2kHz)	Maximum allowable current 200 Arms cont
Frequency (Hz)	100 0 Hz	±0 3% rdg ±1 dgt	Accuracy range 30 0 to 99 9Hz 95 to 1000Hz
	1000 Hz	±10% rdg ±1 dgt	

AC current measurement accuracy range is 10% to 100% (5% to 100% in 200 A range). Accuracy is given for the filter OFF condition.

/ WARNING

Inspect the unit and check that it is operating correctly before use. When carrying out measurement on live lines, wear proper protective grar, insulating rubber gloves, insulating rubber boots and safety belines, and use extreme caution to avoid electric shock accidents.

⚠ DANGER



In order to prevent short circuits and injury use the clamp product on electrical currents with a voltage less than the maximum operation circuit voltage.

In order to prevent short-circuits and injury when the clamp core top is open do not use have conductive.

lote. Company names and Product names appearing in this catalog are trademarks or registered trademarks of various companies.

DISTRIBUTED BY



99 Washington Street Melrose, MA 02176 Phone 781-665-1400 Toll Free 1-800-517-8431





