



# TinyFan Options



## RPM Signal is Shifted to 5v:

This means, you can connect here Neopixels without the need for a resistor! (Its shifted both ways, means this pin can be used as Input or Output)



AUX2 AUX3

**GPIO** 

V+

GND or GPIO


AUX1

## The middle Pin provides Power!

This means, if you need to connect a 5v Fan. you can inject 5v with a Dupont connector here! (Make sure your PSU's shares GND!)



## 5v injection Example:



#### In GPIO Mode:

- 2-Wire Fans, on V+ and PGND
- RGB Leds, on V+ and PGND
- 3-Wire Fans with RPM (RPM/V+/PGND)
- Neopixels with a 100-Ohm resistor on the GPIO Pin
- Whatever your imagination allows!



- 3-Wire Fans with PWM-Signal, (PWM/V+/GND)
- Uncontrollable 3-Wire RPM Fans, (RPM/V+/GND)
- Neopixels with a 100-Ohm resistor on the GPIO Pin
- Thermistors on GPIO+GND
- G-Code Buttons on GPIO+GND
- Whatever your imagination allows!



G1 G2 G3 G4 G5 G6

- Additional Thermistors
- Additional G-Code Buttons
- Additional Neupixel Ports (requires a 100 Ohm Resistor)
- Whatever your imagination allows!