

This document lists the compatible batteries with all GoodWe storage inverters, consisting in 4 system types:

- 1) Low-voltage energy storage systems
- 2) High-voltage energy storage systems
- 3) Commercial and industrial energy storage systems
- 4) High-voltage Energy Storage Systems (for U.S only).

Only batteries listed in this document are approved for connection to GoodWe storage inverters according to GoodWe Limited Warranty.

## 1) Low-voltage Energy Storage Systems

Battery	Battery	Battery		In	verter Ser	ies	
Brand	Series	Model	ES	EM	SBP	ES G2	SBP G
	SECU-A	SECU-A5.4L	•	•	•	•	•
GOODWE	Lynx Home U <sup>*1</sup>	LX U5.4-L	•	•	•	•	•
S/EM/SBP/BP:	,				1		
	ersions 11 and above are required for compa		EC	EM	CDD	EC 02	CDD C
Battery Brand	Battery Series  Battery-Box Pro Series*1	Battery Model	ES	EIVI	SBP	ES G2	SBP G2
	Battery-Box Res Series 1	-	•	•	•	•	•
BYD	Battery-Box LV Series <sup>2</sup>	-	•	•	•	•	•
סוט	Battery-Box Premium LVL*2	LVL 15.4	•	•	•	•	•
	Battery-Box Premium LVS Series <sup>2</sup>	LVL 15.4	•	•	•	•	•
S/EM/SBP/BP:	Ballery-Box Premium LVS Series	-					
1. ARM firmware v	ersions 00 and above are required for compa ersions 07 and above are required for compa						
Battery Brand	Battery Series	Battery Model	ES	EM	SBP	ES G2	SBP G2
	-	RESU 3.3*1	•	•		•	•
		RESU 6.5*1	•	•	•	•	•
	DECLLIVE :	RESU 10 <sup>*1</sup>	•	•	•	•	•
LG	RESU LV Series	RESU 12 <sup>*2</sup>	•	•	•	•	•
		RESU 13 <sup>*2</sup>	•	•	•	•	•
		RESU 6.4 EX <sup>*1</sup>	•	•	•	•	•
	ersions 00 and above are required for compa ersions 07 and above are required for compa Battery Series		ES	EM	SBP	ES G2	SBP G2
attery Brana	US2000 Series <sup>*1</sup>	US2000	•		•	0	001 02
	US3000 Series*2	US3000	•	•	•	•	•
	US2000 Series*1	US2000C	•	•	•	•	•
PYLON	US3000C Series*2	US3000C	•	•	•	•	•
I ILON	Force L1 Series <sup>2</sup>	Force-L1	•	•	•	•	•
	Force L2 Series <sup>2</sup>	Force-L2	•	•	•	•	•
	US5000 Series*3	US5000		_		•	•
<ol><li>ARM firmware v</li></ol>	ersions 00 and above are required for comparersions 07 and above are required for comparersions 00 and above 00 and 00 a	atibility. atibility. atibility.				-	
Battery Brand	Battery Series	Battery Model	ES	EM	SBP	ES G2	SBP G2
		DYNESS-LV x1	•	•	•		
	DYNESS-LV Series <sup>*1</sup>	DYNESS-LV x2	•	•	•		
	DINESS-LV SEIRS	DYNESS-LV x3	•	•	•		
DYNESS		DYNESS-LV x4	•	•	•		
DYNESS		POWERBOX F-2.5	•	•	•		
DYNESS	DOWEDBOY E Sorios <sup>*1</sup>	POWERBOX F-2.5 POWERBOX F-5.0	•	•	•		
DYNESS	POWERBOX F Series <sup>*1</sup>						

POWERBOX F-10.0

<sup>\*1.</sup> ARM firmware versions 07 and above are required for compatibility.



# 1) Low-voltage Energy Storage Systems

Battery	Battery	Battery Model	Inverter Series					
Brand	Series		ES	EM	SBP			
	LBS051100A Series <sup>*1</sup>	LBS051100A-A02	•					
OLOID		LBS051100A-A03	•					
OLOID	LBS051200A Series <sup>*1</sup>	LBS051200A-A02	•					
		LBS051200A-A03	•					

ES:
\*1. ARM firmware versions 12 and above are required for compatibility.

Battery Brand	Battery Series	Battery Model	ES	EM	SBP
	,	Soluna 4K Pack	•	•	•
Soluna	LV(48V) Battery Series	Soluna 5K Pack	•	•	•
		Soluna EOS 5K Pack	•	•	•
Battery Brand	Battery Series	Battery Model	ES	EM	SBP
	Smile5-BAT Series	SMILE5-BAT*2	•	•	•
		Smile-BAT-10.1P <sup>+2</sup>	•	•	•
A1 D11A*1	Smile-BAT Series	Smile-BAT-10.3P <sup>*2</sup>	•	•	•
ALPHA*1		Smile-BAT-13.3P <sup>*3</sup>	•	•	•
	M48112-P Series	M48112-P*3	•	•	•
	M48100-P Series	M48100-P*3	•	•	•

## ES/EM/SBP/BP:

- \*1. CAN communication line sequence of ALPHA-ESS battery does not match GoodWe inverters. A matching solution provided by ALPHA-ESS is required.

  \*2. ARM firmware versions 10 and above are required for compatibility.

  \*3. ARM firmware versions 11 and above are required for compatibility.

Battery Brand	Battery Series	Battery Model	ES	ЕМ	SBP					
		Firefly-3.6K	•	•	•					
Tecloman		Firefly-7.2K	•	•	•					
	Firefly Series <sup>*1</sup>	Firefly-10.8K	•	•	•					
		Firefly-14.4K	•	•	•					
		Firefly-18.0K	•	•	•					
		Firefly-21.6K	•	•	•					
		Firefly-25.2K	•	•	•					
ES/EM/SBP:										

\*1. ARM firmware versions 12 and above are required for compatibility.

Battery Brand	Battery Series	Battery Model	ES	ЕМ	SBP
UZENERGY	L051100-A Series	L051100-A <sup>*1</sup>	•	•	•

\*1. ARM firmware versions 12 and above are required for compatibility.



### 2) High-voltage Energy Storage Systems

Battery	Battery Series	Battery Model	Inverter Series					
Brand			ET (5-10kW)*	EH	ВТ	вн	ЕНВ	ET (15-30kW)
		LX F6.6-H	•	•	•	•	•	•
COODWE	Lynx Home F <sup>*1</sup>	LX F9.8-H	•	•	•	•	•	•
GOODWE	Lynx Home F <sup>*1</sup> Lynx Home F PLUS+ <sup>*1</sup>	LX F13.1-H	•	•	•	•	•	•
		LX F16.4-H	•		•			•

\*. Including ET Series: ET PLUS+, ET PLUS+ (16A) ET/EH/BT/BH/EHB:

\*1. ARM firmware versions 19 and above are required for compatibility.

Battery Brand	Battery Series	Battery Model	ET (5-10kW)*	EH	ВТ	ВН	ЕНВ	ET (15-30kW)
	Battery-Box HV Series <sup>*1</sup>	-	•	•	•	•		
		HVM 8.3		•		•	•	
		HVM 11.0	•	•	•	•	•	•
	Dattaria Dan Draminia IIV/M²2	HVM 13.8	•	•	•	•	•	•
	Battery-Box Premium HVM <sup>*2</sup>	HVM 16.6	•	•	•	•	•	•
BYD		HVM 19.3	•	•	•	•	•	•
		HVM 22.1	•	•	•	•	•	•
		HVS 5.1	•	•	•	•	•	•
	D-11 D D 11/0*2	HVS 7.7	•	•	•	•	•	•
	Battery-Box Premium HVS <sup>*2</sup>	HVS 10.2	•	•	•	•	•	•
		HVS 12.8	•		•			•

<sup>\*.</sup> Including ET Series: ET PLUS+, ET PLUS+ (16A)

ET/EH/BT/BH/EHB:

\*2. ARM firmware versions 02 and above are required for compatibility.

BYD CAN communication line PIN1/2 corresponds to inverter CAN communication line PIN4/5.

\*2. HVS batteries combined with ET15~30K series cannot reach the maximum charging and discharging power of the inverter.

<b>Battery Brand</b>	Battery Series	Battery Model	ET (5-10kW)*	EH	ВТ	ВН	EHB	ET (15-30kW)
	RESU FLEX Series 1	FLEX 8.6	•					
		FLEX 12.9	•					
LG		FLEX 17.2	•					
LG	RESU Type-R Series	RESU10H_Type-R					•	
	RESU Prime Series <sup>*2</sup>	RESU10H Prime					•	
		RESU16H Prime					•	

<sup>\*.</sup> Including ET Series: ET PLUS+, ET PLUS+ (16A)

ET/EH/BT/BH/EHB:

<sup>\*1.</sup> ARM firmware versions 07 and above are required for compatibility.
\*2. ARM firmware versions 11 and above are required for compatibility.

<sup>\*1.</sup> Only compatible with ET PLUS+ Series. ARM firmware versions 23 and above are required for compatibility.
\*2. ARM firmware versions 20 and above and DSP versions 02 and above are required for compatibility.



### 2) High-voltage Energy Storage Systems

Battery	Battery	Battery	Inverter Series				
Brand	Series	Model	ET (5-10kW)*	EH	ВТ	ВН	
	Powercube H1 Series	POWERCUBE-H1-48 <sup>*1</sup>	•	•	•	•	
PYLON	Force H1 Series*2	Force-H1	•	•	•	•	
	Force H2 Series*2	Force-H2	•	•	•	•	

<sup>\*.</sup> Including ET Series: ET PLUS+, ET PLUS+ (16A)

#### ET/EH/BT/BH/EHB:

<sup>\*2.</sup> ARM firmware versions 14 and above are required for compatibility. Please note that the nominal voltage of FORCE-H1 Series must be within the Battery Voltage Range of GoodWe inverters. At least 5 FORCE-H1 battery modules for ET.

<b>Battery Brand</b>	Battery Series	Battery Model	ET (5-10kW)*	EH	BT	ВН
DYNESS	Tower Series <sup>*1</sup>	Tower T7		•		•
		Tower T10	•	•	•	•
		Tower T14	•	•	•	•
		Tower T17	•		•	

<sup>\*.</sup> Including ET Series: ET PLUS+, ET PLUS+ (16A)

#### ET/EH/BT/BH/EHB:

<sup>\*1.</sup> ARM firmware versions 10 and above are required for compatibility.

<b>Battery Brand</b>	Battery Series	Battery Model	ET (5-10kW)*	EH	BT	ВН
Soluna	HV Battery Series <sup>*1</sup>	Soluna 7K Pack HV		•		•
		Soluna 10K Pack HV	•	•	•	•
		Soluna 15K Pack HV	•		•	

<sup>\*.</sup> Including ET Series: ET PLUS+, ET PLUS+ (16A)

#### ET/EH/BT/BH/EHB:

<sup>\*1.</sup> ARM firmware versions 10 and above are required for compatibility.

<b>Battery Brand</b>	Battery Series	Battery Model	ET (5-10kW)*	EH	BT	ВН
iPotisEdge		Mint-JKE5		•		•
	Mint-JKE <sup>*1</sup>	Mint-JKE10		•		•
	IVIIIII-JKE	Mint-JKE15	•	•	•	•
		Mint-JKE20	•	•	•	•

<sup>\*.</sup> Including ET Series: ET PLUS+, ET PLUS+ (16A)

#### ET/EH/BT/BH/EHB:

<sup>\*1.</sup> ARM firmware versions 12 and above are required for compatibility.

Battery Brand	Battery Series	Battery Model	ET (5-10kW)*	EH	BT	ВН
	WTS Power-CORE 1.0 <sup>*1</sup>	WTS Power-CORE 1.0-5.5				
		WTS Power-CORE 1.0-8.3	•		•	
	WTS Power-CORE 1.0	WTS Power-CORE 1.0-11.0	•		•	
		WTS Power-CORE 1.0-13.8	•		•	
W/TC		WTS Energy-CORE 1.0-9.6				
WTS		WTS Energy-CORE 1.0-12.8	•		•	
	WTS Energy-CORE 1.0*1	WTS Energy-CORE 1.0-16.0	6.0		•	
	W15 Ellergy-CORE 1.0	WTS Energy-CORE 1.0-19.2	•		•	
		WTS Energy-CORE 1.0-22.4	•		•	
	I	WTS Energy-CORE 1.0-25.6	•		•	

#### ET/BT:

### 3) Commercial and Industrial Energy Storage Systems

Datton, Brand	Bottom, Covins	Pottony Model	Inverter Series		
Battery Brand	Battery Series	Battery Model	ETC	ВТС	
GOODWE		LX C 101-10	•	•	
	Lynx C series <sup>*1</sup>	LX C 120-10	•	•	
	Lynx C series	LX C 138-10	•	•	
		LX C 156-10	•	•	

#### ETC 50K/BTC 50K:

<sup>\*1.</sup> ARM firmware versions 07 and above are required for compatibility. Please note that the nominal voltage of POWERCUBE-H1-48 Series must be within the Battery Voltage Range of GoodWe inverters. Maximum 8 units for EH/BH, and 11 units for ET/BT.

<sup>\*1.</sup> ARM firmware versions 14 and above are required for compatibility.

<sup>\*1:</sup> EMS firmware versions 02 and above are required for compatibility.

ETC 100K:

<sup>\*1.</sup> EMS firmware versions 00 and above are required for compatibility.



## 4) High-voltage Energy Storage Systems (for U.S only).

Pottory Prond	rand Battery Series	Battery Model	Inverter Series			
Battery Brand			A-ES	A-BP	ES-US20	SBP-US20
	SECU-S <sup>*1</sup>	SECU-S13	•	•		
		SECU-S15	•	•		
		SECU-S18	•	•		
GoodWe		SECU-S20	A-ES A-BP ES			
Goodyve		LX F9.6-30	•	•	•	•
	Lynx Home FH Series US <sup>2</sup>	LX F12.8-30	•	•	•	•
	Lyrix Horrie FH Series 03	LX F16.0-30	•	•	•	•
		LX F19.2-30	•	•	•	•

#### A-ES/A-BP:

\*1. ARM firmware versions 14 and above are required for compatibility.

#### ES-US20/SBP-US20:

- \*2. For ES-US20/SBP-US20, ARM firmware versions 03 or above are required for compatibility with Lynx Home FH Series US.
- \*2. ARM firmware versions 24 and above and DSP versions 07 and above are required for compatibility.

Battery Brand	Battery Series	Battery Model	A-ES	A-BP	ES-US20	SBP-US20
		HVL 12.0	•	•		
		HVL 16.0	•	•		
BYD	Battery-Box Premium HVL*1	HVL 20.0	•	•		
סוט	Ballery-Box Freinium HVL	HVL 24.0	•	•		
		HVL 28.0	• •	•		
		HVL 32.0	•	•		

A-ES/A-BP:
\*1. ARM firmware versions 11 and above are required for compatibility.

Battery Brand	Battery Series	Battery Model	A-ES	A-BP	ES-US20	SBP-US20
OLOID	LBS102100A Series <sup>*1</sup>	LBS102100A	•	•		
	LBS153100A Series <sup>*1</sup>	LBS153100A	•	•		
	LBS205100A Series <sup>*1</sup>	LBS205100A	•	•		

\*1. ARM firmware versions 14 and above are required for compatibility.

		7				
Battery Brand	Battery Series	Battery Model	A-ES	A-BP	ES-US20	SBP-US20
	HV Battery Series*1*2	Soluna 7K Pack HV	•	•		
Soluna		Soluna 10K Pack HV	•	•		
		Soluna 15K Pack HV	•	•		

#### A-ES/A-BP:

- \*1. ARM firmware versions 10 and above are required for compatibility.
- \*2. Soluna HV does not have UL9540 certificate.

Battery Brand	Battery Series	Battery Model	A-ES	A-BP	ES-US20	SBP-US20
LG	RESU Type-R Series*2*3	RESU10H_Type-R	•	•		
	RESU Prime Series*1*4	RESU10H Prime	•	•		•
	RESU FIIIIle Selles	RESU16H Prime	•	•		•

#### A-ES/A-BP:

- \*1. ARM firmware versions 20 and above and DSP versions 05 and above are required for compatibility.
- \*2. When A-BP is compatible with LG RESU HV Series, the micro-grid applications are not supported.
- \*3. The compatibility of A-ES/A-BP with LG RESU10H Type-R is stated as follows: 1) Connection of RESU10H Type-R batteries in parallel is not supported.
- 2) For first inverter operation with LG battery, the inverter must be powered by the grid for the LG battery to be activated
- 3) LG RESU10H Type-R battery Max discharge power is 5kW. Please ensure backup load peak power does not exceed 5kVA in backup mode. Loads with large inrush current (such as inductive loads including motors) may lead to output failure on backup side.
- 4) Depending on real-time battery condition, such as SOC, battery temperature etc, the battery output power may not be able to support backup load, which could lead to system failure. If this occurs, both battery and backup supply will cease. Power will resume if there is solar power available.
- 5) LG battery needs time to switch from charge to discharge up to the preset power. Quickly switching from on-grid mode to backup mode could fail if backup load power is
- higher than the max power ramp-up the battery can sustain within a limited time.

  \*4. ARM firmware versions 05 and above and DSP versions 02 and above are required for compatibility.