

Instructions on Dismantling at end of life of Light sources and separate control gear (EU) 2019/2020

Product details

Product : Refrigerator-Freezer
Brand : SAMSUNG
Model(s) : RS6**5*****
Manufacturer: : Samsung Electronics Co., Ltd
Factory
 F1: Suzhou Samsung Electronics Co., LTD Export
 No.218, Jiepu Road, Suzhou Industrial Park, Jiangsu Province, P.R.China

- ☐ Which components are included;
 - light source(s) : Yes
 - separate control gear(s) : No

1. Tools needed

Item	How to use	Pictures
Driver	Use for assembling and disassembling of screw.	 Phillips Head Driver & Flat Head Driver

2. Dismantling LED light at end of life: Please refer to the disassembly method below.

[Precautions]

- Be sure to unplug the power cord before dismantling.
√ Electrification
- Dismantling of Lamp(s) and Control gear(s) shall be done by Samsung Service Center or Professional repairer.

Light Source 1	<table> <tr> <th data-bbox="406 165 861 215">Description</th><th data-bbox="861 165 1426 215">Figure</th></tr> <tr> <td data-bbox="406 215 861 555"> 1. Disassemble the case lamp using a flat head driver. Disassemble from the back of the case lamp. </td><td data-bbox="861 215 1426 555">  </td></tr> <tr> <td data-bbox="406 555 861 768"> 2. Remove the housing by pressing the housing connection using a flat head driver. </td><td data-bbox="861 555 1426 768">  </td></tr> </table>	Description	Figure	1. Disassemble the case lamp using a flat head driver. Disassemble from the back of the case lamp.		2. Remove the housing by pressing the housing connection using a flat head driver.	
Description	Figure						
1. Disassemble the case lamp using a flat head driver. Disassemble from the back of the case lamp.							
2. Remove the housing by pressing the housing connection using a flat head driver.							
Light Source 2	<table> <tr> <th data-bbox="406 813 861 862">Description</th><th data-bbox="861 813 1426 862">Figure</th></tr> <tr> <td data-bbox="406 862 861 1202"> 1. Disassemble the case lamp using a flat head driver. Disassemble from the back of the case lamp. </td><td data-bbox="861 862 1426 1202">  </td></tr> <tr> <td data-bbox="406 1202 861 1415"> 2. Remove the housing by pressing the housing connection using a flat head driver. </td><td data-bbox="861 1202 1426 1415">  </td></tr> </table>	Description	Figure	1. Disassemble the case lamp using a flat head driver. Disassemble from the back of the case lamp.		2. Remove the housing by pressing the housing connection using a flat head driver.	
Description	Figure						
1. Disassemble the case lamp using a flat head driver. Disassemble from the back of the case lamp.							
2. Remove the housing by pressing the housing connection using a flat head driver.							