


Connection for Control Signals



Annotations:

- Steer signal will be automatically asserted when motor driver is powered if J7 is unfitted
 Remote and Work signals may be analog 0..15V if using the ESP32 option



Cable M12-A male 4/5pole, e. g. weidmueller.com SAIL-M12G-5-1.5U (945761<u>0150</u>)

5 pole 1.5m unshielded = 0150cm

TITLE: Connecting Power Socket REV: 1.0


2021-01-09

EasyEDA Date:

Company: agopengps.discourse.group

Drawn By: GoRoNb

Sheet: 1/1




TITLE:


Connecting the Wheel Angle Sensor (WAS)

REV: 1.0

Company: agopengps.discourse.group Sheet: 1/1

Date: 2021-01-09 Drawn By: GoRoNb





Drawn By: GoRoNb

REV: 1.0

Sheet: 1/1