# 16CH DVR Quick Start Guide



1.	Packing	<b>.</b> 1
2.	Hard Disk InstallationF	13
3.	DVD-RW InstallationP	.4
4.	Front Panel ControlsP	28
5.	Rear Panel ConnectorsF	<u>.</u> 9

1

#### **PACKING**


- 1. DVR
- 2. Quick Start
- 3. IR Remote Control \*Pressed "DVR1" Button before use
- 4. Battery
- 5. CD
- 6. Hard Disk Mount
- 7. Screws
- 8. Power Cord
- 9. SATA Cord

Note: Standard shipping products do not include HDD


Step 1) Fix the HDD to rack mount with the screws as indicated.




Step 2) Remove all screws and remove the machine cover in accordance with the direction of the arrow.







Step 4) Connect the power and the SATA cables as indicated.



Note: After installation, please initialize Hard Disk before starting to record. For more detailed information, please check out User Manual "Storage Setup" for reference.



#### DVD-RW INSTALATION


## DVD-RW Installation

(Standard shipping products do not include HDD and DVD-RW)


Step 1) Remove the riser of DVR-RW.



Step 2) Fix the DVD-RW to rack mount with the screws as indicated




Step 3) Remove all screws and remove the machine cover in accordance with the direction of the arrow.



Step 4) Fix the DVD-RW rack mount with the screws into to housing as indicated



Step 5) Connect the power and the SATA cables as indicated.




FRONT PANEL CONTROLS



1.	USB 2.0	USB port
	LED Display (From left to right)	HDD : Hard disk drive
2.		Power: Power is on
		LAN: Network connected
		LOGIN: User login
		REC : Recording
		PLAY : DVR play video
3.	LOCK	On / Off Key Lock in live mode.
	Playback Keys	REW: In PLAYBACK mode, press to play rewind
4.		PLAY / PAUSE: In PLAYBACK mode, pause / resume playback
••		STOP: In PLAYBACK mode, stop playback
		FF : In PLAYBACK mode, press to play forwards
5.	Arrow keys	In SETUP mode, move the cursor up / down, reduce / increase the
<u> </u>		value of key. ·
6.	Number 0~9 \	Select the full screen channel in live mode.
	10+	Select the full screen channel in playback.
7.	IR Sensor	Input sensor for the remote control
8.	DVD Writer	Optional DVD-RW backup device. (Option)
		STATUS: In live mode, enter the System Information menu
	Function Keys	BACKUP: In LIVE mode, press to display the BACKUP menu.
		MUTE : In LIVE mode, enable/ disable live audio
		ZOOM: In LIVE mode, enlarge the display of a channel.
9.		PIP : No function
		FREEZE: In LIVE mode, display can be FREEZE.
		PTZ : Display PTZ Menu.
		ESC : In SETUP mode, Exit / Return to previous setup menu
		MENU: In LIVE mode, press to display menu.

### **REAR PANEL CONNECTORS**

## Rear Panel



• SDI IN	SDI input port for HD camera, 8 in total.
EXTERNAL I/O	External I/O port, left and right are two groups, see the following table function
AUDIO IN	For 8-way audio
CVBS OUT	BNC output port for second monitor
• IR	IR extension cable jack.
• HDMI	HDMI port
• VGA	VGA port.
AUDIO OUT	RCA output port for audio output, 2 in total.
• USB	USB port
• LAN	Network port.
• eSATA	External SATA hard disks port for expanding recording space. (depends on model)
• AC 110/220V	Socket for an AC 110/220V input.

