## Getting Started with LaserCAN (Batch 1)

#### 1. Connect Power

While your robot is powered off, wire the **V+** and **GND** to **RoboRIO 5V or 6V rails**, found on the PWM and DIO headers. Alternatively, daisy-chain power from another LaserCAN device (up to 8).

DO NOT POWER DIRECTLY FROM THE PDP/PDH

### 2. Connect CAN

Solder your Green and Yellow CAN wires to CANL and CANH on the LaserCAN respectively. Optionally, daisy chain other CAN devices (data only).

### 3. Power On


Turn your robot on. You should see the LaserCAN's yellow LED blink briefly.

## 4. Configure the LaserCAN

Download GrappleHook from https://grapplerobotics.au/grapplehook/ and install. Launch GrappleHook and connect to your RoboRIO to set a CAN ID and name, as well as modify LaserCAN settings.

### 5. Get the Vendor Dependency

Follow the instructions at https://grapplerobotics.au/product/lasercan/ to integrate into your FRC code.







## Thank you for your purchase!

Need help? Find more info at https://grapplerobotics.au

# Getting Started with LaserCAN (Batch 1)

### 1. Connect Power

While your robot is powered off, wire the **V+** and **GND** to **RoboRIO 5V or 6V** rails, found on the PWM and DIO headers. Alternatively, daisy-chain power from another LaserCAN device (up to 8).

DO NOT POWER DIRECTLY FROM THE PDP/PDH

### 2. Connect CAN

Solder your Green and Yellow CAN wires to CANL and CANH on the LaserCAN respectively. Optionally, daisy chain other CAN devices (data only).

#### 3. Power On

Turn your robot on. You should see the LaserCAN's yellow LED blink briefly.

## 4. Configure the LaserCAN

Download GrappleHook from https://grapplerobotics.au/grapplehook/ and install. Launch GrappleHook and connect to your RoboRIO to set a CAN ID and name, as well as modify LaserCAN settings.

## 5. Get the Vendor Dependency

Follow the instructions at https://grapplerobotics.au/product/lasercan/ to integrate into your FRC code.

