

ErgoDesk-Pro Assembly Guide (Doc: AN-2026)

⚠ WARNING: Two-person lift required (Desktop >25kg). Do NOT use high-torque power tools (Max 5 Nm) to prevent stripping threads. Assemble on a padded surface.

Parts & Hardware

- * Major: (A) Desktop x1 | (B) Lifting Columns x2 | (C) Feet Brackets x2 | (D) Crossbar Frame x1 | (E) Control Box/Handset x1**
- * Fasteners: (H1) M6x16mm Screws x12 | (H2) M8x25mm Bolts x8 | (H3) Rubber Washers x6 | (T1/T2) Allen Wrenches Included**

Assembly Steps

- 1. Extend Crossbar: Place Crossbar (D) on surface. Loosen center screws with T1, extend to match Desktop (A) pilot holes.**
- 2. Attach Columns: Insert Columns (B) into frame (motor cables facing inward). Secure each with 4 H1 screws using T1 in a cross-pattern.**
- 3. Install Feet: Align Feet (C) to column bases. Secure with 4 H2 bolts per foot using T2.**
- 4. Mount Desktop: Place Desktop (A) face down. Invert the frame onto it, placing Rubber Washers (H3) at mounting points. Secure with remaining H1 screws.**
- 5. Wiring & Flip: Mount Control Box (E). Plug columns into M1/M2 and handset into HS. With two people, carefully flip the desk upright.**

First-Use Initialization (Reset)

Plug into outlet. Hold DOWN until lowest point. Release, then hold DOWN again for 5 seconds until "RST" flashes. Continue holding until desk dips slightly, rises, and stops.