

Mini-Drone Quick Setup (MD-26)

Safety Fixes

- * Blade Guard:* Always snap the blade guards on before powering up for indoor flight.
- * Battery:* Do not leave the LiPo battery charging unattended. Unplug immediately once the charger light turns green.

Box Contents

- * [A]* Quadcopter Drone
- * [B]* 2.4GHz Controller
- * [C]* USB Charging Cable
- * [D]* Spare Propellers (x4)

Step-by-Step Sync

Step 1: Charge & Insert Battery

1. Connect the battery to the *USB Cable [C]*. Plug into a 5V wall adapter.
2. Once the red light turns off (fully charged), slide the battery into the drone's belly compartment until it clicks.

Step 2: Propeller Orientation

1. If replacing damaged *Propellers [D]*, match the letter stamped on the blade ("A" or "B") to the letter stamped on the drone's motor arm.
2. Push down firmly to secure. *Note: Incorrect placement will prevent the drone from lifting off.*

Step 3: Controller Pairing

1. Place the *Drone [A]* on a flat, level surface. Turn on its power switch (LEDs will flash rapidly).
2. Switch on the *Controller [B]*.
3. Push the left joystick *all the way UP*, then *all the way DOWN*.
4. The drone's LEDs will turn solid. Pairing is successful.

Basic Flight Controls

- * Left Stick:* Push UP/DOWN for altitude; Left/Right to rotate the nose.
- * Right Stick:* Push in any direction to fly forward, backward, or sideways.
- * Emergency Stop:** Press and hold both top bumper buttons simultaneously to instantly kill the motors.