

Room monitor: setup essentials

Identify the display

Check your model manual for the supported measurements and units. Temperature may be displayed in C or F; humidity is often % relative humidity. Record exactly what is shown. Do not assume every device measures the same air-quality variables.

Choose a repeatable location

Place the unit where the manufacturer permits. Note its height and position. Direct sun, heaters, vents, water spray or an open door can affect a reading. Choose a location that represents the area you want to observe and keep that position consistent for comparisons.

Allow the stated settling time

After moving or switching on the unit, follow its manual for stabilization. Record the time and whether the device was recently moved. Do not treat the first changing number as a settled measurement.

Keep the units and conditions

Write down the reading, units, time, placement and anything unusual, such as a door opening or nearby ventilation. Compare observations collected under similar conditions. A single reading is a snapshot, not a complete explanation of plant condition.

Need model-specific help?

Follow the manual included with your unit. Email support@mastergrowbot.com with your model and question. No app subscription is needed to use the tool independently.