Supported Command List - V2.1

Table of contents

- Table of contents
- Version history
- Payload mavlink target
- Command mavlink list
    - Set camera running mode
    - Set camera record source
    - Set camera view source
    - Set OSD mode
    - Set setting target
    - Set EO camera zoom mode
    - Set EO camera zoom - Super Resolution
    - Set EO camera index zoom - Combine
    - Set camera zoom target - Combine
    - Set EO camera zoom speed
    - Set camera zoom type
    - Set IR zoom
    - Set camera EO freeze
    - Set camera EO high sensitivity
    - Set camera focus type
    - Set camera EO focus mode
    - Set camera EO focus manual value
    - Set camera EO focus speed
    - Set camera IR palette
    - Set camera SpotAE display
    - Set camera SpotAE mode
    - Set camera SpotAE position
    - Set payload camera start capture image
    - Set payload camera stop capture image
    - Set payload camera start record video
    - Set payload camera stop record video
    - Set payload stream bitrate
    - Set payload stream resolution
    - Set payload standby mode
    - Set payload restart apps
    - Set camera video flip
    - Set camera video defog
    - Set camera video defog level
    - Set camera video auto exposure
    - Set camera video shutter speed
    - Set camera video aperture value
    - Set camera video bright value

- Set camera video white balance
- Set gimbal mode
- Set gimbal forward flag
- Set gimbal RC mode
- Set gimbal move to angle
- Set gimbal move by speed
- Do gimbal calib gyro
- Do gimbal auto tune
- Set LRF mode
- Set payload object tracking mode
- Set payload object tracking position
- Do object detection
- Get payload camera information
- Get payload camera streaming information
- Get payload storage
- Get payload capture status
- Get payload camera mode
- Get payload camera FOV status

Version history

Version	Publish date	Description
1.0.0	06 Jan 2023	Add example to do Connect payload Add example to do Load payload settings Add example to do Set payload settings Add example to do Image capture with the payload Add example to do Video record with the payload Add example to do Get video streaming from payload
1.0.1	25 May 2023	Included Gremsy gSDK to communicate and control gimbal Add examples to move gimbal in Angle mode and Angular rate mode using Mavlink Gimbal Protocol v2
v1.1.0	30 July 2024	Add some examples Get LRF status for VIO Payload define
v2.0.0	16 Aug 2024	Replace gSDK by MAVLINK interface Provide MAVLINK command list Publish resource
v2.1.0	09 Nov 2026	Add camera settings commands: Set OSD mode, Set setting target, Set EO camera zoom speed, Set IR zoom, Set camera EO freeze, Set camera EO high sensitivity, Set camera EO focus mode, Set camera EO focus manual value, Set camera EO focus speed Add Set camera zoom target - Combine command Add Set camera SpotAE display / mode / position commands Add Set payload stream bitrate / resolution commands Add Set payload standby mode and Set payload restart apps commands Add set gimbal forward flag command Add Do gimbal calib gyro and Do gimbal auto tune commands Add Set LRF mode command Add Get payload camera FOV status command Change Do object tracking to Set payload object tracking mode and Set payload object tracking position (new parameter layout) Modify target component of Set gimbal move to angle / by speed (101 to 154) Modify Set gimbal mode command

Payload mavlink target

Encode a command_long struct	Values	Description
target_system	1	
target_component	191	MAV_COMP_ID_ONBOARD_COMPUTER
chan	0	MAVLink channel

Command mavlink list

Set camera running mode

- Message: COMMAND_LONG (76)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
command	uint16_t	MAV_CMD_SET_CAMERA_MODE (530)	MAV_CMD
confirmation	uint8_t	1	
param2	float	0 1	Photo mode Video mode

Set camera record source

- Message: PARAM_EXT_SET (323)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
param_id	char[16]	"C_V_REC"	
param_value	char[128]	"0" "1" "2" "5"	Record both Record EO Record IR Record OSD
param_type	uint8_t	5 (MAV_PARAM_EXT_TYPE_UINT32)	MAV_PARAM_EXT_TYPE

Set camera view source

- Message: PARAM_EXT_SET (323)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
param_id	char[16]	"C_SOURCE"	
param_value	char[128]	"0" "1" "2" "3" "4"	EO/IR Only EO Only IR IR/EO Sync
param_type	uint8_t	5 (MAV_PARAM_EXT_TYPE_UINT32)	MAV_PARAM_EXT_TYPE

Set OSD mode

- Message: PARAM_EXT_SET (323)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
param_id	char[16]	"OSD_MODE"	
param_value	char[128]	"0" "1" "2" "3"	Off Debug Status Custom
param_type	uint8_t	5 (MAV_PARAM_EXT_TYPE_UINT32)	MAV_PARAM_EXT_TYPE

Set setting target

- Message: PARAM_EXT_SET (323)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
param_id	char[16]	"SETTING_TARGET"	

Field Name	Type	Values	Description
param_value	char[128]	"0" "1" "2"	EO IR GIMBAL
param_type	uint8_t	5 (MAV_PARAM_EXT_TYPE_UINT32)	MAV_PARAM_EXT_TYPE

Set EO camera zoom mode

- Message: PARAM_EXT_SET (323)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
param_id	char[16]	"C_V_ZM_MODE"	
param_value	char[128]	"0" "2"	Combine Super Resolution
param_type	uint8_t	5 (MAV_PARAM_EXT_TYPE_UINT32)	MAV_PARAM_EXT_TYPE

Set EO camera zoom - Super Resolution

- Message: PARAM_EXT_SET (323)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
param_id	char[16]	"C_V_ZM_SR_LV"	
param_value	char[128]	"0" "1" "2" "3" "4" "5" "6" "7" "8" "9" "10"	1X 2X 4X 6X 8X 10X 12X 14X 16X 18X 20X

Field Name	Type	Values	Description
		"11" "12" "13" "14" "15"	22X 24X 26X 28X 30X
param_type	uint8_t	5 (MAV_PARAM_EXT_TYPE_UINT32)	MAV_PARAM_EXT_TYPE

Set EO camera index zoom - Combine

- Message: PARAM_EXT_SET (323)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
param_id	char[16]	"C_V_ZM_CB_LV"	
param_value	char[128]	"0" "1" "2" "3" "4" "5" "6"	1X 10X 20X 40X 80X 120X 240X
param_type	uint8_t	5 (MAV_PARAM_EXT_TYPE_UINT32)	MAV_PARAM_EXT_TYPE

Set camera zoom target - Combine

- Message: COMMAND_LONG (76)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	26 (MAV_COMP_ID_USER2)	MAVLINK User Component ID
command	uint16_t	MAV_CMD_USER_4 (31013)	MAV_CMD
confirmation	uint8_t	1	
param1	float	2	
param2	float	0	
param3	float	"4"	Zoom position

Field Name	Type	Values	Description
param4	float	1...300	1x to 300x

Set EO camera zoom speed

- Message: PARAM_EXT_SET (323)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
param_id	char[16]	"C_V_ZOOM_SPEED"	
param_value	char[128]	"0"	Zoom speed value can be set from 0 to 7, step 1
param_type	uint8_t	5 (MAV_PARAM_EXT_TYPE_UINT32)	MAV_PARAM_EXT_TYPE

Set camera zoom type

- Message: COMMAND_LONG (76)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
command	uint16_t	MAV_CMD_SET_CAMERA_ZOOM (531)	MAV_CMD
confirmation	uint8_t	1	
param1	float	0 1 2	ZOOM_TYPE_STEP ZOOM_TYPE_CONTINUOUS ZOOM_TYPE_RANGE
param2	float	-1 for wide, 1 for tele -1 for wide, 1 for tele, 0 to stop zooming A percentage value between 0.0 and 100.0	Zoom one step increment Continuous zoom up/down until stopped Zoom value as proportion of full camera range

Set IR zoom

- Message: PARAM_EXT_SET (323)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
param_id	char[16]	"C_T_ZOOM"	
param_value	char[128]	"0" "1" "2" "3" "4" "5" "6" "7"	1X 2X 3X 4X 5X 6X 7X 8X
param_type	uint8_t	5 (MAV_PARAM_EXT_TYPE_UINT32)	MAV_PARAM_EXT_TYPE

Set camera EO freeze

- Message: PARAM_EXT_SET (323)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
param_id	char[16]	"C_V_FREEZE"	
param_value	char[128]	"2" "3"	On Off
param_type	uint8_t	5 (MAV_PARAM_EXT_TYPE_UINT32)	MAV_PARAM_EXT_TYPE

Set camera EO high sensitivity

- Message: PARAM_EXT_SET (323)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
param_id	char[16]	"C_V_HS"	

Field Name	Type	Values	Description
param_value	char[128]	"2" "3"	On Off
param_type	uint8_t	5 (MAV_PARAM_EXT_TYPE_UINT32)	MAV_PARAM_EXT_TYPE

Set camera focus type

- Message: COMMAND_LONG (76)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
command	uint16_t	MAV_CMD_SET_CAMERA_FOCUS (532)	MAV_CMD
confirmation	uint8_t	1	
param1	float	1 4	FOCUS_TYPE_CONTINUOUS FOCUS_TYPE_AUTO
param2	float	-1: focusing in, 1: focusing out, 0: stop	Continuous focus up/down until stopped

Set camera EO focus mode

- Message: PARAM_EXT_SET (323)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
param_id	char[16]	"C_V_FM"	
param_value	char[128]	"0" "1" "2"	Manual Auto focus Auto focus onepush
param_type	uint8_t	5 (MAV_PARAM_EXT_TYPE_UINT32)	MAV_PARAM_EXT_TYPE

Set camera EO focus manual value

- Message: PARAM_EXT_SET (323)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
param_id	char[16]	"C_V_FV"	
param_value	char[128]	"0"	Manual Focus manual value can be set from 0 to 53248, step 1
param_type	uint8_t	5 (MAV_PARAM_EXT_TYPE_UINT32)	MAV_PARAM_EXT_TYPE

Set camera EO focus speed

- Message: PARAM_EXT_SET (323)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
param_id	char[16]	"C_V_F_SPD"	
param_value	char[128]	"0"	Focus speed can be set from 0 to 7, step 1
param_type	uint8_t	5 (MAV_PARAM_EXT_TYPE_UINT32)	MAV_PARAM_EXT_TYPE

Set camera IR palette

- Message: PARAM_EXT_SET (323)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
param_id	char[16]	"C_T_PALETTE"	
param_value	char[128]	"0" "1" "2" "3" "4" "5" "6"	F1: WhiteHot ; G1: WhiteHot F1: BlackHot ; G1: Fulgurite F1: Rainbow ; G1: IronRed F1: RainbowHC ; G1: HotIron F1: Ironbow ; G1: Medical F1: Lava ; G1: Arctic F1: Arctic ; G1: Rainbow1

Field Name	Type	Values	Description
		"7" "8" "9"	F1: Globow ; G1: Rainbow2 F1: Gradedfire ; G1: Tint F1: Hottest ; G1: BlackHot
param_type	uint8_t	5 (MAV_PARAM_EXT_TYPE_UINT32)	MAV_PARAM_EXT_TYPE

Set camera SpotAE display

- Message: COMMAND_LONG (76)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	26 (MAV_COMP_ID_USER2)	MAVLINK User Component ID
command	uint16_t	MAV_CMD_USER_4 (31013)	MAV_CMD
confirmation	uint8_t	1	
param1	float	4	
param2	float	5	
param3	float	0	
param4	float	"0" "1"	Off On
param5	float	0	
param6	float	0	
param7	float	0	

Set camera SpotAE mode

- Message: COMMAND_LONG (76)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	26 (MAV_COMP_ID_USER2)	MAVLINK User Component ID
command	uint16_t	MAV_CMD_USER_4 (31013)	MAV_CMD
confirmation	uint8_t	1	
param1	float	4	
param2	float	5	
param3	float	1	

Field Name	Type	Values	Description
param4	float	"2" "3"	On Off
param5	float	0	
param6	float	0	
param7	float	0	

Set camera SpotAE position

- Message: COMMAND_LONG (76)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	26 (MAV_COMP_ID_USER2)	MAVLINK User Component ID
command	uint16_t	MAV_CMD_USER_4 (31013)	MAV_CMD
confirmation	uint8_t	1	
param1	float	4	
param2	float	5	
param3	float	2	
param4	float	"x"	pos_x
param5	float	"y"	pos_y
param6	float	"w"	width
param7	float	"h"	height

Set payload camera start capture image

- Message: COMMAND_LONG (76)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
command	uint16_t	MAV_CMD_IMAGE_START_CAPTURE (2000)	MAV_CMD
confirmation	uint8_t	1	

Field Name	Type	Values	Description
param2	int	Default, min: 0	Desired elapsed time between two consecutive pictures (in seconds)

Set payload camera stop capture image

- Message: COMMAND_LONG (76)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
command	uint16_t	MAV_CMD_IMAGE_STOP_CAPTURE (2001)	MAV_CMD
confirmation	uint8_t	1	

Set payload camera start record video

- Message: COMMAND_LONG (76)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
command	uint16_t	MAV_CMD_VIDEO_START_CAPTURE (2500)	MAV_CMD
confirmation	uint8_t	1	

Set payload camera stop record video

- Message: COMMAND_LONG (76)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting

Field Name	Type	Values	Description
command	uint16_t	MAV_CMD_VIDEO_STOP_CAPTURE (2501)	MAV_CMD
confirmation	uint8_t	1	

Set payload stream bitrate

- Message: COMMAND_LONG (76)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	26 (MAV_COMP_ID_USER2)	MAVLINK User Component ID
command	uint16_t	MAV_CMD_USER_4 (31013)	MAV_CMD
confirmation	uint8_t	1	
param1	float	4	
param2	float	2	
param3	float	"1" "2"	EO IR
param4	float	0	
param5	float	512000 … 16000000	from 512 kbps to 16 Mbps

Set payload stream resolution

- Message: COMMAND_LONG (76)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	26 (MAV_COMP_ID_USER2)	MAVLINK User Component ID
command	uint16_t	MAV_CMD_USER_4 (31013)	MAV_CMD
confirmation	uint8_t	1	
param1	float	4	
param2	float	2	
param3	float	"1" "2"	EO IR
param4	float	1	
param5	float	"0" "1"	1920x1080 (EO)/ 1208x1024 (IR) 1208x720 (EO)/ 640x512 (IR)

Field Name	Type	Values	Description
		"2" "3" "4"	960x540 (EO)/ 480x384 (IR) 320x256 (IR) 160x128 (IR)

Set payload standby mode

- Message: COMMAND_LONG (76)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	26 (MAV_COMP_ID_USER2)	MAVLINK User Component ID
command	uint16_t	MAV_CMD_USER_4 (31013)	MAV_CMD
confirmation	uint8_t	1	
param1	float	4	
param2	float	3	
param3	float	0	
param4	float	"0" "1"	Off On

Set payload restart apps

- Message: COMMAND_LONG (76)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	26 (MAV_COMP_ID_USER2)	MAVLINK User Component ID
command	uint16_t	MAV_CMD_USER_4 (31013)	MAV_CMD
confirmation	uint8_t	1	
param1	float	4	
param2	float	4	
param3	float	"0" "1" "2" "3" "4" "5"	Payload app Streaming app Tracking app Web UI app Gimbal app Reboot payload
param4	float	0	

Field Name	Type	Values	Description
param5	float	0	
param6	float	0	
param7	float	0	

Set camera video flip

- Message: PARAM_EXT_SET (323)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
param_id	char[16]	"C_V_FLIP"	
param_value	char[128]	"2" "3"	On Off
param_type	uint8_t	5 (MAV_PARAM_EXT_TYPE_UINT32)	MAV_PARAM_EXT_TYPE

Set camera video defog

- Message: PARAM_EXT_SET (323)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
param_id	char[16]	"C_V_DEFOG"	
param_value	char[128]	"0" "1"	Off On
param_type	uint8_t	5 (MAV_PARAM_EXT_TYPE_UINT32)	MAV_PARAM_EXT_TYPE

Set camera video defog level

- Message: PARAM_EXT_SET (323)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID

Field Name	Type	Values	Description
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
param_id	char[16]	"C_V_DEFOG_LV"	
param_value	char[128]	"0" "1" "2" "3"	Lowest Low Mid High
param_type	uint8_t	5 (MAV_PARAM_EXT_TYPE_UINT32)	MAV_PARAM_EXT_TYPE

Set camera video auto exposure

- Message: PARAM_EXT_SET (323)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
param_id	char[16]	"C_V_AE"	
param_value	char[128]	"0" "3" "10" "11" "13"	Auto Manual Shutter Iris Bright
param_type	uint8_t	5 (MAV_PARAM_EXT_TYPE_UINT32)	MAV_PARAM_EXT_TYPE

Set camera video shutter speed

- Message: PARAM_EXT_SET (323)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
param_id	char[16]	"C_V_SP"	
param_value	char[128]	"13" "14" "17"	1/10 1/20 1/50

Field Name	Type	Values	Description
		"20" "21" "25" "26" "27" "28" "30"	1/100 1/125 1/500 1/725 1/1000 1/1500 1/2000
param_type	uint8_t	5 (MAV_PARAM_EXT_TYPE_UINT32)	MAV_PARAM_EXT_TYPE

Set camera video aperture value

- Message: PARAM_EXT_SET (323)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
param_id	char[16]	"C_V_IrP"	
param_value	char[128]	0	Aperture value can be set from 0 to 25, step 1
param_type	uint8_t	5 (MAV_PARAM_EXT_TYPE_UINT32)	MAV_PARAM_EXT_TYPE

Set camera video bright value

- Message: PARAM_EXT_SET (323)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
param_id	char[16]	"C_V_BrP"	
param_value	char[128]	0	Bright value can be set from 0 to 41, step 1
param_type	uint8_t	5 (MAV_PARAM_EXT_TYPE_UINT32)	MAV_PARAM_EXT_TYPE

Set camera video white balance

- Message: PARAM_EXT_SET (323)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
param_id	char[16]	"C_V_WB"	
param_value	char[128]	"0" "1" "2" "3" "4" "5"	Auto Indoor Outdoor One push ATW Manual
param_type	uint8_t	5 (MAV_PARAM_EXT_TYPE_UINT32)	MAV_PARAM_EXT_TYPE

Set gimbal mode

Note: For Software Package v307 and later, PARAM_EXT_SET must not be used to configure the gimbal mode. Use MAVLINK_MSG_ID_GIMBAL_DEVICE_SET_ATTITUDE (Message ID: 284) instead.

- Message: MAVLINK_MSG_ID_GIMBAL_DEVICE_SET_ATTITUDE (284)

Field Name	Type		Values	Description
target_system	uint8_t		1	System ID
target_component	uint8_t		154 (MAV_COMP_ID_GIMBAL)	Gimbal Components ID
flags	uint16_t		1, 2, 4, 8, 16, 32, 64, 128, 256, 512	Bitmask for configuring Gimbal modes. Multiple flags can be combined using bitwise OR
q	float[4]		NaN	Quaternion components, w, x, y, z
angular_velocity_x	float	rad/s	0	X component of angular velocity (Roll)
angular_velocity_y	float	rad/s	0	Y component of angular velocity (Pitch)
angular_velocity_z	float	rad/s	0	Z component of angular velocity (Yaw)

Set gimbal forward flag

- Message: PARAM_EXT_SET (323)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
param_id	char[16]	"GB_FW_FLAG"	
param_value	char[128]	"0" "1" "2"	Autopilot Onboard computer SBUS Convert
param_type	uint8_t	5 (MAV_PARAM_EXT_TYPE_UINT32)	MAV_PARAM_EXT_TYPE

Set gimbal RC mode

- Message: PARAM_EXT_SET (323)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
param_id	char[16]	"RC_MODE"	
param_value	char[128]	"0" "1"	Gremsy Standard
param_type	uint8_t	5 (MAV_PARAM_EXT_TYPE_UINT32)	MAV_PARAM_EXT_TYPE

Set gimbal move to angle

- Message: GIMBAL_DEVICE_SET_ATTITUDE (284)

Field Name	Type		Values	Description
target_system	uint8_t		1	System ID
target_component	uint8_t		154 (MAV_COMP_ID_GIMBAL)	Gimbal Components ID
q	float[4]		mavlink_euler_to_quaternion(roll, pitch, yaw, q)	Quaternion components, w, x, y, z
angular_velocity_x	float	rad/s	NaN	X component of angular velocity (Roll)

Field Name	Type		Values	Description
angular_velocity_y	float	rad/s	NaN	Y component of angular velocity (Pitch)
angular_velocity_z	float	rad/s	NaN	Z component of angular velocity (Yaw)

Set gimbal move by speed

- Message: GIMBAL_DEVICE_SET_ATTITUDE (284)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	154 (MAV_COMP_ID_GIMBAL)	Gimbal Components ID
q	float[4]	NaN	Quaternion components, w, x, y, z
angular_velocity_x	float	rad/s Speed roll	X component of angular velocity (Roll)
angular_velocity_y	float	rad/s Speed pitch	Y component of angular velocity (Pitch)
angular_velocity_z	float	rad/s Speed yaw	Z component of angular velocity (Yaw)

Do gimbal calib gyro

- Message: COMMAND_LONG (76)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	154 (MAV_COMP_ID_GIMBAL)	Gimbal Components ID
command	uint16_t	MAV_CMD_GIMBAL_REQUEST_AXIS_CALIBRATION (42503)	Command ID
confirmation	uint8_t	1	
param7	float	1	

Do gimbal auto tune

- Message: COMMAND_LONG (76)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	154 (MAV_COMP_ID_GIMBAL)	Gimbal Components ID
command	uint16_t	31012 (MAV_CMD_USER_3)	Command ID
confirmation	uint8_t	1	
param7	float	1	

Set LRF mode

- Message: PARAM_EXT_SET (323)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
param_id	char[16]	"LRF_MODE"	
param_value	char[128]	"0" "1" "2" "3"	1Hz 4Hz 10Hz Off
param_type	uint8_t	5 (MAV_PARAM_EXT_TYPE_UINT32)	MAV_PARAM_EXT_TYPE

Set payload object tracking mode

- Message: COMMAND_LONG (76)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	26 (MAV_COMP_ID_USER2)	MAVLINK User Component ID
command	uint16_t	31013 (MAV_CMD_USER_4)	Command ID (of command to send)
confirmation	uint8_t	1	
param1	float	4	
param2	float	0	
param3	float	0	

Field Name	Type	Values	Description
param4	float	"0" "1" "2"	Track stop Track active Track eagleeyes
param5	float	0	
param6	float	0	
param7	float	0	

Set payload object tracking position

- Message: COMMAND_LONG (76)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	26 (MAV_COMP_ID_USER2)	MAVLINK User Component ID
command	uint16_t	31013 (MAV_CMD_USER_4)	Command ID (of command to send)
confirmation	uint8_t	1	
param1	float	4	
param2	float	0	
param3	float	1	
param4	float	"x"	pos_x
param5	float	"y"	pos_y
param6	float	"w"	width
param7	float	"h"	height

Do object detection

- Message: PARAM_EXT_SET (323)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
param_id	char[16]	"TRACK_MODE"	
param_value	char[128]	"0" "1"	Disable Enable

Field Name	Type	Values	Description
param_type	uint8_t	5 (MAV_PARAM_EXT_TYPE_UINT32)	MAV_PARAM_EXT_TYPE

Get payload camera information

- Message: COMMAND_LONG (76)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
command	uint16_t	MAV_CMD_REQUEST_CAMERA_INFORMATION (521)	MAV_CMD
confirmation	uint8_t	1	

Get payload camera streaming information

- Message: COMMAND_LONG (76)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
command	uint16_t	MAV_CMD_REQUEST_VIDEO_STREAM_INFORMATION (2504)	MAV_CMD
confirmation	uint8_t	1	

Get payload storage

- Message: COMMAND_LONG (76)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting

Field Name	Type	Values	Description
command	uint16_t	MAV_CMD_REQUEST_STORAGE_INFORMATION (525)	MAV_CMD
confirmation	uint8_t	1	

Get payload capture status

- Message: COMMAND_LONG (76)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
command	uint16_t	MAV_CMD_REQUEST_CAMERA_CAPTURE_STATUS (527)	MAV_CMD
confirmation	uint8_t	1	

Get payload camera mode

- Message: COMMAND_LONG (76)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
command	uint16_t	MAV_CMD_REQUEST_CAMERA_SETTINGS (522)	MAV_CMD
confirmation	uint8_t	1	

Get payload camera FOV status

- Message: COMMAND_LONG (76)

Field Name	Type	Values	Description
target_system	uint8_t	1	System ID

Field Name	Type	Values	Description
target_component	uint8_t	101 (MAV_COMP_ID_CAMERA2)	MAVLINK Camera Component ID on Web setting
command	uint16_t	MAV_CMD_REQUEST_MESSAGE (512)	MAV_CMD
confirmation	uint8_t	1	
param1	float	MAVLINK_MSG_ID_CAMERA_FOV_STATUS (271)	
param2	float	"0" "1"	Camera EO Camera IR