

A+ Core 1 Playbook

IT Labs

Prepared by Garrick White

10.2.8 Replace a Printer Fuser

The fuser unit or fuser assembly is a critical component of your laser printer. Using pressure and heat, it fuses the toner powder onto the page to create a print.

Step 1: Power off the printer

Step 2: Remove the Power Chord

Step 3: Open the Rear Duplexer Panel

Step 4: Remove Fuser

Press on the blue levers to release the fuser lock

Pull the fuser straight back to remove (with the fuser removed you should inspect the fuser drive gear on the left-hand side of the printer for excessive wear)

Step 5: Install New Fuser

Step 6: Close the Duplexer Rear Panel

Step 7: Connect Power

Step 8: Check Print Status

Press the power button, the printer should go through a brief self-diagnosis before displaying the printer is ready to use.

Question 1

When prepping a printer to replace a fuser, which of the steps should you first take? (select all that apply.)

answer

Remove the power cord

Power off the printer

Wait 10 minutes for the fuser to cool before starting work

Question 2

When replacing a fuser, what internal component of the printer should be inspected for excessive wear once the fuser has been removed?

Fuser Drive Gear

Question 3

When troubleshooting printing issues what are some of the signs that a printer fuser needs to be replaced?

All of the above

Question 4

To fuse toner powder onto a page to create a print, what does the fuser unit use? (Select all that apply.)

Heat

Pressure