

CompTIA A+ Core 1 Playbook

IT Labs

Prepared by Garrick White

4.2.10 Troubleshoot Drive Availability

You work at a computer repair store. A customer has just bought a used computer at a very good price. The previous owner said the computer worked, but when it was brought home, the computer would not start.

In this lab, your task is to diagnose and correct the problems preventing this system from booting into Windows.

You'll know that you've successfully corrected all the problems when:

- The computer recognizes all the components in the BIOS.
- The computer boots to Windows.

Keep in mind the following when working on the system:

- The computer was in use and working previously.
- The previous owner mentioned that he replaced the hard drive when preparing to sell the computer.
- The new owner of the computer wants the machine to boot into Windows every time to avoid any possible issues in the future.

Complete this lab as follows:

1. Replicate the problem by turning on the computer.
 1. On the computer, select the **power button** to turn it on.
A prompt is shown, indicating that the computer failed to turn on.
 2. Press **F2** to enter the BIOS/UEFI.
2. Verify that the computer is able to see all connected drives.
 1. In the BIOS/UEFI menu, expand the **System Configuration** menu.
 2. Select the **Drives** option in the expanded System Configuration menu.
 3. Verify that all drives are enabled.
3. Verify that the hard drive is a part of the boot sequence.
 1. Select **Boot Sequence** from the expanded General menu.
 2. Check the box for **Internal HDD** to enable the computer to boot from the hard drive.
4. Make the hard drive the primary boot device and boot to Windows.
 1. On the Boot Sequence menu, select **Internal HDD** on the right-hand side of the screen.
 2. Select the **up arrow** four times in order to place the internal HDD as the primary boot device.
 3. Select **Apply** at the bottom of the screen to save changes made to the BIOS/UEFI.
 4. Select the **Exit** at the bottom of the screen to exit the BIOS/UEFI configuration.
 5. Wait for the system to boot into Windows.