

Pump P-204 Maintenance Manual

1. General Overview

The Pump P-204 is a high-pressure centrifugal pump used for cooling loops.

2. Maintenance Procedures

When performing maintenance on the main valve, the required torque is exactly 55 Nm. Do not over-torque.

3. Safety Regulations

Confined space entry around the pump area requires continuous atmospheric monitoring as per Factory Act Sec