RN0059 Release Notes CoreAHBLite v5.5





a MICROCHIP company

Microsemi Headquarters

One Enterprise, Aliso Viejo, CA 92656 USA Within the USA: +1 (800) 713-4113 Outside the USA: +1 (949) 380-6100 Sales: +1 (949) 380-6136 Fax: +1 (949) 215-4996

Email: sales.support@microsemi.com www.microsemi.com

©2020 Microsemi, a wholly owned subsidiary of Microchip Technology Inc. All rights reserved. Microsemi and the Microsemi logo are registered trademarks of Microsemi Corporation. All other trademarks and service marks are the property of their respective owners.

Microsemi makes no warranty, representation, or guarantee regarding the information contained herein or the suitability of its products and services for any particular purpose, nor does Microsemi assume any liability whatsoever arising out of the application or use of any product or circuit. The products sold hereunder and any other products sold by Microsemi have been subject to limited testing and should not be used in conjunction with mission-critical equipment or applications. Any performance specifications are believed to be reliable but are not verified, and Buyer must conduct and complete all performance and other testing of the products, alone and together with, or installed in, any end-products. Buyer shall not rely on any data and performance specifications or parameters provided by Microsemi. It is the Buyer's responsibility to independently determine suitability of any products and to test and verify the same. The information provided by Microsemi hereunder is provided "as is, where is" and with all faults, and the entire risk associated with such information is entirely with the Buyer. Microsemi does not grant, explicitly or implicitly, to any party any patent rights, licenses, or any other IP rights, whether with regard to such information itself or anything described by such information. Information provided in this document is proprietary to Microsemi, and Microsemi reserves the right to make any changes to the information in this document or to any products and services at any time without notice.

About Microsemi

Microsemi, a wholly owned subsidiary of Microchip Technology Inc. (Nasdaq: MCHP), offers a comprehensive portfolio of semiconductor and system solutions for aerospace & defense, communications, data center and industrial markets. Products include high-performance and radiation-hardened analog mixed-signal integrated circuits, FPGAs, SoCs and ASICs; power management products; timing and synchronization devices and precise time solutions, setting the world's standard for time; voice processing devices; RF solutions; discrete components; enterprise storage and communication solutions, security technologies and scalable anti-tamper products; Ethernet solutions; Power-over-Ethernet ICs and midspans; as well as custom design capabilities and services. Learn more at www.microsemi.com.



Contents

1	Revisi	on History	1
	1.1	Revision 12.0	1
	1.2	Revision 11.0	1
	1.3	Revision 10.0	1
	1.4	Revision 9.0	1
	1.5	Revision 8.0	1
	1.6	Revision 7.0	1
	1.7	Revision 6.0	1
	1.8	Revision 5.0	1
	1.9	Revision 4.0	1
	1.10	Revision 3.0	1
	1.11	Revision 2.0	1
	1.12	Revision 1.0	2
_	O A	LIDI to V.E. E. Dologoo Notos	2
2		HBLite v5.5 Release Notes	
	2.1	Features	
	2.2	Interfaces	
	2.3	Delivery Types	
	2.4	2.3.1 RTL	
	2.4	Supported Families	3
	2.5	Supported Families Supported Tool Flows	3
	2.5 2.6	Supported Families Supported Tool Flows Installation Instructions	3 4 4
	2.5 2.6 2.7	Supported Families Supported Tool Flows Installation Instructions Documentation	3 4 4
	2.5 2.6 2.7 2.8	Supported Families Supported Tool Flows Installation Instructions Documentation Known Issues and Workarounds	3 4 4 4
	2.5 2.6 2.7 2.8 2.9	Supported Families Supported Tool Flows Installation Instructions Documentation Known Issues and Workarounds Resolved Issues in the v5.5 Release	3 4 4 4 4
	2.5 2.6 2.7 2.8 2.9 2.10	Supported Families Supported Tool Flows Installation Instructions Documentation Known Issues and Workarounds Resolved Issues in the v5.5 Release Resolved Issues in the v5.4 Release	3 4 4 4 4 4
	2.5 2.6 2.7 2.8 2.9 2.10 2.11	Supported Families Supported Tool Flows Installation Instructions Documentation Known Issues and Workarounds Resolved Issues in the v5.5 Release Resolved Issues in the v5.4 Release Resolved Issues in the v5.3 Release	3 4 4 4 4 4 4
	2.5 2.6 2.7 2.8 2.9 2.10 2.11 2.12	Supported Families Supported Tool Flows Installation Instructions Documentation Known Issues and Workarounds Resolved Issues in the v5.5 Release Resolved Issues in the v5.4 Release Resolved Issues in the v5.3 Release Resolved Issues in the v3.1 Release	3 4 4 4 4 4 5
	2.5 2.6 2.7 2.8 2.9 2.10 2.11	Supported Families Supported Tool Flows Installation Instructions Documentation Known Issues and Workarounds Resolved Issues in the v5.5 Release Resolved Issues in the v5.4 Release Resolved Issues in the v5.3 Release	3 4 4 4 4 4 5 5



Tables

Table 1	Resolved SARs in CoreAHBLite v5.4 Release	4
Table 2	Resolved SARs in CoreAHBLite v5.3 Release	4
Table 3	Resolved SARs in CoreAHBLite v3.1 Release	Ę
Table 4	Resolved SARs in CoreAHBLite v3.0 Release	Ę



1 Revision History

The revision history describes the changes that were implemented in the document. The changes are listed by revision, starting with the most current publication.

1.1 Revision 12.0

Added PolarFire® SoC support. Updated changes related to CoreAHBLite v5.5.

1.2 **Revision 11.0**

Updated changes related to CoreAHBLite v5.4.

1.3 Revision 10.0

Updated changes related to CoreAHBLite v5.3. Added information about PolarFire® support.

1.4 **Revision 9.0**

Updated changes related to CoreAHBLite v5.2. Added information about IGLOO[®]2 and RTG4[™] support.

1.5 **Revision 8.0**

Updated changes related to CoreAHBLite v5.0. Added two more master interfaces. CoreAHBLite can now support a total of four masters.

1.6 Revision 7.0

Updated changes related to CoreAHBLite v4.0.

A greater range of memory space configurations is now supported. Slave slot size can range from 256 bytes to 256 Mbytes.

Mode with 16 x 64 Kbyte slots along with one huge (2 GByte) slot is still supported, but initialization interfaces located from 0x00040000 - 0x0004FFFF are no longer supported in this mode.

Combining of slave slots is now possible. This allows multiple regions of the memory map to be accessed through a single slave interface (S16). This feature may be useful while accessing MSS resources in the SmartFusion or SmartFusion2 device.

1.7 **Revision 6.0**

Updated changes related to CoreAHBLite v3.1. Added capability for memory maps to be altered in SmartDesign to reflect the value of the MODE_CFG parameter.

1.8 Revision 5.0

Updated changes related to CoreAHBLite v3.0. Added another memory configuration mode. Added huge slot capability and Init/Config client support.

1.9 Revision 4.0

Updated changes related to CoreAHBLite v2.0. Added multi-master capability and additional ports to satisfy multi-master capability.

1.10 **Revision 3.0**

Updated changes related to CoreAHBLite v1.3. Minor updates.

1.11 **Revision 2.0**

Updated changes related to CoreAHBLite v1.2. Minor updates.



1.12 **Revision 1.0**

Revision 1.0 was the first publication of this document. Created for CoreAHBLite v1.1.



CoreAHBLite v5.5 Release Notes 2

This document accompanies the release of CoreAHBLite v5.5. It describes the features and enhancements of CoreAHBLite v5.5. It also contains the information on system requirements, supported families, implementations, known issues and workarounds, and resolved issues with the previous version.

2.1 **Features**

CoreAHBLite has the following features:

- Supports up to four masters
- Supports up to 16 slaves (up to 17 in one mode, if a huge slave is in use)
- Address space per slave varies from 256 bytes to 256 MB (Huge slave occupies 2 GB)
- Supports allocation of slave slots to a "combined region" slave interface in most modes
- Allows access to slave slots to be enabled on a per master basis. All masters have equal priority (round-robin arbitration scheme)
- Supports remapping feature for master 0 interface

Interfaces 2.2

CoreAHBLite v5.5 supports four AHB-Lite master interfaces and up to 16 AHB-Lite slave interfaces (up to 17 slave interfaces are supported in one mode when the huge slave is in use).

Microsemi recommends using SmartDesign to connect and configure CoreAHBLite v5.5 while creating a system design.

2.3 **Delivery Types**

No license is required to use the core.

2.3.1 RTL

Complete RTL source code is provided for the core.

2.4 **Supported Families**

CoreAHBLite supports the following families:

- PolarFire® SoC
- PolarFire[®]
- RTG4[™]
- SmartFusion®2
- IGLOO[®]2
- SmartFusion[®]
- IGLOO®
- IGLOO®e
- IGLOO® PLUS
- $\mathsf{Fusion}^{\mathbb{R}}$
- ProASIC®3
- ProASIC®3E ProASIC®3L
- Axcelerator[®]
- RTAX-S



2.5 Supported Tool Flows

Use Libero Design software v8.6 or later with the CoreAHBLite v5.5 release.

2.6 Installation Instructions

The CoreAHBLite CPZ file must be installed into Libero software. This is done automatically through the Catalog update function in Libero, or the CPZ file can be manually added using the **Add Core** catalog feature. Once the CPZ file is installed in Libero, the core can be configured, generated, and instantiated within SmartDesign for inclusion in the Libero project. For more information, see the *Knowledge Based article*.

To know how to create SmartDesign project using the IP cores, refer to *Libero SoC documents page* and use the latest SmartDesign user guide.

2.7 Documentation

This release contains a copy of the *CoreAHBLite Handbook*. The handbook, describes the core functionality and gives step-by-step instructions on how to simulate, synthesize, and place-and-route this core, and also implementation suggestions. Refer to *Libero SoC documents page* for instructions on obtaining IP documentation.

For updates and additional information, visit the Intellectual Property pages on the Microsemi SoC Products Group website: visit:

http://www.microsemi.com/products/fpga-soc/design-resources/ip-cores.

2.8 Known Issues and Workarounds

There are no known issues in CoreAHBLite v5.5.

2.9 Resolved Issues in the v5.5 Release

There were no software action requests (SARs) resolved. PolarFireSoC support is added.

2.10 Resolved Issues in the v5.4 Release

Table 1 • Resolved SARs in CoreAHBLite v5.4 Release

SAR	Description
87186	Core not working in burst mode.
105585	Mirrored slave to Mirrored master enhancement.

2.11 Resolved Issues in the v5.3 Release

Table 2 • Resolved SARs in CoreAHBLite v5.3 Release

SAR	Description
83890	HTRANS bit0 is connected to "0" for all slaves at top level.
56427	Check hdl errors out on testbench created by system builder.
87186	Core not working in burst mode.
54034	Need more information on AMBA AHBLite protocol specification.



2.12 Resolved Issues in the v3.1 Release

Table 3 • Resolved SARs in CoreAHBLite v3.1 Release

SAR	Description
23409	XPATH equations needed to differentiate mode memory maps.

2.13 Resolved Issues in the v3.0 Release

Table 4 • Resolved SARs in CoreAHBLite v3.0 Release

SAR	Description
14960	Validation should warn if all slots are disabled.
12612	Core now supports 60 MHz operations.
17753	File components.vhd need to be packaged using logical library COREAHBLITE_LIB.
14958	Clock and reset signals should be tagged as mandatory.
14666	Remap input has no default value in SmartDesign.
19750	Mirrored slave HMASTLOCK_S* outputs need to be brought out at the top-level.

2.14 Resolved Issues in the v2.0 Release

The v2.0 release is an updated version of the previous release, with new I/O signals and some modified I/O signals.