

## **CoreResetP v7.1 Release Notes**

These release notes accompany the production release of CoreResetP v7.1. This document provides details about the features, enhancements, system requirements, supported families, implementations, and known issues and workarounds.

#### **Features**

- Sequences reset signals in a SmartFusion<sup>®</sup>2 or IGLOO<sup>®</sup>2 device.
- Interacts with CoreConfigP to ensure that reset releases are coordinated with the initialization of the peripheral blocks in a SmartFusion2 or IGLOO2 device. The relevant peripheral blocks are the double data rate (DDR) controllers and the high speed serial interface (SERDESIF) blocks.

## **Delivery Types**

CoreResetP is delivered as register transfer level (RTL) code. The core is freely available and unlicensed.

## **Supported Families**

- SmartFusion2
- IGLOO2

## **Supported Tool Flows**

Use Libero v11.4 software or later with CoreResetP v7.1 release.

## Installation Instructions

CoreResetP is available through the Libero SoC IP Catalog. The core can be downloaded from a remote web-based repository to the local vault. Once installed in Libero SoC, the core can be instantiated, configured, connected, and generated using the SmartDesign tool. The System Builder tool automatically instantiates and connects CoreResetP when constructing a design.

## **Known Issues and Workarounds**

There are no known issues in this release.



# Release History

Table 1 provides the release history of CoreResetP.

Table 1. Release History of CoreResetP

Version	Date	Changes
7.1	May 2016	Minor change to the configuration GUI: "090" is replaced with "060 or 090".
7.0	June 2014	Added SDIF0_0_CORE_RESET_N and SDIF0_1_CORE_RESET_N outputs (and corresponding SOFT_SDIF0_0_CORE_RESET and SOFT_SDIF0_1_CORE_RESET inputs).
		Renamed CONFIG_DONE input to CONFIG1_DONE.
		Added SDIF_RELEASED output and CONFIG2_DONE input.
		Added DDR_READY and SDIF_READY outputs.
		Renamed FAB_RESET_N output to MSS_HPMS_READY and removed SOFT_FAB_RESET input.
		Removed USER_FAB_RESET_N output and SOFT_USER_FAB_RESET input. (INIT_DONE is essentially the same signal as USER_FAB_RESET_N.)
		Removed CLR_INIT_DONE input.
		Removed EXT_RESET_IN_N input.
		Renamed USER_FAB_RESET_IN_N input to FAB_RESET_N.
5.1	January 2014	Updated handbook included with core.
5.0	Sept 2013	Added logic to support PCIe related functionality (HotReset and L2/P2 support).
		Added SOFT_* input ports that are intended to support software control of individual reset line assertion and de-assertion.
4.0	July 2013	First production release.



**Microsemi Corporate Headquarters** One Enterprise, Aliso Viejo, CA 92656 USA

Within the USA: +1 (800) 713-4113 Outside the USA: +1 (949) 380-6100 Sales: +1 (949) 380-6136 Fax: +1 (949) 215-4996

E-mail: sales.support@microsemi.com

© 2016 Microsemi Corporation. All rights reserved. Microsemi and the Microsemi logo are trademarks of Microsemi Corporation. All other trademarks and service marks are the property of their respective owners.

Microsemi Corporation (Nasdaq: MSCC) offers a comprehensive portfolio of semiconductor and system solutions for communications, defense and security, aerospace, and industrial markets. Products include high-performance and radiation-hardened analog mixed-signal integrated circuits, FPGAs, SoCs, and ASICs; power management products; timing and synchronization devices and precise time solutions; voice processing devices; RF solutions; discrete components; enterprise storage and communications solutions, security technologies, and scalable anti-tamper products; Ethernet solutions; Power-over-Ethernet ICs and midspans; custom design capabilities and services. Microsemi is headquartered in Aliso Viejo, California, and has approximately 4,800 employees worldwide. Learn more at www.microsemi.com.

Microsemi makes no warranty, representation, or guarantee regarding the information contained herein or the suitability of its products and services for any particular purpose, nor does Microsemi assume any liability whatsoever arising out of the application or use of any product or circuit. The products sold hereunder and any other products sold by Microsemi have been subject to limited testing and should not be used in conjunction with mission-critical equipment or applications. Any performance specifications are believed to be reliable but are not verified, and Buyer must conduct and complete all performance and other testing of the products, alone and together with, or installed in, any end-products. Buyer shall not rely on any data and performance specifications or parameters provided by Microsemi. It is the Buyer's responsibility to independently determine suitability of any products and to test and verify the same. The information provided by Microsemi hereunder is provided "as is, where is" and with all faults, and the entire risk associated with such information is entirely with the Buyer. Microsemi does not grant, explicitly or implicitly, to any party any patent rights, licenses, or any other IP rights, whether with regard to such information itself or anything described by such information. Information provided in this document is proprietary to Microsemi, and Microsemi reserves the right to make any changes to the information in this document or to any products and services at any time without notice.