

Date 87.01.27		Norsk Data A.S PROGRAM DESCRIPTION	Page 2 of 8
Product	Name COSMOS Network Monitor	Reg. no. 211104A	Category STPR

1 SYSTEMS PREREQUISITES

The following are prerequisites for the installation of COSMOS Network Monitor:

- SINTRAN III version J or newer.
- X-MESSAGE version J or newer.

2 INSTALLATION CONSIDERATIONS

The COSMOS Network Monitor consists of three parts:

- test part, which checks status of connections and servers.
- report part, which allows the operator to produce reports
- monitory part, which does online monitoring of status on a terminal whenever started.

The test part should only be installed on one machine (per operator domain) in the network. This machine should be a central one and have good access to other parts of the network. The test part is installed under user RT.

The configuration file and the logging file from the test part are input files to the report part. To prevent that the operator has to copy these files to another machine when producing reports, the report part is installed on the same machine as the test part. It may be installed under any user. NOTE that you also have to install the enclosed report production tool REPRO for ND-100 on your machine.

The monitory part may be run on any system in the network which has access to the system where the test part is running. It may be installed under any user.

Date 87.01.27		Norsk Data A.S PROGRAM DESCRIPTION	Page 3 of 8
Product	Name COSMOS Network Monitor	Reg. no. 211104A	Category STPR

3 INSTALLATION PROCEDURE

The installation procedure allows you to choose whether to install the test & report part AND/OR the monitory part.

3.1 Running the installation program

Installing the different parts of the COSMOS Monitor is done as follows:

- Log in as user SYSTEM.
- Make sure that the user(s) you want to copy the files to has enough free user space. The amount of space is given on the front page of this PD-sheet.
- Insert the first release floppy in the floppy drive.
- Enter the directory on the floppy

```
@ENTER-DIRECTORY↓
DIRECTORY NAME: 211104A<rev>-XX-01↓
DEVICE NAME: FLOPPY-DISC-<drive-no.>↓
DEVICE UNIT: <floppy-unit>↓
@
```

- Start the installation program with the command:

```
@(211104A:FLOPPY-USER)INST-COSMON↓
```

The two messages:

```
USER-BREAK TERMINATION ENABLED and
FATAL-ERROR TERMINATION ENABLED
```

are not error messages, but simply informing you that the error handling is ready.

- Choose which part(s) of the COSMOS Monitor you want to install; test & report AND/OR monitory part.
- When you are asked for user name, you should write the name without any abbreviations. The files concerned with the report production will be placed on this user area. The file in the monitory part will also be placed on this area if you choose to install it. The RT- program will be placed under user RT.

Date 87.01.27		Norsk Data A.S PROGRAM DESCRIPTION	Page 4 of 8
Product	Name COSMOS Network Monitor	Reg. no. 211104A	Category STPR

3.2 What the installation program does

When you run the installation procedure, the following will be done:

If you install the test & report part:

The following files will be copied from the diskette:

To user RT:

COSMON-MAIN-A:PROG	(RT-program doing the testing).
COSMON-DEF-A:CONF	(Configuration file).
COSMON-LOAD-A:MODE	(Load file for RT-program).

To user area given by you:

COSMON-SERV-A:PROG	(Saves logfile and starts REPRO for producing reports).
REP-COSMON-A:RPRT	(Library used by REPRO).
COSMON-STAT-A:LOOK	(Lookup file used by REPRO).

The following files will be created:

On the user area given by you:

COSMON-INRP-A:SYMB	(Infile to REPRO).
COSMON-OUTRP-A:TEXT	(Default outfile from REPRO).

If you install the monitory part:

The following files will be copied from the diskette:

To user area given by you:

COSMON-WIND-A:PROG	(Operator's monitor program).
--------------------	-------------------------------

4 Ending the installation procedure

When the installation program has terminated successfully, you should give the command:

@DELETE-FILE (SYSTEM)INST-COSMON:PROG

ooo ND Norsk Data ooo

Date 87.01.27		Norsk Data A.S PROGRAM DESCRIPTION	Page 5 of 8
Product	Name COSMOS Network Monitor	Reg. no. 211104A	Category STPR

5 FURTHER PROCEDURES

5.1 Loading the COSMON Main RT-program

To load the COSMON-Main RT-program you do as follows:

- Log in as user SYSTEM or RT
- Run the mode file COSMON-LOAD-A:MODE on user RT.

@MODE (RT)COSMON-LOAD-A:MODE,,,,↓

This mode command should be inserted in the SINTRAN file HENT-MODE:MODE, to ensure that the COSMON-Main RT-program is loaded after a cold start.

5.2 Starting and stopping the COSMON Main RT-program

Before you start the COSMON Main RT-program, you must use PED (or any other text editor with 7-bit storage format) to build up your own version of the configuration file

COSMON-DEF-A:CONF

A sample version is copied from the diskette which will be useful for keeping the required format. A description of the format of this file is found in the COSMOS Network Monitor Operator Guide.

Remember the cost if testing connections over public networks.

To be able to check status of servers on a system in a network, this system must run XMSG K or later. If not, an error message will be returned.

The logging file, COSMON-LOG:LOGS, will be created when the RT-program is started.

Start the COSMON Main RT-program using the SINTRAN command

@RT COSMON↓

You should add this command in the SINTRAN file LOAD-MODE:MODE (or LOAD-SYSTEM:BATC) so that the COSMON Main RT-program is restarted after a warm start.

Date 87.01.27		Norsk Data A.S PROGRAM DESCRIPTION		Page 6 of 8
Product	Name COSMOS Network Monitor	Reg. no. 211104A	Category STPR	

If you want to produce reports you must also execute the command

@SET-FILE-ACCESS COSMON-LOG:LOGS R,,

The RT-program is stopped by the SINTRAN command

@ABORT COSMON↓

5.3 Running the COSMON Window program

The monitoring part of the COSMOS Network Monitor consists of only one program. When this is started

@COSMON-WIND↓

the operator is asked on which system the COSMON Main RT-program is running. The operator may in this way be miles away from the machine where the test part is running and still get a status display on his/her terminal. When this has been specified, the status display on the terminal will start.

You may shift pages with the <↑> and <↓> keys. Status will be continuously updated until the operator wants to stop it. This is done by pressing the <EXIT> or the <CR> key.

Only one COSMON Window program per running RT-program may be started at the same time. Remember the cost if you choose to set up a connection between the test part and the monitoring part over a public network.

5.4 Producing Reports

The COSMON Main RT-program logs all changes in status for those entries in the configuration file which have been specified to be logged. Since this logging file is rather tiresome to read, you may produce reports which are easier to read. You may also produce statistics reports over the network access.

Install the enclosed standard report production tool REPRO for ND-100 (Reg.no. 250196C) by running the REPRO installation job, unless it is already installed on your machine.

Log in as the user where you have installed the report part. The reports are produced through the COSMON-SERV(ICE) program. Before you produce a report from the logging file you must merge the configuration file and the logging file. This is done in

Date 87.02.06		Norsk Data A.S PROGRAM DESCRIPTION	Page 7 of 8
Product	Name COSMOS Network Monitor	Reg. no. 211104A	Category STPR

COSMON-SERVICE with the command:

@COSMON-SERV↓

COSMON-SERVICE:SAVELOG↓

To produce a report from one of your merged files, you execute the command:

COSMON-SERVICE:REPORT↓

You may choose between three different types of reports:

DETAIL - an easier-to-read version of the logfile for connections

GLOBAL - a statistics report for connections

SERVER - an easier-to-read version of the logfile for servers

The reports will be written to the file

COSMON-OUTRP:TEXT

unless you specify another file name.

Further instructions are given in the COSMOS Network Monitor Operator Guide.

Date 87.01.27		Norsk Data A.S PROGRAM DESCRIPTION	Page 8 of 8
Product	Name COSMOS Network Monitor	Reg. no. 211104A	Category STPR

6 APPENDIX A

6.1 Finding out the status of the COSMON Main RT-program

A useful command is the SINTRAN command:

@LIST-RT-DESCRIPTION COSMON↓

It gives the status of the RT-program, which should be

ACTIVE or
IN TIME QUEUE

when the program is running. If the state is PASSIVE, the COSMON Main RT-program needs to be restarted or in some cases reloaded.

ND SOFTWARE LIBRARY DISKETTE

PAGE 1

Containing : COSMOS Network Monitor

Directory Name : 211104A01-XX-01S

User Name : FLOPPY-USER

Nr	File name	Type T	File access:			Pages	Bytes
			Public	Friend	Own		
0	COSMON-WIND-A01	PROG I	R	RWACD	RWACD	44	274432
1	INST-COSMON-A01	PROG I	R	RWACD	RWACD	61	190842
2	files using 105 pages. 148 pages reserved out of 148 pages.						

ND SOFTWARE LIBRARY DISKETTE

PAGE 1

Containing : COSMOS Network Monitor

Directory Name : 211104A01-XX-02S

User Name : FLOPPY-USER

Nr	File name	Type	T	File access:			Pages	Bytes
				Public	Friend	Own		
0	COSMON-MAIN-A01	PROG	I	R	RWACD	RWACD	65	286720
1	COSMON-DEF-A01	CONF	I	R	RWACD	RWACD	2	1907
2	COSMON-LOAD-A01	MODE	I	R	RWACD	RWACD	2	472
3	COSMON-SERV-A01	PROG	I	R	RWACD	RWACD	13	268288
4	REP-COSMON-A01	RPRT	I	R	RWACD	RWACD	31	61440
5	COSMON-STAT-A01	LOOK	I	R	RWACD	RWACD	2	233
6	files using 115 pages. 148 pages reserved out of 148 pages.							

ND SOFTWARE LIBRARY DISKETTE

PAGE 1

Containing : COSMOS Network Monitor

Directory Name : 211104A01-XX-01D

User Name : FLOPPY-USER

Nr	File name	Type T	File access:			Pages	Bytes
			Public	Friend	Own		
0	COSMON-MAIN-A01	PROG I	R	RWACD	RWACD	65	286720
1	COSMON-DEF-A01	CONF I	R	RWACD	RWACD	2	1907
2	COSMON-LOAD-A01	MODE I	R	RWACD	RWACD	2	472
3	COSMON-SERV-A01	PROG I	R	RWACD	RWACD	13	268288
4	REP-COSMON-A01	RPRT I	R	RWACD	RWACD	31	61440
5	COSMON-STAT-A01	LOOK I	R	RWACD	RWACD	2	233
6	COSMON-WIND-A01	PROG I	R	RWACD	RWACD	44	274432
7	INST-COSMON-A01	PROG I	R	RWACD	RWACD	61	190842
8	files using 220 pages. 607 pages reserved out of 610 pages.						