

NORD SOFTWARE LIBRARY DISKETTE

CONTAINING : SUBSYSTEM PACKAGE II

DIRECTORY NAME : ND-10400A
USER NAME : FLOPPY-USER

FILE 0 : (ND-10400A:FLOPPY-USER)FMAC-1403C:BFUN#1
FILE 1 : (ND-10400A:FLOPPY-USER)MAC-1415C:BFUN#1
FILE 2 : (ND-10400A:FLOPPY-USER)QED-1644L:BFUN#1
FILE 3 : (ND-10400A:FLOPPY-USER)F32-MAC-1628C:BFUN#1
FILE 4 : (ND-10400A:FLOPPY-USER)F32-FMAC-1920B:BFUN#1
FILE 7 : (ND-10400A:FLOPPY-USER)NPL-1896D:BFUN#1

16 MARCH 1982

NORD SOFTWARE LIBRARY OBJECT DESCRIPTION		PAGE 1 OF <u>1</u>	
PROGRAM	NAME MACF		PROGRAM NUMBER MAC-1408 C
REFERENCE	DATE April -78	NAME RJO	PROGRAM CATEGORY A
REVISED	DATE	NAME	REVISION LOG FOR PROGRAM ALL MAC ASSEMBLERS
EXPIRED	DATE	NAME	NEW PROGRAM NUMBER
COMPUTERS	☐ 1 ☐ 2B ☐ 5 ☒ 10 ☐ 12 ☐ 20 ☐ 50 ☐ ____		
OPERATING SYSTEMS	☐ TSS ☒ SIN III M ☐ SIN III C ☐ ALONE ☐ ____		
TYPE	☒ BINARY ☐ OCTAL ☐ BRF ☐ RB ☐ ____		
DOCUMENTATION	☐ SYSTEM DESCRIPTION ☐ USER DESCRIPTION ☒ MANUAL TITLE <u>MAC Users Guide</u>		
ADDRESS SPACE	SIZE Approx. 13 K + Table		BOUNDARIES 144600<177777
	START ADDRESS 177777		RESTART ADDRESS 177775
PURPOSE	Assembler for NORD-10		

LOADING/OPERATING PROCEDURE, USE

② PLACE T-R

② DUMP "MACF" ,177777,177775

or

② DUMP-REENTRANT. MACF, 177777, 177775, T-R



PROGRAM	NAME MAC		PROGRAM NUMBER MAC-1415 C
REFERENCE	DATE April -78	NAME RJO	PROGRAM CATEGORY A
REVISED	DATE	NAME	REVISION LOG FOR PROGRAM ALL MAC ASSEMBLERS
EXPIRED	DATE	NAME	NEW PROGRAM NUMBER
COMPUTERS	☐ 1 ☐ 2B ☐ 5 ☒ 10 ☐ 12 ☐ 20 ☐ 50 ☐ _____		
OPERATING SYSTEMS	☐ TSS ☒ SIN III M ☐ SIN III C ☐ ALONE ☐ _____		
TYPE	☒ BINARY ☐ OCTAL ☐ BRJ ☐ RB ☐ _____		
DOCUMENTATION	☐ SYSTEM DESCRIPTION ☐ USER DESCRIPTION ☒ MANUAL		
	TITLE MAC Users Guide		
ADDRESS SPACE	size Approx. 13 K + Tables		BOUNDARIES 145600<177777
	START ADDRESS 177777		RESTART ADDRESS 177775
PURPOSE	Assembler for NORD-10		

LOADING/OPERATING PROCEDURE, USE

@PLACE T-R

@DUMP "MAC" , 177777, 177775

or

@ DUMP-REENTRANT, MAC, 177777. 177775. T-R

PROGRAM	NAME	PROGRAM NUMBER
	QED	SUT-1644L
		PART OF ND-NUMBER 10005Q,RS10044N,P,Q 10400A
COMPUTERS	X 10 ! . 12 ! . 50 ! X 100 ! . 500 ! !	
INSTR.SET	. 48 BIT FL. ! . 32 BIT FL. ! . COMMERCIAL !	
OP.SYSTEM	X SIN III VS ! . SIN III RT ! . ALONE !	
PROG.TYPE	X BINARY ! . BRF ! . SYMBOLIC !	
DOCUMEN- TATION	NUMBER: ND-60.031.04 TITLE: QED USERS MANUAL	
ADDRESS SPACE (BIN.PROG)	BOUNDRIES: 0<22777 START ADDRESS: 0	RESTART ADDRESS: 1
PURPOSE	CONVERSATIONAL EDITOR.	

LOADING/OPERATING PROCEDURE, USE

This program uses all the virtual memory except the program area as buffers (56K).

Example of dump:

DUMP-REENTRANT QED-1644L,0,1,QED-1644L:BPUN

PROGRAM	NAME	PROGRAM NUMBER
	QED	SUT-1644L
		PART OF ND-NUMBER
		10005Q,R,S 10044N,P,Q
		10400A
ISSUED	DATE 80.08.14	BY (INITIALS) BR
REASON	X ERROR CORRECTION	. DIFFERENT ENVIRONMENT
	X CHANGE/ADDITION	

CHANGES

Errors corrected :

1. Some errors when reading a specified interval of lines from a file is corrected.
2. An error when specifying 12 tabulator stops is corrected.

Changes made :

1. The edit character (CTRL)R which skip next "word" is changed to (CTRL)G. (CTRL)R now retypes the old and new line and awaits more edit characters (same as in command buffer editing under SINTRAN III).



PROGRAM	NAME MAC-32		PROGRAM NUMBER MAC-1628 C
REFERENCE	DATE April 78	NAME RJO	PROGRAM CATEGORY A
REVISED	DATE	NAME	REVISION LOG FOR PROGRAM ALL MAC ASSEMBLERS
EXPIRED	DATE	NAME	NEW PROGRAM NUMBER
COMPUTERS	☐ 1 ☐ 28 ☐ 5 ☒ 10 ☐ 12 ☐ 20 ☐ 50 ☐ _____		
OPERATING SYSTEMS	☐ TSS ☒ SIN III M ☐ SIN III C ☐ ALONE ☐ _____		
TYPE	☒ BINARY ☐ OCTAL ☐ BRP ☐ RB ☐ _____		
DOCUMENTATION	☐ SYSTEM DESCRIPTION ☐ USER DESCRIPTION		☒ MANUAL
	TITLE <u>MAC User's Guide</u>		
ADDRESS SPACE	SIZE	BOUNDARIES 145600<177777	
	START ADDRESS 177777	RESTART ADDRESS 177775	
PURPOSE	Assembler for NORD-1Ø		

LOADING/OPERATING PROCEDURE, USE

NB! This is a version for 32-bits floating point hardware!

@ PLACE T-R

@ DUMP "MAC-32", 177777, 177775

or

@ DUMP-REENTRANT, MAC-32, 177777, 177775, T-R



PROGRAM	NAME MACF-32		PROGRAM NUMBER MAC-1920 B
REFERENCE	DATE April -78	NAME RJO	PROGRAM CATEGORY A
REVISED	DATE	NAME	REVISION LOG FOR PROGRAM ALL MAC ASSEMBLERS
EXPIRED	DATE	NAME	NEW PROGRAM NUMBER
COMPUTERS	☐ 1 ☐ 28 ☐ 5 ☒ 10 ☐ 12 ☐ 20 ☐ 50 ☐ _____		
OPERATING SYSTEMS	☐ TSS ☒ SIN III M ☐ SIN III C ☐ ALONE ☐ _____		
TYPE	☒ BINARY ☐ OCTAL ☐ BRJ ☐ RB ☐ _____		
DOCUMENTATION	☐ SYSTEM DESCRIPTION ☐ USER DESCRIPTION ☒ MANUAL TITLE <u>MAC II User's Guide</u>		
ADDRESS SPACE	SIZE	BOUNDARIES 144600<177777	
	START ADDRESS 177777	RESTART ADDRESS 177775	
PURPOSE	Assembler for NORD-10		

LOADING/OPERATING PROCEDURE, USE

NB! This is a version for '32-bits floating point hardware!

② PLACE T-R

② DUMP "MACF-32", 177777, 177775

or

② DUMP-REENTRANT, MACF-32, 177777, 177775, T-R



NORD SOFTWARE LIBRARY
PROGRAM DESCRIPTION

PAGE 1 OF 1

PROGRAM	NAME NORD-PL	PROGRAM NUMBER NPL-1896D PART OF 10005L, M, N, O, R, S, 10040GA NO NUMBER 10044K, I, M, N, P, Q
COMPUTERS	☒ 10 ☐ 12 ☐ 50 ☒ 100 ☐ 500 ☐ _____	
INSTRUCTION SET	☐ 48 BIT FL ☐ 32 BIT FL ☐ COMMERCIAL ☐ _____	
OPERATING SYSTEMS	☒ SIN III VS ☐ SIN III RT ☐ ALONE ☐ _____	
PROGRAM TYPE	☒ BINARY ☐ BRF ☐ SYMBOLIC ☐ _____	
DOCUMENTATION	NUMBER _____ TITLE <u>NORD-PL Users Guide</u>	
ADDRESS SPACE (For Binary Programs)	BOUNDARIES 0 < 74215	
	START ADDRESS 0	RESTART ADDRESS 1
PURPOSE	Compiles NORD-PL-programs into MAC-assembly code.	

LOADING/OPERATING PROCEDURE, USE

Non-reentrant load :

@PLACE <input file>
@DUMP "NPL-1896D",0,1

Reentrant load :

@DUMP-REENTRANT NPL,0,1, <input file>