

# TechNest Smart Home App — User Guide

Product Documentation · Version 3.2 · Published August 2026

## 1. Getting Started

TechNest is a smart home application that lets users control connected devices such as lights, thermostats, and locks from a single mobile app. To begin using TechNest, download the app from your device's app store, create an account using your email address, and connect your first device by scanning the QR code printed on the device itself.

## 2. Account Recovery

If you are unable to sign in, you can regain access to your account by requesting a reset link. Open the app, select 'Trouble signing in?' on the login screen, and enter the email address linked to your account. A recovery link will be sent to that email and expires after 30 minutes.

## 3. Device Compatibility

TechNest currently supports devices that use Wi-Fi (2.4GHz only) or Bluetooth Low Energy. Devices operating on a 5GHz-only network are not supported at this time. The app is compatible with iOS 15 and above, and Android 10 and above.

## 4. Automation Rules

Users can create automation rules that trigger actions based on time, location, or another device's state. For example, a rule can be set to turn on the porch light at sunset, or to lower the thermostat automatically when the user's phone leaves a defined home radius. Up to 20 automation rules can be active at once on the Free plan; the Pro plan allows unlimited rules.

## 5. Subscription Plans

TechNest offers a Free plan and a Pro plan. The Free plan supports up to 10 connected devices and 20 automation rules at no cost. The Pro plan costs \$4.99 per month and unlocks unlimited devices, unlimited automation rules, and 30-day video history for compatible cameras.

## 6. Data & Privacy

Device usage data is stored securely and is never sold to third parties. Users can request a full export of their data or permanent account deletion at any time from the Settings menu under 'Privacy & Data'. Deletion requests are processed within 7 business days.

## **7. Troubleshooting Connectivity**

If a device repeatedly disconnects, first confirm it is within range of the Wi-Fi router and that the router is broadcasting a 2.4GHz network. Restarting both the device and the home router resolves most connectivity issues. If problems persist, remove the device from the app and re-add it using the QR code setup process.