GE UNI RS DL

CONTROL UNIT FOR TWO-LEAF GATES




INSTRUCTIONS AND WARNINGS FOR INSTALLATION, USE AND MAINTENANCE

SAMT® Garage & Gate Automation


LIFE home integration

STANDARD INSTALLATION





Tab. 1: Components and devices of a typical GE UNI R DL automation.

Tab. 2: Description of the content of a GE UNI R DL control unit pack.



GEBOX ASSEMBLY INSTRUCTIONS.





List of electric cables

The cables needed may vary depending on the installation and type and quantity of devices installed.

The cables used in the installation must be IEC 60335 compliant.

Pos.	Connection	Type of cable
1	Electricity supply line	3x1,5 mm² cable
2	Power supply	Supplied with motor
3	Flashing light	2x1 mm² cable
4	Radio aerial	Screened RG58 50 Ω cable
5	Tx Photo	2x1 mm² cable
6	Rx Photo	4x1 mm² cable
7	Selector	3x1 mm² cable
8	Internal button panel.	3x1 mm² cable
9	Sensitive strip (signal)	2x1 mm² cable

FUSES
Two internal Fuses

a)F1 protects the secondary 24v supply against transformer overload
Technical: Mini fuses 5x20 T1.6A certificated by IEC 60127 or EN 60127

b)F2 protects the primary 24v supply against motor overload
Technical: Mini fuses 5x20 T3.15A certificated by IEC 60127 or EN 60127

ATTENTION: the cables used must be suited to the type of installation.
It is the Fitter's responsibility to choose appropriate material.

- Use the power supply cable provided with the operator only.
- The power cable provided may not be extended or shortened
- All wires must be unsheathed as little as possible (6mm at the most), as close as possible to the connection terminals, in order to prevent accidental contact with live parts should the cables disconnect from the terminals.
- Do not pre-seal cables to be fastened to the terminals using screws.
- If it is possible that wires subject to voltage higher than 50 Volt RMS and very low voltage safety wires may come into contact with one another, wires with voltage higher than 50 volt RMS must be insulated with a sheath; or the very low voltage safety wire must have an insulating sheath at least 1mm thick.
- No external connection cables must be of the flat twin tinsel cord type.

Setting up the electric system and connection to the mains supply

This manual does not describe how the electrics system should be prepared for connection to the mains. It does, however, give the following warnings:

- **The electricity supply line must be installed and connected by an authorised electrician or professional fitter.**
- **The electricity supply must be adequately protected against short circuits and static discharge.**
- **The power supply network must contain an omnipolar circuit breaker with a contact opening distance equal to or greater than 3.5 mm that assures the complete disconnection of the power supply.**


Control unit connections

Fitters must make the connections of the 230 Vac 50 Hz electricity supply, and the various automation devices.
Connections between the control unit, motor, encoder and transformer have already been performed by the Manufacturer.


- Once the connections to the control unit have been made, the Fitter must use bands to join adjacent wires into groups of 2, 3 or 4 in order to prevent them coming away from the terminal board: bands must be attached as close as possible to the terminals, no more than 10mm away, taking care not to damage wire insulation. No cable may remain unpaired.
- The bands are only for unsheathed cables (sheathed cables are held in place by the sheath).
- Pay careful attention not to pair wires with voltages higher than 50 Volt RMD with lower voltage wires.
- The wiring performed internally by the manufacturer is already equipped with clamping bands.


Indicator LEDs

There is a row of 6 LEDs on the right hand side of the board, under the terminals. the NC inputs, stop and photo, the corresponding LEDs L7, L11 and L12 are normally lit; for the NO inputs open, close and step, the corresponding LEDS L8, L9 and L10 are normally off. These LEDs therefore indicate any malfunction of the connected devices.





GE UNI R DL



























1 - 2	**Aerial:** aerial cable input 1 sheath, 2 cables. Use a RG58- 50ohm cable	
6	**Common:** for stop, open, close, step and photo inputs.	
6 - 7	**STOP*** : programmable NC input, commands gate stoppage. Can be connected to safety devices such as an emergency stop button. When the command is released automatic closure never occurs and a new movement command must be given. **Leave jumpered if no device is envisaged**	
6 - 8	**OPEN:** NO input, commands gate opening.	
6 - 9	**CLOSE:** NO input, commands gate closure.	
6 -10	STEP: NO input, commands gate movement according to the following cycles:	
	SEMI-AUTOMATIC MODE: Open, stop, close, stop. 4-STEP MODE Open, pause, close, pause. 4-STEP with stop : OPEN-STOP-CLOSE-STOP CONDOMINIUM MODE: Open.	
6 -11	**PHOTO 1*:** programmable NC input for photocells or safety devices. Causes gate stoppage during both opening and closure. Motion resumesduring opening when the photocell or safety device is disengaged.Leave jumpered if no device is envisaged.	
6 - 12	**PHOTO:** NC input for photocells or safety devices. Does not intervene during gate opening; during closure causes reversal of gate motionuntil open. **Leave jumpered if no device is envisaged.**	
16 - 13	**ELECTROLOCK** 12 V ac output for connection of the 12 Vac 15 VA electrolock.	
16 - 14	**INDICATOR LIGHT**: 24Vac 3W max output, for connecting an indicator light that copies the function of the flashing light during movement and that remains on when the gate is open.	
16 - 15	**24 V ac OUTPUT**: power supply for various devices, 200 mA max.	
16	**ELECTROLOCK, INDICATOR LIGHT AND 24 V ac OUTPUT COMMON.**	
17	**PHASE 1, CAPACITOR**	**OPERATOR 2 POWER SUPPLY**: 230 Vac 50 Hz output 300 W max.
18	**COMMON**	
19	**PHASE 2, CAPACITOR**	
20	**FASE 1, CONDENSATORE**	**OPERATOR 1 POWER SUPPLY**: 230 Vac 50 Hz output 300 W max.
21	**COMMON**	
22	**FASE 2, CONDENSATORE**	
23 - 25	**FLASHING LIGHT**: 230 Vdc 25W max output for connecting a SPLENDOR SRL flashing light characterised by three flashing modes: 1) slow during door opening; 2) fast (flashing times halved) during closure. 3) three flashes and a pause to indicate a fault state or travel identification.	
24 - 25	**COURTESY LIGHT**: 230 Vdc 40W max. output for connecting a courtesy light that switches on at the start of each movement (opening or closure) and is characterised by an adjustable on time.	
25	**FLASHING OR COURTESY LIGHT POWER SUPPLY COMMON.**	
L 1 L 2	**230Vac 50Hz POWER SUPPLY**, fusable input L2.	

PROGRAMMING THE CONTROL BOARD

STOP PLATES - Ensure that the open and close stop plates are set to the correct position
SINGLE MOTOR - In the case of a single gate installation connect the motor into terminals 20-21-22 before programming enter the options menu 2 and select single motor activated (led 4 on)
ISOLATION SWITCH - A means of isolation must be connected to the incoming supply cable, local to the control board, to aid programming.


PHASE 1



POWERING UP - With the power off, hold the start button down ,reinstate the power supply and release the button. The red led's will flash

NOTE: Carrying out this operation will reset the previously stored perameters


PHASE 2



AUTOMATIC PROGRAMMING

- Position the gate leafs at 45 degrees.
- Press the start button for 5 seconds, the 5 leds at the top of the board will light and start to flash.
- Press the start button and motor 2 should run closed. If it runs open,you must invert the cables of electric motors to invert the movement. The red and green led's will flash.
- Once motor 2 has closed, motor 1 will then close, once closed it will re-open followed by motor 2. Once both motors are open, motor 1 will start to close again followed by motor 2.
- Once both motors have completed this full close cycle the programming is complete and the red led's will light and green led's will flash. The gates will now operate on the start button in semi automatic mode.**OPEN-STOP-CLOSE-STOP**
- This programming will set a default leaf delay time. If you wish to change this please refer to the manual set up instructions (page 10)
- You can now encode the radio transmitters and enter the programming menus to suit the type of operation required.

PHASE 3



PROGRAMMING RADIO TRANSMITTERS
TOTAL OPENING COMMAND

- Press the radio icon button (top left) once. The left green led will light and the first (L to R) of the top 5 led's (A) will light.
- Hold down the button on the transmitter that you want to perform a total opening of the gates. Once the top 5 led's light the transmitter has been coded.
- To exit wait 25 seconds or push the radio icon button twice.

PEDESTRIAN OPENING COMMAND (ACTIVE ON MOTOR 1)


- Press the radio icon button (top left) **TWICE**. The left green led will light and the second (L to R) of the top 5 led's (B) will light.
- Hold down the button on the transmitter that you want to perform a pedestrian opening of the gate. Once the top 5 led's light the transmitter has been coded.

SEMIAUTOMATIC mode is enabled: by giving the 'STEP' command, the automation changes movement following the sequence 1 –**OPEN** 2 – **STOP** 3 – **CLOSE** 4 – **STOP**. **Automatic re-closure is not enabled.**

Once programming is complete the START button acts as a step command


DELETING RADIO CONTROL TRANSMITTERS

The control unit is fitted with a built-in radio receiver with a 1 channel 1000-code memory, with a 433.92 MHz frequency with LIFE Rolling Code and Auto code encoding.



DELETING A SINGLE RADIO TRANSMITTER

- Press the radio icon button (top left) for 5 seconds. The left green led will light and start flashing.
- Hold down the button on the transmitter you wish to delete until all the top 5 led's light. The transmitter has been deleted
- To exit wait 25 seconds or push the radio icon button once.



DELETING ALL RADIO TRANSMITTERS.

•

flashing.
five more seconds, the first two and
flash alternatively. All




Photo Input


Opening - No effect, continues to open.

Photo1 input

Opening - Stops and continues opening when

PROGRAMMING MENUS

In this mode by pressing the start button or



SELECTING A PAUSE TIME

•


Press and to set the various **PAUSE TIME** values.

Wait 25 seconds or press again to quit.

LEDS ON	PAUSE TIME
○○○○○○	AUTOMATIC RE-CLOSURE IS NOT ENABLED
●○○○○○	5 s
●●○○○○	10 s
●●●○○○	30 s
●●●●○○	60 s
●●●●●●	120 s

OPTION MENU 1


Press the option button (bottom right) once, then press in sequence to scroll through the options as shown by the five flashing of the led indicates the option selected. The + button is used to select the function indicated flashing. The – button will de select the option, led off. To exit continue to scroll through to



LEDS	OPTIONS 1
○○○○○○	**No function is active.**
●○○○○○	**Residential : The automation closes automatically after the set PAUSE TIME**
○●○○○○	**Functioning mode as OPEN – STOP – CLOSE – STOP.**
○○●○○○	**Activation of the electrolock.**
○○○●○○	**Input STOP becomes FOTO2, the photocell is activated also for the opening phase** (See page 7 for details)
○○○○●○	**When gate has been opened, after passing between the photocells the gates will close**

OPTION MENU 2


Press the option button (bottom right) for 5 seconds, then press in sequence to scroll through the options as shown by five led's at the top. The flashing of the led indicates the option selected. The + button is used to select the function



LEDS	OPTIONS 2
○○○○○○	**No function is active.**
●○○○○○	**Deceleration when reaching end points**
○●○○○○	**Activate extra-stroke on closing and opening.**
○○●○○○	**Preflashing**
○○○●○○	**Single motor activated (connect on terminals 20-21-22)**
○○○○●○	**Soft Start**

FORCE

The force function regulates the thrust and the speed of the automation.



Wait 25 seconds or press  again to quit.


LEDS ON	FORCE VALUE
	Minimum
	Maximum

OBSTACLE DETECTION

The automation is fitted with an obstacle detection system. The automation inverts its movement when it strikes an

fies an obstacle, the automation inverts the motion and performs


fies an obstacle on opening, the automation performs a short reversal of motion, before



Wait 25 seconds or press again to quit.

LEDS ON	OBSTACLE DETECTION
	NO OBSTACLE DETECTION
	MINIMUM
	MAXIMUM

MANUAL PROGRAMMING




POSITION THE GATE AT 45 DEGREES

- Press the start button for 5 seconds, the first of the 5 top led's light and flash.
- The programming can be done manually with a radio transmitter or a switch connected across terminal 6 & 10 .




LEARNING THE CLOSING LIMIT

- Give a command with a radio transmitter or with a switch connected across terminals 6 & 10. Motor 2 will run closed and shut off when it drives against the close stop. The right red led will remain on.
- Give a second command using the radio transmitter or switch and motor 1 will run closed and shut off when it drives against the close stop. The left red led will remain on.



LEARNING THE OPEN LIMIT

- Give a command with a radio transmitter or with a switch connected across terminals 6 & 10. Motor 1 will run open. To set the required opening leaf delay, give a second command when the first gate has achieved the required delay.
- The two motors will run to the open stops and shut off. The two red led's will light.



LEARNING THE FULL CLOSING TRAVEL

- Give a command with a radio transmitter or with a switch connected across terminals 6 & 10. Motor 2 will run closed. To set the required closing leaf delay give a second command using the radio transmitter or switch when motor 2 has achieved the required delay.
- The two motors will run to the closing stops and shut off. To verify the completion of the manual programming the two red led's will light and the green led's will flash.

If the result is not satisfactory carry out the procedure again.

If the result is not satisfactory to reset the power and start over from scratch.

5 GENERAL INFORMATION

It is strictly forbidden to copy or reproduce this instruction manual without written permission to do so and subsequent verification by **LIFE home integration**. Translation into other languages of all or part of the manual is strictly forbidden without previous written authorisation from and subsequent verification by **LIFE home integration**. All rights on this document are reserved.
LIFE home integration will not accept responsibility for damage or malfunctions caused by incorrect installation or improper use of products and Users are therefore recommended to read this manual carefully **LIFE home integration** will not accept responsibility for damage or malfunctions caused by the use of the automation together with the devices of other manufacturers; such action will render the warranty void.
LIFE home integration will not accept responsibility for damage or injury caused by non-compliance with the installation, set up, maintenance and use indications contained in this manual and the safety instructions described in the SAFETY INSTRUCTIONS AND WARNINGS chapter.
With the aim of improving its products, LIFE home integration reserves the right to bring about alterations to them at any time, without giving prior notice. This document conforms to the state of the automation at which it is provided when released for sale.

5.1 INFORMATION ON THE MANUFACTURER

LIFE home integration is the manufacturer of the **RG1 24DL** control unit (referred to for short as "control unit") and the owner of all rights concerning this document.. The Manufacturer's information as required by Machinery Directive 98/37/EC is given below:

- Manufacturer: **LIFE home integration**
- Address: **Via S.Pertini,3/5 – 31014 COLLE UMBERTO (TV) Włochy**
- Telephone: **+ 39 0422 809 254**
- Fax: **+ 39 0422 809 250**
- http: **www.homelife.it**
- e-mail: **info@homelife.it**

The identity plate bearing the information on the Manufacturer is fixed to the control unit. The plate specifies the type and date (month/year) of manufacture of the product.
For further information on technical and/or commercial issues and technician call-out and spares requests, Clients may contact the Manufacturer or area representative from which the product was purchased.

5.2 INTENDED USE

- **The RG1 UNIR DLcontrol unit has been exclusively designed to command 1 electromechanical operator with 230 Vac power supply destined to motorising 'residential' type leafs. Any usage differing from that described above is forbidden.**
- **The control unit may only be used with other LIFE products.**
- **The manufacturer declines all responsibility for damage caused by improper use. All risks are the fitter's responsibility and the warranty shall be rendered void.**
- **The control unit may not be installed or used in potentially explosive environments.**
- Motorised gates must conform to current European standards and Directives, including EN 12604 and EN 12605.
- The control unit may only be used when in perfect working order and in compliance with the intended use, in the awareness of safety and hazard conditions and in compliance with the instructions for installation and use.
- Any dysfunctions that may pose threats to safety must be eliminated immediately.
- The control unit may not be used in environments prone to flooding.
- Do not use the operator in environmental conditions characterised by harsh atmospheric agents (e.g. salty air).

6 SAFETY INSTRUCTIONS AND WARNINGS

6.1 General instructions and warnings

- **This manual is designed for use by PROFESSIONAL FITTERS only. Installation of the control unit requires practical and theoretical knowledge of mechanics, electrics and electronics as well as current sector legislation and regulations.**
- **Once the control unit has been installed, it is forbidden for users to perform any operation on the control unit even following the instructions in this manual, which, as mentioned previously, are intended for use by qualified personnel only.**
- **Fitters must operate in compliance with the following: law 46/90, directive 98/37/EC, 73/23/EEC, 89/336/EEC and subsequent amendments. He/she must also make constant reference to harmonised standards EN 12453 and EN 12445.**
- **The indications given in this manual must always be observed when installing, connecting, adjusting, testing and setting the control unit. The Manufacturer declines all responsibility for damage or injury caused by non-observance of the instructions contained in this manual.**
- The Manufacturer declines all responsibility for damage and faults to the control unit caused by non-observance of the instructions contained in this manual.
- Keep this manual in a safe and easily accessible place so that it can be consulted rapidly when necessary.
- During installation, connection, trial run and usage of the control unit, observe all applicable accident prevention and safety regulations.
- In the interests of safety and optimal functioning of the control unit, only use original spares, accessories, devices and fastening apparatus.
- Do not perform alterations on any control unit device or component. This type of operation may cause malfunctions. The manufacturer declines all responsibility for damage caused by products that have been modified.
- Should liquids penetrate inside the control unit, disconnect the electricity supply and contact the Manufacturer's Assistance Service immediately; use of the control unit in such conditions may cause hazard situations.
- In the event of long periods of inactivity, in order to prevent the leakage of harmful substances from the battery (optional), it should be removed, stored in a dry place and recharged periodically.
- In the case of faults or problems that cannot be resolved using the information contained in this manual, contact the Manufacturer's assistance service.

6.2 Storage instructions and warnings

- **The Manufacturer declines all responsibility for damage and faults to control unit functioning caused by non-compliance with the storage instructions given below.**
- The control unit must be stored in closed, dry places, at room temperatures of between –20 and +70°C and raised off the ground.
- Keep the control unit away from sources of heat and naked flames, which could damage it and cause malfunctions, fires or hazard situations.

7 INSTALLATION

ATTENTION: Important safety instructions. Follow all instructions carefully, incorrect installation may cause serious injury.
Before commencing installation we highly recommend reading the instructions and warnings contained in this manual carefully (see the SAFETY INSTRUCTIONS AND WARNINGS Chap) and observing the instructions it contains.

7.1 Instructions and warnings for installations

- **Before commencing installation read the. SAFETY INSTRUCTIONS AND WARNINGS chapter carefully**
- **The PROFESSIONAL FITTER who installs the control unit is responsible for performing risk analysis and regulating the automation's safety devices consequentially.**
- **The Fitter must check that the temperature range declared on the control unit is suited to the place in which the device is installed.**
- **Any normally open/off buttons installed for the activation of the operator must be positioned so that they are within view of the gate but distant from moving parts. Unless said commands operate using keys, they must be positioned at a minimum height of 1.5m and not accessible to unauthorised persons.**
- During installation, make constant reference to harmonised standards EN 12453 and EN12445.
- Ensure that the individual devices to be installed are compatible with the **RG1 UNIR DL** control unit. Do not proceed if even just one device is unsuitable for the intended use.
- Ensure that the place of installation of the central unit is not prone to flooding, does not contain sources of heat or naked flames, fires or hazard situations in general.
- During installation, protect control unit components in order to prevent liquids (e.g. rain) and/or foreign bodies (earth, gravel, etc) penetrating inside.
- Connect the control unit to a power supply line created in compliance with current regulations and earthed and fitted with a power supply sectioning switch.
- Wrapping materials must be disposed of in compliance with local regulations.
- Wear protective goggles when making holes for clamping.

In the event of work at heights of over 2m from the ground, for example for the installation of the indicator lamp or aerial, fitters must be equipped with ladders, safety harnesses, protective helmet, and all other equipment required by law and the standards governing this kind of work. Refer to Directive 89/655/EEC amended by 2001/45/EC.

8 TESTING AND TRIAL RUN

- **The testing and trial run must be performed by a COMPETENT PERSON supervised and aided by a PROFESSIONAL FITTER. It is the responsibility of the person who tests and sets up the automation (of which the control unit is a part) to perform the checks required in accordance with the risks existing and to check conformity with the relevant legislation and standards, in particular with EN standard 12445, which governs the methods for performing trials on gate automations and EN standard 12453 that specifies the performance requisites concerning safety of use.**
- The testing and trial run are the most essential phases of installation for guaranteeing maximum operating safety.
- The checks and procedures for testing may also be used for routine checks on the automation and its devices.
- The automation may only be tested if a non-hazardous force tolerance has been set. Force tolerance must be adjusted to a minimum value so as to exclude the danger of injury during closure.
- Adjust the maximum force in line with EN standard 12445.
- Never touch the gate or moving parts when they are in motion.
- Remain at a safe distance when the gate is in motion: only pass when the gate is completely open and immobile.
- In the event of malfunctions (noisiness, jerky movements, etc.) suspend the use of the automation immediately: failure to observe this rule may entail serious hazards, risks of accidents and/or serious damage to the gate and the automation.
- Always remember that the following residual risks exist when the gate is in movement:
  a) impact and crushing against the main closure edge (against the single leaf or between the two leaves);
  b) impact and crushing in the opening area;
  c) cshearing between the moving and the fixed guides and support during movement;
  d) mechanical risks caused by movement.

8.1 Testing

During testing, ensure that the measurement of the gate's impact force has been performed in accordance with EN standards 12445 and 12453.

- **Check that the indications given in the SAFETY INSTRUCTIONS AND WARNINGS and INSTRUCTIONS AND INDICATIONS FOR INSTALLATION chapters have been carefully observed.**
- **Ensure that the automation is correctly adjusted and that the protection and release systems are in good working order.**
- Using the key selector or the radio control perform gate opening and closure tests and ensure that each movement of the gate corresponds to the control unit settings. Perform as many checks as necessary to be certain of perfect operation.
- Ensure the correct operation of the LEDs on the keyboard of the control unit (see specific manual).
- In particular, for photocell checks, check that there is no interference with other devices. Pass a cylindrical tube with a diameter of 5cm and a length of approximately 30 cm through the optic axis that connects the two photocells. Perform this check firstly close to the transmitter and then close to the receiver and lastly halfway between the two.
- In all three cases, the device must intervene by passing from the active state to the alarm state and vice versa, thus causing the action set on the control unit: for example, during a closure manoeuvre it must cause inversion of movement.
- Perform the photocell operation test required in compliance with EN standard 12445 p. 4.1.1.6. The results must satisfy EN standard 12453 p. 5.1.1.6.

ATTENTION: once the automation has been tested, the parameters set must not be altered. If further adjustments (e.g. alterations to the voltage value) are made, all the checks required for testing and compliance with EN standard 12445 must be repeated.

8.2 First usage

The automation may only be used for the first time once all the checks described in the TESTING chapter have been performed successfully. The automation may not be used in precarious or temporary conditions.

a) **Compile a technical file for the automation, which must include at least:**
   - a general mechanical and electrical diagram,
   - risk analysis and solutions adopted for eliminating or reducing risks,
   - manuals of the individual components,
   - list of the components used,
   - instructions for use and warnings concerning use by the owner,
   - system maintenance record
   - declaration of the system's CE conformity

b) Fix a CE marking plate to the gate, bearing at least the following information:
   - Name and address of the party responsible for installation and testing;
   - Type of automation,
   - model,
   - registration number,
   - year of installation,
   - CE mark.

c) Fill in the declaration of conformity and give it to the owner of the automation.
d) Compile the guide with the instruction manual (EN 12635 p. 5.3 and 5.4) and give it to the owner of the automation.
e) Compile the maintenance and improvement log (EN 12635 p. 5.3) and give it to the owner of the automation.
f) Compile the guide containing the instructions for maintenance that provides instructions concerning the maintenance of all automation devices (EN 12635 p. 5.3 and 5.5) and give it to the owner of the automation.
g) Before the first use of the automation, the owner must have been given adequate information concerning hazards and residual risks.

9 SAFETY INSTRUCTIONS AND WARNINGS

9.1 Instructions and warnings for use

- **It is the fitter's duty to perform risk analysis and inform the user/owner of any existing residual risks. Any residual risk detected must be recorded in writing in the operator manual.**
- The following residual risks are usually present in moving gates: impact and crushing against the main closure surface (of the single leaf or between the two leaves); impact and crushing in the opening area; crushing between the mobile and fixed guide and support parts during movement; mechanical risks caused by movement.
- The Manufacturer will not accept responsibility for damage or injury caused by the non-observance of the information on use contained in this manual, and the failure to observe the safety indications given below.
- The Manufacturer declines responsibility for damage and malfunctions caused by non-compliance with the instructions for use.
- Keep this manual in a safe and easily accessible place so that it can be consulted rapidly when necessary.
- Before activating the gate ensure that all persons are at a safe distance.
- Never touch the gate or moving parts when they are in motion.
- Remain at a safe distance when the gate is in motion: only pass when the gate is completely open and immobile.
- Do not allow children to play with gate controls; do not leave radio controls or other control devices within children's reach.
- Prevent children from playing or standing in the vicinity of the gate or the control organs (radio controls). The same precautions should be adopted for disabled persons and animals.
- In the event of malfunctions (noisiness, jerky movements, etc.) suspend the use of the automation immediately:: failure to observe this rule may entail serious hazards, risks of accidents and/or serious damage to the gate and the automation. Contact a PROFESSIONAL FITTER and in the meantime use the gate manually by disconnecting the operator (see the OPERATOR/ACTUATOR RELEASE chapter) OPERATOR/ACTUATOR RELEASE chapter) of the operator manual.
- In order to maintain the automation in efficient conditions, ensure that the operations indicated in the MAINTENANCE chapter are performed at the frequency indicated by a PROFESSIONAL FITTER.
- Examine the installation frequently in order to check that there are no signs of mechanical unbalance, wear and damage to the wires and assembled parts: do not use the operator until the necessary repairs or adjustments have been made.
- Should liquids penetrate inside the control unit, disconnect the electricity supply and contact the Manufacturer's Assistance Service immediately; use of the control unit in such conditions may cause hazard situations. The automation may not be used in these conditions, even with buffer batteries (optional).
- If a problem arises that cannot be resolved using the information contained in this manual, contact the Manufacturer's assistance service.



10 MAINTENANCE

10.1 Maintenance instructions and warnings

- **Once the automation has been tested, the parameters set must not be altered. If further adjustments (e.g. alterations to the voltage value) are made, ALL THE CHECKS REQUIRED FOR TESTING AND COMPLIANCE WITH STANDARDS MUST BE REPEATED.**
- **The Manufacturer declines responsibility for damage or injury caused by non-compliance with the information provided in this manual and the safety instructions provided below**
- **The Manufacturer declines all responsibility for damage and malfunctions deriving from non-compliance with the maintenance instructions.**
- **In order to keep the operator efficient and safe, follow the cleaning, checking and routine maintenance procedures as described in this manual. This is the owner's duty.**
- **Any checking, maintenance or repair work must be conducted by a PROFESSIONAL FITTER**
- **Always switch off the electricity supply in the event of malfunctions, breakdowns and before any other operations in order to avoid the gate from being activated.**
- **Always disconnect the operator's power supply before performing any maintenance or cleaning operation.**
- **The owner is NOT authorised to remove the control unit cover as it contains live parts.**
- **If the power cable is damaged, it must be replaced by the Manufacturer or its technical Assistance service or in any case a person with a similar qualification in order to avoid risks.**
- If the power cable is damaged, it must be replaced by the Manufacturer or its technical Assistance service or in any case a person with a similar qualification in order to avoid risks.
- Do not perform technical or programming modifications on the control unit. Operations of this type may cause malfunctions and/or risk of accidents. The manufacturer declines all responsibility for damage caused by products that have been modified.
- In the event of intervention of automatic or fuse switches, before restoring function conditions identify and eliminate the fault. Request the intervention of a PROFESSIONAL FITTER.
- The disconnection and replacement of the pair of buffer batteries (optional) may be performed by a PROFESSIONAL FITTER only.
- If a fault that cannot be solved following the information contained in the present manual arises, contact the manufacturer's assistance service.
- All maintenance, repair or replacement of parts must be recorded in the maintenance log, which is SUPPLIED AND INITIALLY FILLED IN BY THE FITTER.

10.2 Routine maintenance

Every 6 months a PROFESSIONAL FITTER should repeat the series of tests described for automation testing (see INSTALLATION MANUAL – TESTING AND TRIAL RUN Chap.). – TESTING AND TRIAL RUN Chap.).

11 DEMOLITION AND DISPOSAL

- The control unit is constructed using various materials, which implies the adoption of different disposal procedures. Refer to regulations in force in the country in which the automation is installed, especially with regard to the buffer batteries (if present).
- If present the batteries must be removed from the control unit prior to disposal. Disconnect the control unit from the electricity supply before removing batteries.
- Contact qualified firms for disposal.

ATTENTION: operator disconnection from the mains supply must be performed by a qualified electrician using suitable tools.

Declaration of conformity

CE

under Directive 98/37/EC, appendix II, part B (Manufacturer's Declaration of CE Conformity)

L**IFE Home Integration**
Via S.Pertini 3/5
31014 COLLE UMBERTO (TV)

declares that the following product:

GEUNIR DL control unit

satisfies the essential requisites established in the following directives:

- Low voltage directive 73/23/EEC and subsequent amendments,
- Electromagnetic compatibility directive 89/336/EEC and subsequent amendments,
- Radio and telecommunications equipment directive 1999/5/EC and subsequent amendments.

and satisfies the following standards:

• EN 12445:2000	Industrial, commercial and garage doors and gates – Safety in the usage of motorised doors – testing methods
• EN 12453:	Industrial, commercial and garage doors and gates – Safety in the usage of motorised doors – Requisites
• EN 60204-1:1997	Machinery safety – Electric equipment of the machine – Part 1: general rules.
• EN 60950	Information technology equipment - Safety - Part 1: General requisites
• ETSI EN 301489-3:2001	Electromagnetic compatibility for radio equipment and appliances.
• EN 300220-3:2000	Radio equipment and systems – short band devices – Technical characteristics and testing methods for radio apparatus with a frequency of 25 to 1000 MHz and powers of up to 500mW.

The Manufacturer also declares that it is not permitted for the abovementioned components to be used until such time as the system in which they are incorporated is declared conform to directive 98/37/EC.

COLLE UMBERTO _____

Name of Signor: **MICHELE RUI**

Position: **PRESIDENT**

Signature:



Address: Factory 19, 5 Lyn Parade PRESTONS NSW 2170

Telephone: (02) 9607 4100

Email: sales@SAMT.com.au

www.samtgatemotors.com.au