

AquaPure RO Water Purifier — User & Service Guide

1. Overview & Indicator Lights

The AquaPure RO purifier has three indicator lights on the front panel: POWER (white), PURE (blue) when water is ready, and FILTER (red) when a filter needs replacement.

A steady red FILTER light means a cartridge has reached the end of its rated life and must be replaced to maintain water quality.

2. Filter Replacement

The purifier uses three filters: the Sediment pre-filter, the Carbon block, and the RO membrane.

Replace the Sediment and Carbon filters every 6 months, and the RO membrane every 24 months, or sooner in hard-water areas.

To replace a filter: turn off the inlet valve, press the filter release collar, twist the cartridge anticlockwise, insert the new cartridge, and flush for 10 minutes before use.

3. Maintenance

Sanitise the storage tank every 6 months. Check all push-fit connectors for leaks monthly.

Do not operate the purifier with inlet water pressure below 0.3 MPa; install a booster pump if your supply is low-pressure.

4. Troubleshooting

NO WATER OR SLOW FLOW: The most common cause is a clogged Sediment or Carbon filter. If the red FILTER light is on, replace the filters (Section 2). Also confirm the inlet valve is fully open and inlet pressure is at least 0.3 MPa.

WATER TASTES OR SMELLS BAD: This usually means the Carbon filter is exhausted. Replace the Carbon block and flush the system for 10 minutes. If taste persists, sanitise the tank.

WATER LEAKING FROM THE UNIT: Turn off the inlet valve immediately. Most leaks come from a loose push-fit connector or an improperly seated filter cartridge. Reseat the cartridge and push each connector fully home.

RED FILTER LIGHT STAYS ON AFTER REPLACEMENT: Reset the filter timer by holding the RESET button on the front panel for 5 seconds.

PURE LIGHT NEVER TURNS BLUE: The storage tank may be empty or the RO membrane may be clogged. Allow 1-2 hours to fill; if still unlit, replace the RO membrane.