

Volt-S Electric Scooter — Owner's & Service Manual

1. Safety

Always wear a helmet. Do not ride in heavy rain or through standing water deeper than 5 cm.

Disconnect the battery before performing any electrical service. The system carries 48V.

Use only Volt-S approved spare parts. Unauthorised parts may void the warranty.

2. Operating Controls

The right handlebar contains the throttle, the horn button, and the headlight switch.

Press the horn button firmly; the horn should sound immediately and loudly.

The headlight switch has three positions: OFF, LOW beam, and HIGH beam.

The LCD dashboard shows speed, battery charge, and any active error codes (E1, E2, E3).

3. Maintenance Schedule

Every 1 month: check tyre pressure (40 PSI) and brake lever travel.

Every 3 months: inspect brake pads and clean the charging port.

Every 6 months: inspect all fuses and connectors; lubricate the folding mechanism.

Every 12 months: have the battery health checked at an authorised service centre.

4. Electrical System and Fuses

The horn, headlight, indicators and dashboard are protected by individual fuses in the fuse box, located under the footboard cover (see Figure 4.2).

Fuse F1 (15A) protects the headlight circuit. Fuse F2 (10A) protects the dashboard. Fuse F3 (7.5A) protects the horn circuit. Fuse F4 (10A) protects the indicators.

To access the fuse box, power off the scooter, unscrew the four footboard screws, and lift the cover. Each fuse is labelled. A blown fuse shows a broken metal strip inside.

Figure 4.2: Fuse box layout — F1 headlight, F2 dashboard, F3 horn, F4 indicators.

5. Troubleshooting

HORN NOT WORKING: First check whether the headlight works normally. If the headlight works but the horn is completely silent, the most likely cause is a blown horn fuse (F3) or a faulty horn button. Inspect fuse F3 in the fuse box (Figure 4.2) and replace it with a 7.5A fuse if the metal strip is broken. If the horn is weak rather than silent, the 48V battery may be low, or the horn unit itself may be failing and need replacement.

HEADLIGHT NOT WORKING: Check fuse F1 (15A). If the fuse is intact, the bulb or the headlight switch may be faulty.

SCOOTER WILL NOT POWER ON: Ensure the battery is charged. If the dashboard is blank, check fuse F2 (10A) and the main battery connector under the footboard.

BATTERY NOT CHARGING: Verify the charger LED is green when connected. Clean the charging port. Error code E2 indicates a charging fault — contact service.

WEAK BRAKES: Inspect brake pad thickness; replace pads below 2 mm. Error code E3 indicates the electronic brake sensor needs inspection.