



AIRCRAFT MAINTENANCE MANUAL

BLEED AIR SYSTEM – ADJUSTMENT/TEST

****ON A/C ALL**

TASK 36–11–00–710–801

**Operational Check of the Bleed Air Nacelle Shut–Off Valve (this task incorporates 215200–204)
(MRB#361100–203)**

1. General

- A. This procedure is for the operational check of the bleed air nacelle shut–off valves. The procedure includes a check of the Central Diagnostic System (CDS) messages.

2. Job Set–Up Information

Subtask 36–11–00–946–003

A. Reference Information

REFERENCE	DESIGNATION
TASK 24–00–00–861–801	Energize the Aircraft Electrical System
TASK 24–00–00–861–802	De–energize the Aircraft Electrical System
TASK 45–00–21–742–801	Retrieval of Data from the Central Diagnostic System–Environmental Control System (ECS) Air Conditioning

3. Procedure

Subtask 36–11–00–710–001

- A. Do the operational check of the nacelle shut–off valve as follows:
- (1) Energize the aircraft electrical system (Refer to [TASK 24–00–00–861–801](#)).
 - (2) Get access to the CDS messages for the Environmental Control System (Refer to [TASK 45–00–21–742–801](#)).
 - (3) Check the CDS messages for the Environmental Control System for fault codes.
 - (4) If the fault code 1002, 1005, 1006, 1007, L NAPRSOV or R NAPRSOV is not there, the flow control and shut–off valve is satisfactory.
 - (5) De–energize the aircraft electrical system (Refer to [TASK 24–00–00–861–802](#)).



DE HAVILLAND AIRCRAFT
OF CANADA LIMITED

AIRCRAFT MAINTENANCE MANUAL

4. Close Out

Subtask 36-11-00-941-003

- A. Remove all tools, equipment, and unwanted materials from the work area.



AIRCRAFT MAINTENANCE MANUAL

**ON A/C ALL

TASK 36-11-00-710-802

Operational Test of the Bleed Air System

1. General

- A. The procedure that follows is for the operational check of the bleed air system. The bleed air system consists of the ducts, valves, and sensors between each of the engines and the air conditioning pack, it also includes the ducts and components between the APU and the air conditioning pack.

2. Job Set-Up Information

Subtask 36-11-00-946-004

A. Reference Information

REFERENCE	DESIGNATION
TASK 24-00-00-861-801	Energize the Electrical System
TASK 24-00-00-861-802	De-energize the Electrical System
TASK 49-00-00-869-801	Start Procedure of the APU
TASK 49-00-00-869-802	Shutdown Procedure of the APU
TASK 71-00-00-868-801	Engine Start
TASK 71-00-00-868-802	Engine Shutdown

3. Job Set-Up

Subtask 36-11-00-865-001

- A. Make sure that the circuit breakers that follow are closed:

CB PANEL AND CB NO	NAME
LEFT DC , A7	DE-ICE CONT
LEFT DC , M5	DE-ICE CONT
LEFT DC , N8	PRESS IND 1
LEFT DC, B7	ECS/BA CONT-L AUTO
LEFT DC, C7	ECS/BA CONT-R MAIN
RIGHT DC , S5	DE-ICE CONT
RIGHT DC , A7	PRESS IND 2
RIGHT DC , M4	CAUT/WRN LTS 1
RIGHT DC , N4	CAUT/WRN LTS 2

PSM 1-84-2
EFFECTIVITY:
See first effectivity on page 503 of 36-11-00



AIRCRAFT MAINTENANCE MANUAL

CB PANEL AND CB NO	NAME
RIGHT DC, Q6	ECS/BA CONT-L MAN
RIGHT DC, R6	ECS/BA CONT-R AUTO

Subtask 36-11-00-861-001

- B. Energize the electrical system (Refer to [TASK 24-00-00-861-801](#)).

4. Procedure

Subtask 36-11-00-710-002

- A. Do a operational test of the bleed air system from the engines to the air conditioning pack as follows:

NOTE: There is a 15 second delay for the DEICE PRESS caution light to appear. In this procedure, whenever it is stated to make sure the DEICE PRESS caution light comes on, wait for 15 seconds.

- (1) Start the left engine (Refer to [TASK 71-00-00-868-801](#)) and run it at ground idle (DISC) with the condition lever at MIN detent.
- (2) On the AIR CONDITIONING panel, set the switches as follows:
 - (a) PACKS switches to AUTO
 - (b) BLEED 1 switch to ON
 - (c) BLEED 2 switch to OFF
 - (d) BLEED selector to MAX
 - (e) RECIRC to OFF
 - (f) TEMP CONTROL selectors at operator discretion
- (3) On the ICE PROTECTION panel, set the switches as follows:
 - (a) AIRFRAME MODE SELECTOR to OFF
 - (b) BOOT AIR switch to NORM
- (4) Allow the bleed air system to stabilize for 5 minutes (minimum).
- (5) Make sure the #1 BLEED HOT and/or #2 BLEED HOT caution lights do not come on.
- (6) If the #1 BLEED HOT and/or #2 BLEED HOT caution lights come on, do as follows:
 - (a) Move the Power Lever Angle (PLA) of the No. 1 engine above the FLIGHT IDLE until the bleed stage switching occurs.

NOTE: When the bleed switching occurs, the de-ice pressure gauge needle on the co-pilot side panel will move.



AIRCRAFT MAINTENANCE MANUAL

- (b) Make sure #1 BLEED HOT and/or #2 BLEED HOT caution lights do not come on.
- (7) On the copilot side panel, make sure DEICE PRESS 1 and DEICE PRESS 2 indicate 18 ± 2 psi.
- (8) Make sure that you can feel air coming out of the cockpit gaspers.
- (9) On the AIR CONDITIONING panel, set the PACKS switches to OFF.
 - (a) Make sure that both DEICE PRESS 1 and DEICE PRESS 2 indicators show less than 10 psi.
 - (b) Make sure the DEICE PRESS caution light comes ON.
- (10) On the AIR CONDITIONING panel, set the BLEED 1 switch to OFF.
 - (a) Make sure that both DEICE PRESS 1 and DEICE PRESS 2 indicators show 18 ± 2 psi.
 - (b) Make sure the DEICE PRESS caution light goes OFF.
 - (c) Check that you can no longer feel air coming out of the cockpit gaspers
- (11) On the AIR CONDITIONING panel, set the BLEED 1 switch to ON.
 - (a) Make sure that both DEICE PRESS 1 and DEICE PRESS 2 indicators show less than 10 psi.
 - (b) Make sure the DEICE PRESS caution light comes ON.
- (12) On the ICE PROTECTION panel, set the AIRFRAME MODE SELECTOR to SLOW.
 - (a) Make sure that both DEICE PRESS 1 and DEICE PRESS 2 indicators show 18 ± 2 psi.
 - (b) Make sure the DEICE PRESS caution light goes OFF.
- (13) On the ICE PROTECTION panel, set the AIRFRAME MODE SELECTOR to OFF.
 - (a) Make sure that both DEICE PRESS 1 and DEICE PRESS 2 indicators show less than 10 psi.
 - (b) Make sure the DEICE PRESS caution light comes ON.
- (14) On the AIR CONDITIONING panel, set the BLEED 1 switch to OFF.
- (15) Start the right engine (Refer to [TASK 71-00-00-868-801](#)) and run it at ground idle (DISC) with the condition lever at MIN detent.
- (16) On the AIR CONDITIONING panel, set the BLEED 1 switch to ON.
- (17) On the AIR CONDITIONING panel, set the BLEED 2 switch to ON.
 - (a) Make sure that both DEICE PRESS 1 and DEICE PRESS 2 indicators show less than 10 psi.
 - (b) Make sure the DEICE PRESS caution light comes ON.
- (18) Slowly advance both power levers to a position above 86% NH.
 - (a) Make sure that both DEICE PRESS 1 and DEICE PRESS 2 indicators show 18 ± 2 psi.



AIRCRAFT MAINTENANCE MANUAL

- (b) Make sure the DEICE PRESS caution light goes off.
- (19) On the AIR CONDITIONING panel, set the PACKS switches to AUTO.
- (20) On the ICE PROTECTION panel, set the BOOT AIR switch to ISO.
- (21) Allow the system to stabilize for 1 minute.
- (22) Slowly move the power lever 1 to DISC.
 - (a) Make sure that DEICE PRESS 1 indicator shows less than 10 psi.
 - (b) Make sure that DEICE PRESS 2 indicator shows 18 ± 2 psi.
 - (c) Check that the DEICE PRESS caution light comes ON.
- (23) Slowly move the power lever 2 to DISC.
 - (a) Make sure that DEICE PRESS 1 and DEICE PRESS 2 indicators both show 18 ± 2 psi.
 - (b) Check that the DEICE PRESS caution light goes off.
- (24) On AIR CONDITIONING panel, set the RECIRC switch to OFF and move the BLEED selector from MAX to MIN.
 - (a) Verify that there is a decrease in flow from the cockpit gaspers.
- (25) Make sure the #1 BLEED HOT and/or #2 BLEED HOT caution lights did not come on.
- (26) If the #1 BLEED HOT and/or #2 BLEED HOT caution lights come on, do as follows:
 - (a) Move the Power Lever Angle (PLA) of the No. 1 engine above the FLIGHT IDLE until the bleed stage switching occurs.

NOTE: When the bleed switching occurs, the de-ice pressure gauge needle on the co-pilot side panel will move.
 - (b) Make sure #1 BLEED HOT and/or #2 BLEED HOT caution lights do not come on.
- (27) Shutdown the left engine (Refer to [TASK 71-00-00-868-802](#)).
- (28) On the AIR CONDITIONING panel, set the switches as follows:
 - (a) PACKS switches to AUTO
 - (b) BLEED 2 switch to ON
 - (c) BLEED 1 switch to OFF
 - (d) BLEED selector to MAX
 - (e) TEMP CONTROL selectors at operator discretion
- (29) On the ICE PROTECTION panel, set the switches as follows:
 - (a) BOOT AIR switch to NORM.
 - (b) AIRFRAME MODE SELECTOR to OFF.
- (30) Allow the bleed air system to stabilize for 5 minutes (minimum).



AIRCRAFT MAINTENANCE MANUAL

- (31) Make sure the #1 BLEED HOT and/or #2 BLEED HOT caution lights do not come on.
- (32) If the #1 BLEED HOT and/or #2 BLEED HOT caution lights come on, do as follows:
 - (a) Move the Power Lever Angle (PLA) of the No. 1 engine above the FLIGHT IDLE until the bleed stage switching occurs.

NOTE: When the bleed switching occurs, the de-ice pressure gauge needle on the co-pilot side panel will move.
 - (b) Make sure #1 BLEED HOT and/or #2 BLEED HOT caution lights do not come on.
- (33) On the copilot side panel, make sure DEICE PRESS 1 and DEICE PRESS 2 indicate 18 ± 2 psi.
- (34) Make sure that you can feel air coming out of the cockpit gaspers.
- (35) On the AIR CONDITIONING panel, set the PACKS switches to OFF.
 - (a) Make sure that both DEICE PRESS 1 and DEICE PRESS 2 indicators show less than 10 psi.
 - (b) Make sure the DEICE PRESS caution light comes on.
- (36) On the AIR CONDITIONING panel, set the BLEED 2 switch to OFF.
 - (a) Make sure that both DEICE PRESS 1 and DEICE PRESS 2 indicators show 18 ± 2 psi.
 - (b) Make sure the DEICE PRESS caution light goes OFF.
 - (c) Check that you can no longer feel air coming out of the cockpit gaspers
- (37) On the AIR CONDITIONING panel, set the BLEED 2 switch to ON.
 - (a) Make sure that both DEICE PRESS 1 and DEICE PRESS 2 indicators show less than 10 psi.
 - (b) Make sure the DEICE PRESS caution light comes ON.
- (38) On the ICE PROTECTION panel, set the AIRFRAME MODE SELECTOR to SLOW.
 - (a) Make sure that both DEICE PRESS 1 and DEICE PRESS 2 indicators show 18 ± 2 psi.
 - (b) Make sure the DEICE PRESS caution light goes OFF.
- (39) On the AIR CONDITIONING panel, set the BLEED 1 and BLEED 2 switches OFF.
- (40) Shutdown the right engine (Refer to [TASK 71-00-00-868-802](#)).

Subtask 36-11-00-710-003

- B. Do an operational test of the bleed air system from the APU to the air conditioning pack as follows:
 - (1) Start the APU (Refer to [TASK 49-00-00-869-801](#)).
 - (2) On the AIR CONDITIONING panel, set the switches as follows:



AIRCRAFT MAINTENANCE MANUAL

- (a) BLEED 1 switch to OFF
 - (b) BLEED 2 switch to OFF
 - (c) PACKS switches to AUTO
 - (d) RECIRC switch to OFF
- (3) On APU CONTROL panel, select the BL AIR switch/light to open.
- NOTE:** On the APU CONTROL panel, make sure the STARTER light goes off and the RUN light comes on before you select the BL AIR switch/light.
- (a) Make sure OPEN light on the switch/light comes on.
 - (b) Check for a steady airflow at the cockpit gaspers.
- (4) Let the APU run for 5 minutes (minimum), make sure that the #1 BLEED HOT and #2 BLEED HOT caution lights do not come on.
- (5) On the AIR CONDITIONING panel, set the BLEED 1 to ON, make sure the OPEN light on the BL AIR switch goes off.
- (6) On the AIR CONDITIONING panel, set the BLEED 1 to OFF, make sure the OPEN light on the BL AIR switch comes on.
- (7) On the AIR CONDITIONING panel, set the BLEED 2 to ON, make sure the OPEN light on the BL AIR switch goes off.
- (8) On the AIR CONDITIONING panel, set the BLEED 2 to OFF, make sure the OPEN light on the BL AIR switch comes on.
- (9) On the AIR CONDITIONING panel, set the PACKS switches to OFF.
- (10) On the APU CONTROL panel, select the BL AIR switch/light.
- (a) Make sure the OPEN light on the switch/light goes off.
- (11) Shutdown the APU (Refer to [TASK 49-00-00-869-802](#)).

5. Close Out

Subtask 36-11-00-861-002

- A. De-energize the electrical system (Refer to [TASK 24-00-00-861-802](#)).



AIRCRAFT MAINTENANCE MANUAL

DUCTS, P3.0 – ADJUSTMENT/TEST

**ON A/C ALL

TASK 36–11–01–710–801

Operational Test of the Bleed Air System After Replacement or Disconnect and Reconnect of the P3.0 Ducts

1. General

- A. The procedure that follows is for the operational check of the bleed air system after the removal and installation or disconnect and reconnect of the P3.0 ducts that follow:
- P3.0 HP to HPSOV Duct
 - HPSOV to Precooler Duct
 - Precooler Outlet Duct.

2. Job Set-Up Information

Subtask 36–11–01–946–029

A. Reference Information

REFERENCE	DESIGNATION
TASK 24–00–00–861–801	Energize the Electrical System
TASK 24–00–00–861–802	De–energize the Electrical System
TASK 71–00–00–868–801	Engine Start
TASK 71–00–00–868–802	Engine Shutdown

3. Job Set-Up

Subtask 36–11–01–865–027

- A. Make sure that the circuit breakers that follow are closed:

CB PANEL AND CB NO	NAME
LEFT DC , A7	DE–ICE CONT
LEFT DC , M5	DE–ICE CONT
LEFT DC , N8	PRESS IND 1
LEFT DC, B7	ECS/BA CONT–L AUTO
LEFT DC, C7	ECS/BA CONT–R MAIN
RIGHT DC , S5	DE–ICE CONT
RIGHT DC , A7	PRESS IND 2

PSM 1–84–2
EFFECTIVITY:
See first effectivity on page 501 of 36–11–01

36–11–01 Page 501
Sep 05/2021



AIRCRAFT MAINTENANCE MANUAL

CB PANEL AND CB NO	NAME
RIGHT DC , M4	CAUT/WRN LTS 1
RIGHT DC , N4	CAUT/WRN LTS 2
RIGHT DC, Q6	ECS/BA CONT-L MAN
RIGHT DC, R6	ECS/BA CONT-R AUTO

Subtask 36-11-01-861-001

- B. Energize the electrical system (Refer to [TASK 24-00-00-861-801](#)).

4. Procedure

Subtask 36-11-01-710-004

- A. Do an operational test of the bleed air system with the engine(s) as follows:

NOTE: It is sometimes necessary to wait 15 seconds for the DEICE PRESS caution light to come ON.

- (1) On the Caution and Warning Panel (CAWP), make sure that the DEICE PRESS caution light is ON.
- (2) Make sure that the DEICE PRESS indicator on the co-pilot side panel shows approximately zero on the two sides.
- (3) Start the engine on the side that the P3.0 HP to HPSOV Duct was replaced or disconnected and reconnected (Refer to [TASK 71-00-00-868-801](#)).
- (4) Operate the engine at ground idle (DISC) with the condition lever at MIN detent.
- (5) On the AIR CONDITIONING panel, set the switches as follows:
 - (a) PACKS switches to AUTO
 - (b) Running engine bleed to ON
 - (c) BLEED selector to MAX
 - (d) RECIRC to OFF
 - (e) TEMP CONTROL selectors at any position.
- (6) On the ICE PROTECTION panel, set the switches as follows:
 - (a) AIRFRAME MODE SELECTOR to OFF
 - (b) BOOT AIR switch to NORM.

NOTE: If the two engines are running, it is necessary to set the BOOT AIR switch to ISO.

- (7) Let the bleed air system become stable for at least five minutes.



AIRCRAFT MAINTENANCE MANUAL

- (8) Monitor the No. 1 BLEED HOT and/or No. 2 BLEED HOT caution lights as necessary.
 - (a) If the No. 1 BLEED HOT and/or No. 2 BLEED HOT caution lights come ON, do the steps that follow:
 - 1. Move the Power Lever Angle (PLA) of the applicable engine above FLIGHT IDLE until the bleed stage switching occurs.
 - 2. Make sure that the DEICE PRESS indicator on the co-pilot side panel increases to 18 psi. This will indicate that the bleed air switching has occurred.
 - 3. Make sure that the No. 1 BLEED HOT and/or No. 2 BLEED HOT caution lights go OFF.
 - (b) If the No. 1 BLEED HOT and/or No. 2 BLEED HOT caution lights are OFF, do the steps that follow:
 - 1. Move the PLA of the applicable engine above FLIGHT IDLE until the bleed stage switching occurs.
 - 2. Make sure that the DEICE PRESS indicator on the co-pilot side panel increases to 18 psi. This will indicate that the bleed air switching has occurred.
- (9) On the CAWP, make sure that the DEICE PRESS caution light is OFF.
- (10) Make sure that the DEICE PRESS indicator on the co-pilot side panel shows 18 ± 2 psi on the two sides.
- (11) With your hand, feel the gaspers in the flight compartment for air flow.
- (12) On the AIR CONDITIONING panel, set the two PACKS switches to OFF.
- (13) Slowly move the PLA to DISC and let the system become stable for one minute.
- (14) Make sure that the DEICE PRESS indicator on the co-pilot side panel shows less than 10 psi on the two sides.
- (15) On the CAWP, make sure that the DEICE PRESS caution light comes ON.
- (16) On the AIR CONDITIONING panel, set the BLEED 1 and BLEED 2 switches to OFF.
- (17) Shutdown the engine (Refer to [TASK 71-00-00-868-802](#)).
- (18) After the engine shutdown, examine the P3.0 duct fitting for signs of leakage.

5. Close Out

Subtask 36-11-01-861-002

- A. De-energize the electrical system (Refer to [TASK 24-00-00-861-802](#)).

THIS PAGE INTENTIONALLY LEFT BLANK



AIRCRAFT MAINTENANCE MANUAL

DUCTS, P2.7 – ADJUSTMENT/TEST

**ON A/C ALL

TASK 36–11–24–710–801

Operational Test of the Bleed Air System After Replacement or Disconnect and Reconnect of the P2.7 Duct

1. General

- A. The procedure that follows is for the operational check of the bleed air system after the removal and installation or disconnect and reconnect of the P2.7 Duct.

2. Job Set-Up Information

Subtask 36–11–24–946–006

A. Reference Information

REFERENCE	DESIGNATION
TASK 24–00–00–861–801	Energize the Electrical System
TASK 24–00–00–861–802	De–energize the Electrical System
TASK 71–00–00–868–801	Engine Start
TASK 71–00–00–868–802	Engine Shutdown

3. Job Set-Up

Subtask 36–11–24–865–001

- A. Make sure that the circuit breakers that follow are closed:

CB PANEL AND CB NO	NAME
LEFT DC , A7	DE–ICE CONT
LEFT DC , M5	DE–ICE CONT
LEFT DC , N8	PRESS IND 1
LEFT DC, B7	ECS/BA CONT–L AUTO
LEFT DC, C7	ECS/BA CONT–R MAIN
RIGHT DC , S5	DE–ICE CONT
RIGHT DC , A7	PRESS IND 2
RIGHT DC , M4	CAUT/WRN LTS 1
RIGHT DC , N4	CAUT/WRN LTS 2
RIGHT DC, Q6	ECS/BA CONT–L MAN
RIGHT DC, R6	ECS/BA CONT–R AUTO

PSM 1–84–2
EFFECTIVITY:
See first effectivity on page 501 of 36–11–24

36–11–24 Page 501
Sep 05/2021



AIRCRAFT MAINTENANCE MANUAL

Subtask 36-11-24-861-001

- B. Energize the electrical system (Refer to [TASK 24-00-00-861-801](#)).

4. Procedure

Subtask 36-11-24-710-001

- A. Do an operational test of the bleed air system with the engine(s) as follows:

NOTE: It is sometimes necessary to wait 15 seconds for the DEICE PRESS caution light to come ON.

- (1) On the Caution and Warning Panel (CAWP), make sure that the DEICE PRESS caution light is ON.
- (2) Make sure that the DEICE PRESS indicator on the co-pilot side panel shows approximately zero on the two sides.
- (3) Start the engine on the side that the P2.7 Duct was replaced or disconnected and reconnected (Refer to [TASK 71-00-00-868-801](#)).
- (4) Operate the engine at ground idle (DISC) with the condition lever at MIN detent.
- (5) On the AIR CONDITIONING panel, set the switches as follows:
 - (a) PACKS switches to AUTO
 - (b) Running engine bleed to ON
 - (c) BLEED selector to MAX
 - (d) RECIRC to OFF
 - (e) TEMP CONTROL selectors at any position.
- (6) On the ICE PROTECTION panel, set the switches as follows:
 - (a) AIRFRAME MODE SELECTOR to OFF
 - (b) BOOT AIR switch to NORM.

NOTE: If the two engines are running, it is necessary to set the BOOT AIR switch to ISO.

- (7) Let the bleed air system become stable for at least five minutes.
- (8) Monitor the No. 1 BLEED HOT and/or No. 2 BLEED HOT caution lights as necessary.
 - (a) If the No. 1 BLEED HOT and/or No. 2 BLEED HOT caution lights come ON, do the steps that follow:
 1. Move the Power Lever Angle (PLA) of the applicable engine above FLIGHT IDLE until the bleed stage switching occurs.
 2. Make sure that the DEICE PRESS indicator on the co-pilot side panel increases to 18 psi. This will indicate that the bleed air switching has occurred.



AIRCRAFT MAINTENANCE MANUAL

3. Make sure that the No. 1 BLEED HOT and/or No. 2 BLEED HOT caution lights go OFF.
- (b) If the No. 1 BLEED HOT and/or No. 2 BLEED HOT caution lights are OFF, do the steps that follow:
 1. Move the PLA of the applicable engine above FLIGHT IDLE until the bleed stage switching occurs.
 2. Make sure that the DEICE PRESS indicator on the co-pilot side panel increases to 18 psi. This will indicate that the bleed air switching has occurred.
- (9) On the CAWP, make sure that the DEICE PRESS caution light is OFF.
- (10) Make sure that the DEICE PRESS indicator on the co-pilot side panel shows 18 ± 2 psi on the two sides.
- (11) With your hand, feel the gaspers in the flight compartment for air flow.
- (12) On the AIR CONDITIONING panel, set the two PACKS switches to OFF.
- (13) Slowly move the PLA to DISC and let the system become stable for one minute.
- (14) Make sure that the DEICE PRESS indicator on the co-pilot side panel shows less than 10 psi on the two sides.
- (15) On the CAWP, make sure that the DEICE PRESS caution light comes ON.
- (16) On the AIR CONDITIONING panel, set the BLEED 1 and BLEED 2 switches to OFF.
- (17) Shutdown the engine (Refer to [TASK 71-00-00-868-802](#)).
- (18) After the engine shutdown, examine the P2.7 duct fitting for signs of leakage.

5. Close Out

Subtask 36-11-24-861-002

- A. De-energize the electrical system (Refer to [TASK 24-00-00-861-802](#)).

THIS PAGE INTENTIONALLY LEFT BLANK



AIRCRAFT MAINTENANCE MANUAL

DUCTS, P2.2 – ADJUSTMENT/TEST

**ON A/C ALL

TASK 36–11–26–710–801

Operational Test of the Bleed Air System After Replacement or Disconnect and Reconnect of the P2.2 Ducts

1. General

- A. The procedure that follows is for the operational check of the bleed air system after the removal and installation or disconnect and reconnect of the P2.2 ducts that follow:
- P2.2 LP Mid Duct
 - P2.2 LP to LPSOV Duct
 - LPSOV to Precooler Duct.

2. Job Set-Up Information

Subtask 36–11–26–946–017

A. Reference Information

REFERENCE	DESIGNATION
TASK 24–00–00–861–801	Energize the Electrical System
TASK 24–00–00–861–802	De–energize the Electrical System
TASK 71–00–00–868–801	Engine Start
TASK 71–00–00–868–802	Engine Shutdown

3. Job Set-Up

Subtask 36–11–26–865–009

- A. Make sure the circuit breakers that follow are closed:

CB PANEL AND CB NO	NAME
LEFT DC , A7	DE–ICE CONT
LEFT DC , M5	DE–ICE CONT
LEFT DC , N8	PRESS IND 1
LEFT DC, B7	ECS/BA CONT–L AUTO
LEFT DC, C7	ECS/BA CONT–R MAIN
RIGHT DC , S5	DE–ICE CONT
RIGHT DC , A7	PRESS IND 2

PSM 1–84–2
EFFECTIVITY:
See first effectivity on page 501 of 36–11–26

36–11–26 Page 501
Sep 05/2021



AIRCRAFT MAINTENANCE MANUAL

CB PANEL AND CB NO	NAME
RIGHT DC , M4	CAUT/WRN LTS 1
RIGHT DC , N4	CAUT/WRN LTS 2
RIGHT DC, Q6	ECS/BA CONT-L MAN
RIGHT DC, R6	ECS/BA CONT-R AUTO

Subtask 36-11-26-861-005

- B. Energize the electrical system (Refer to [TASK 24-00-00-861-801](#)).

4. Procedure

Subtask 36-11-26-710-004

- A. Do an operational test of the bleed air system with the engine(s) as follows:

NOTE: It is sometimes necessary to wait 15 seconds for the DEICE PRESS caution light to come ON.

- (1) On the Caution and Warning Panel (CAWP), make sure that the DEICE PRESS caution light is ON.
- (2) Make sure that the DEICE PRESS indicator on the co-pilot side panel shows approximately zero on the two sides.
- (3) Start the engine on the side that the P2.2 duct was replaced or disconnected and reconnected (Refer to [TASK 71-00-00-868-801](#)).
- (4) Operate the engine at ground idle (DISC) with the condition lever at MIN detent.
- (5) On the AIR CONDITIONING panel, set the switches as follows:
 - (a) PACKS switches to AUTO
 - (b) Running engine bleed to ON
 - (c) BLEED selector to MAX
 - (d) RECIRC to OFF
 - (e) TEMP CONTROL selectors at any position.
- (6) On the ICE PROTECTION panel, set the switches as follows:
 - (a) AIRFRAME MODE SELECTOR to OFF
 - (b) BOOT AIR switch to NORM.

NOTE: If the two engines are running, it is necessary to set the BOOT AIR switch to ISO.

- (7) Let the bleed air system become stable for at least five minutes.



AIRCRAFT MAINTENANCE MANUAL

- (8) Monitor the No. 1 BLEED HOT and/or No. 2 BLEED HOT caution lights as necessary.
 - (a) If the No. 1 BLEED HOT and/or No. 2 BLEED HOT caution lights come ON, do the steps that follow:
 - 1. Move the Power Lever Angle (PLA) of the applicable engine above FLIGHT IDLE until the bleed stage switching occurs.
 - 2. Make sure that the DEICE PRESS indicator on the co-pilot side panel increases to 18 psi. This will indicate that the bleed air switching has occurred.
 - 3. Make sure that the No. 1 BLEED HOT and/or No. 2 BLEED HOT caution lights go OFF.
 - (b) If the No. 1 BLEED HOT and/or No. 2 BLEED HOT caution lights are OFF, do the steps that follow:
 - 1. Move the PLA of the applicable engine above FLIGHT IDLE until the bleed stage switching occurs.
 - 2. Make sure that the DEICE PRESS indicator on the co-pilot side panel increases to 18 psi. This will indicate that the bleed air switching has occurred.
- (9) On the CAWP, make sure that the DEICE PRESS caution light is OFF.
- (10) Make sure that the DEICE PRESS indicator on the co-pilot side panel shows 18 ± 2 psi on the two sides.
- (11) With your hand, feel the gaspers in the flight compartment for air flow.
- (12) On the AIR CONDITIONING panel, set the two PACKS switches to OFF.
- (13) Slowly move the PLA to DISC and let the system become stable for one minute.
- (14) Make sure that the DEICE PRESS indicator on the co-pilot side panel shows less than 10 psi on the two sides.
- (15) On the CAWP, make sure that the DEICE PRESS caution light comes ON.
- (16) On the AIR CONDITIONING panel, set the BLEED 1 and BLEED 2 switches to OFF.
- (17) Shutdown the engine (Refer to [TASK 71-00-00-868-802](#)).
- (18) After the engine shutdown, examine the P2.2 duct fitting for signs of leakage.

5. Close Out

Subtask 36-11-26-861-006

- A. De-energize the electrical system (Refer to [TASK 24-00-00-861-802](#)).

THIS PAGE INTENTIONALLY LEFT BLANK