

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-20-1****Distribution Champer**

Interval	Installed	Required	Procedure
C	1	0	NIL

May be inoperative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Distribution Damper must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard the AIR CONDITIONING panel in the flight compartment with "Distribution Damper INOP".
2. Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DAT 00 –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-20-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-20-2****Recirculation Fan****21-20-2-2****Pre-Mod 4-126236 and (Mod 4-126211 or
Mod 4-126212)**

Interval	Installed	Required	Procedure
C	1	0	NIL

May be inoperative provided Fan is switched OFF.

Minimum Equipment List Procedures (MELP)**Placard**

The inoperative "RECIRC" switch on the AIR CONDITIONING panel must be placarded in the "OFF" position.

Operating Procedures

None required

Maintenance Procedures

1. Placard the AIR CONDITIONING panel with "RECIRC FAN TO REMAIN OFF".
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-20-2. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-20-3****Flow (Pack) Control and Shutoff Valve**

Interval	Installed	Required	Procedure
C	1	0	(M#)

May be inoperative provided:

- The Valve is secured in the open position,
- The Nacelle Shutoff Valves are verified operative, and
- Both digital (AUTO) channels of the ECU are verified operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Flow (Pack) Control and Shutoff Valve must be placarded in the flight compartment.

Operating Procedures

None required

Maintenance Procedures

- Gain access to the Aft Equipment Bay via access panel 311AB.
- Locate the Flow Control and Shutoff Valve, directly overhead, left of center.
- Remove the locking pin from its normally installed position on the valve, held by a retaining cable. (This allows the valve servo air to bleed to ambient.)
- Use a wrench to turn the crank on the flow control and shutoff valve to the open position.
- Install the locking pin to prevent the crank from moving closed.
- Close access panel 311AB.
- Observing all related precautions, start and run engines 1 and 2 and allow engines to stabilize at FLT IDLE.
- On the L. DC circuit breaker panel, pull breaker ECS/BA L AUTO and ECS/BA R MAN and on the R. DC circuit breaker ECS/BA L MAN.
- At the AIR CONDITIONING panel, on the overhead console, select the:
 - CABIN OFF/MAN/AUTO/PACKS switch to AUTO
 - FLT COMP OFF/MAN/AUTO/PACKS switch to OFF

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DAT 00 -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-20-3. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-20-3****Flow (Pack) Control and Shutoff Valve**

- No. 1 BLEED switch to OFF
 - No. 2 BLEED switch to OFF
 - RECIRC FAN switch to OFF
 - CABIN and FLT COMP temperature control knobs to mid-range
10. If APU is operating, ensure APU BLEED is switched OFF.
11. Confirm that no airflow is evident from the cockpit and cabin vents.
12. At the AIR CONDITIONING panel, on the overhead console, select the:
- CABIN OFF/MAN/AUTO/PACKS switch to OFF
 - FLT COMP OFF/MAN/AUTO/PACKS switch to OFF
 - No. 1 BLEED switch to OFF
 - No. 2 BLEED switch to ON
13. Confirm that no airflow is evident from the cockpit and cabin vents.
14. Select CABIN COMP OFF/MAN/AUTO/PACKS switch to AUTO and observe that some level of airflow is initiated.
15. Note the present temperature on the CABIN and FC DUCT TEMP GAUGE.
16. Rotate the CABIN and FLT COMP temperature control knobs to full COOL.
17. After waiting approximately 60 - 90 seconds, confirm that the observed temperature trend is decreasing from ambient. (Note that the rate at which the trend changes will be dependent upon the differential of the ambient temperature compared to the maximum cold air temperature of 3 degrees C. Similarly, the maximum high temperature is 71 degrees C).
18. Rotate the CABIN and FLT COMP temperature control knobs to full WARM and confirm that after waiting approximately 60 - 90 seconds, the observed temperature trend increases.
19. Return temperature control knobs to mid-range.
20. On the L. DC circuit breaker panel, close breaker ECS/BA L AUTO, and on the R. DC circuit breaker pull ECS/BA R AUTO.
21. At the AIR CONDITIONING panel, on the overhead console, select the:
- CABIN OFF/MAN/AUTO/PACKS switch to OFF
 - FLT COMP OFF/MAN/AUTO/PACKS switch to AUTO
 - No. 1 BLEED switch to OFF
 - No. 2 BLEED switch to ON
 - RECIRC FAN switch to OFF
 - CABIN and FLT COMP temperature control knobs to mid-range
22. Confirm that no airflow is evident from the cockpit and cabin vents.
23. At the AIR CONDITIONING panel, on the overhead console, select the:
- CABIN OFF/MAN/AUTO/PACKS switch to OFF

*(...Continued)***ISS III R00****APPROVED BY DAW DELHI, DAT 00 –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-20-3. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-20-3****Flow (Pack) Control and Shutoff Valve**

- FLT COMP OFF/MAN/AUTO/PACKS switch to OFF
 - No. 1 BLEED switch to ON
 - No. 2 BLEED switch to OFF
24. Confirm that no airflow is evident from the cockpit and cabin vents.
25. Select FLT OFF/MAN/AUTO/PACKS switch to AUTO and observe that some level of airflow is initiated.
26. Note the present temperature on the CABIN and FC DUCT TEMP GAUGE.
27. Rotate the CABIN and FLT COMP temperature control knobs to full COOL.
28. After waiting approximately 60 - 90 seconds, confirm that the observed temperature trend is decreasing from ambient. (Note that the rate at which the trend changes will be dependent upon the differential of the ambient temperature compared to the maximum cold air temperature of 3 degrees C. Similarly, the maximum high temperature is 71 degrees C).
29. Rotate the CABIN and FLT COMP temperature control knobs to full WARM and confirm that after waiting approximately 60 - 90 seconds, the observed temperature trend increases.
30. Return temperature control knobs to mid-range.
31. On the L. DC circuit breaker panel, close breaker ECS/BA R MAN, and on the R. DC circuit breaker close ECS/BA R AUTO and ECS/BA L MAN.
32. Shut down engines.
33. Placard the inoperative Flow (Pack) Control and Shutoff Valve in the flight compartment.
34. Make appropriate entry in the aircraft journey log.
- ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-20-3. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-20-4****Display Cooling Fans**

Interval	Installed	Required	Procedure
C	3	2	NIL

May be inoperative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Display Cooling Fan must be placarded in the flight compartment.

Operating Procedures

None required

Maintenance Procedures

1. Placard inoperative Display Cooling Fan in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-20-4. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-20-5 SIDE WINDOW DEMIST Vent Controls****21-20-5-1**

Interval	Installed	Required	Procedure
A	2	1	NIL

One may be inoperative provided:

- Airflow from the side window vent on the inoperative side is confirmed by the pilot, and
- Repairs are made within one flight day.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Side Window Demist must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

- Placard Inoperative Side Window Demist on the AIR CONDITIONING panel.
- Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-20-5. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-20-5 SIDE WINDOW DEMIST Vent Controls****21-20-5-2**

Interval	Installed	Required	Procedure
C	2	0	(M#)

May be inoperative provided the affected side(s) is failed in the open position.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Side Window Demist must be placarded in the flight compartment.

Operating Procedures

None required

Maintenance Procedures

1. To gain access to the Side Window Outlet Flow Control Valve, do the following steps:
 - a) In the cockpit sidewall trim panels, remove the screws which attach the lower sidewall panel to the aircraft structure.
 - b) Carefully pull the lower sidewall panel to disengage the tape fastener at the bottom from the aircraft structure.
 - c) Remove the lower sidewall panel and put it on a clean dry surface.
 - d) Gain access to the Side Window Demist Outlet Flow Control Valve and move the lever to the fully open position.
 - e) Put the lower sidewall panel in position to the aircraft structure. Align the screw holes in the lower sidewall panel to the screw holes in the aircraft structure. Engage the tape fastener at the bottom of the lower sidewall panel to the aircraft structure.
 - f) Install the screws.
2. Placard Inoperative Side Window Demist on the AIR CONDITIONING panel.
3. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -****Signature valid**

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-20-5. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-20-6****Low Level Vent Controls****21-20-6A**

Interval	Installed	Required	Procedure
A	2	1	NIL

One may be inoperative provided:

- Airflow from the side window vent on the inoperative side is confirmed by the pilot, and
- Repairs are made within one flight day.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Low Level Vent must be placarded in the flight compartment.

Operating Procedures

None required

Maintenance Procedures

- Placard inoperative Low Level Vent on AIR CONDITIONING Panel.
- Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DAT 00 –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-20-6. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-20-6****Low Level Vent Controls****21-20-6B**

Interval	Installed	Required	Procedure
C	2	0	(M)

May be inoperative provided the Low Level Vent position is confirmed and lever moved to closed position.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Low Level Vent must be placarded in the flight compartment.

Operating Procedures

None required

Maintenance Procedures

1. To gain access to the Low Level Vent Flow Control Valve, do the following steps:
 - a) On the Nose Fuselage remove the screws which attach the access panel to the nose fuselage.
 - b) Remove the panel in order to gain access to the Low Level Vent Flow Control Valve.
 - c) Move the lever to the fully closed position.
 - d) Install the panel back to its position.
2. Placard inoperative Low Level Vent on AIR CONDITIONING PANEL.
3. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-20-6. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-20-7****FLT COMPT GASPERS (Small and Large)**

Interval	Installed	Required	Procedure
C	4	0	NIL

May be inoperative provided comfort level is acceptable to the pilot.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative FLT COMPT GASPERS must be placarded in the flight compartment.

Operating Procedures

None required

Maintenance Procedures

1. Placard Inoperative FLT COMPT GASPERS on AIR CONDITIONING PANEL.
2. Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-20-7. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-20-8 Aft Baggage Compartment Vent Valves****21-20-8-1 Inlet and Outlet Vent Valves****21-20-8-1A**

Interval	Installed	Required	Procedure
C	2	0	(M)

May be inoperative in the closed position provided:

- Inlet and outlet vent valves (shut-off valves) are deactivated,
- VENT VALVE INLT and VENT VALVE OUTLT CLOSED advisory lights are verified illuminated prior to each flight, and
- Live animals are not carried.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative AFT BAGGAGE VENT Valves must be placarded in the flight compartment.

Operating Procedures

None required

Maintenance Procedures

- Pull and clip the appropriate circuit breakers on the R Main Circuit Breaker panel for the following configurations:
 - With "2" Vents installed: CGO VENT VLS.
 - With "4" Vents installed: CGO VENT VALVES 1 and CGO VENT VALVES 2.
- On the Fire Protection Panel, verify the following "CLOSED" advisory lights are illuminated for the following configuration:
 - With "2" Vents installed:
 - AFT BAGGAGE - VENT VALVE INLT, and
 - AFT BAGGAGE - VENT VALVE OUTLT.
 - With "4" Vents installed:
 - CARGO - VENT VALVE INLT 1 and 2, and

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-20-8. 1



DHC-8-402

MINIMUM EQUIPMENT LIST

AIR CONDITIONING

ATA 21

21-20-8 Aft Baggage Compartment Vent Valves

21-20-8-1 Inlet and Outlet Vent Valves

21-20-8-1A

- ii) CARGO - VENT VALVE OTLT 1 and 2.
- 3. Placard Fire Protection Panel with "INLET and OUTLT VENT VALVES CLOSED".
- 4. Make an appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00

APPROVED BY DAW DELHI, DATED -

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-20-8. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-20-8 Aft Baggage Compartment Vent Valves****21-20-8-1 Inlet and Outlet Vent Valves****21-20-8-1B**

Interval	Installed	Required	Procedure
C	2	0	NIL

May be inoperative in open position provided the baggage compartment is empty, or for ballast purpose, use of bags (made of glass fiber or Kevlar) of sand or ingots of non-magnetic metals (such as lead) is acceptable.

NOTE: Annexure A defines which materials can be used as Ballast.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative AFT BAGGAGE VENT Valves must be placarded in the flight compartment.

Operating Procedures

None required

Maintenance Procedures

1. Placard Fire Protection Panel with "INLET and OUTLET VENT VALVES INOP".
2. Make an appropriate entry in the aircraft journey log.

— — — —

ISS III R03**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-20-8. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-20-8 Aft Baggage Compartment Vent Valves****21-20-8-2 VENT VALVE INLT and VENT VALVE OTLT CLOSED advisory lights**

Interval	Installed	Required	Procedure
C	2	0	NIL

May be inoperative provided the baggage compartment is empty, or for ballast purpose, use of bags (made of glass fiber or Kevlar) of sand or ingots of non-magnetic metals (such as lead) is acceptable.

NOTE: Annexure A defines which materials can be used as Ballast.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative VENT VALVE INLT and VENT VALVE OTLT CLOSED advisory lights must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard Fire Protection Panel with "INLET and OUTLET VENT VALVES INOP".
2. Make an appropriate entry in the aircraft journey log.

■■■■

ISS III R03**APPROVED BY DAW DELHI, DATED -****Signature valid**

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-20-8. 4

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-30-1 CABIN PRESS Warning Light**

Interval	Installed	Required	Procedure
C	1	0	(O)

May be inoperative provided flight is conducted at or below 10,000 feet MSL, per AFM Supplement 113, UNPRESSURIZED FLIGHT - BLEED ON.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative CABIN PRESS warning light must be placarded in the flight compartment.

Operating Procedures

Operations to be conducted in accordance with AFM Supplement 113, UNPRESSURIZED FLIGHT - BLEED ON.

Maintenance Procedures

1. Placard the CABIN PRESS warning light on WARNING CAUTION panel in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-30-1. 1



DHC-8-402

MINIMUM EQUIPMENT LIST

AIR CONDITIONING

ATA 21

**INTENTIONALLY
LEFT
BLANK**

ISS III R00

APPROVED BY DAW DELHI, DATED -

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-30-1. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-30-2 Cabin ALT Indicator****21-30-2A**

Interval	Installed	Required	Procedure
C	1	0	(O)

May be inoperative provided:

- The Cabin DIFF Pressure Indicator is verified operative, and
- A chart is provided to convert cabin differential pressure to cabin altitude.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Cabin ALT indicator must be placarded in the flight compartment.

Operating Procedures

Verify that the DIFF pressure indicator operates normally using Method B on ground or Method A in flight.

Method A (in flight prior to landing)

- Monitor DIFF pressure indicator on CABIN indication panel during the flight.
- Use chart provided by CPCS placard on the overhead panel in the Flight Compartment for converting differential pressure and aircraft altitude to cabin altitude.

Method B (on ground)

- Select the following on the CABIN PRESSURE CONTROL PANEL:
 - AUTO/MAN/DUMP switch - AUTO.
 - FWD OUTFLOW knob - CLSD.
- Ensure all doors are closed, start No. 1 engine and select power lever to FLT IDLE.

OR

Start APU (ensuring there is air in the Reservoir Tank to inflate the door seals).

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-30-2. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-30-2 Cabin ALT Indicator****21-30-2A**

3. Ensure that Cabin DIFF Pressure Indicator on Cabin Indication Panel is at zero psi.
Record DIFF reading.
4. If running engine make the following selections on AIR CONDITIONING panel:
 - a) BLEED 1 switch - BLEED
 - b) BLEED flow control selector - MAX

OR

If running APU, select BL AIR OPEN on APU Control Panel.

5. Advance PLA #2 to the take-off rating detent, greater than 60 degrees.

WARNING: ENSURE THAT CABIN DIFFERENTIAL PRESSURE DOES NOT EXCEED 1.0 PSI.

6. Check the following indication on CABIN INDICATION MODULE: DIFF (PSI) - equal to 0.2 ± 0.1 psi
7. Depressurize the aircraft.

Maintenance Procedures

1. Placard the Cabin ALT Indicator in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-30-2. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-30-2 Cabin ALT Indicator****21-30-2B**

Interval	Installed	Required	Procedure
D	1	0	(O)

May be inoperative provided flight is conducted in an unpressurized configuration, at or below 10,000 feet MSL, in accordance with AFM Supplement 113, UNPRESSURIZED FLIGHT – BLEED ON.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Cabin ALT indicator must be placarded in the flight compartment.

Operating Procedures

Carry out unpressurized flight in accordance with AFM Supplement 113, UNPRESSURIZED FLIGHT - BLEED ON.

Maintenance Procedures

1. Placard the Cabin ALT Indicator in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-30-2. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-30-3 Cabin DIFF Pressure Indicator****21-30-3A**

Interval	Installed	Required	Procedure
C	1	0	(O)

May be inoperative provided:

- The Cabin ALT Indicator is verified operative, and
- A chart is provided to convert cabin altitude to cabin differential pressure.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative DIFF Pressure Indicator must be placarded in the flight compartment.

Operating Procedures

Verify operation of Cabin ALT Indicator using Method B on the ground or Method A (in flight prior to landing).

Method A (In flight prior to landing)

- Monitor the cabin altitude during the flight.
- Use chart provided by CPCS placard on the overhead panel in the flight compartment for converting cabin altitude and aircraft altitude to differential pressure.

Method B (On ground)

- Select the following on the CABIN PRESSURE CONTROL PANEL:
 - AUTO/MAN/DUMP switch – AUTO.
 - FWD OUTFLOW knob – CLSD.
- Ensure all doors are closed, start No. 1 engine and select power lever to FLT IDLE.

OR

Start APU (ensuring there is air in the Reservoir Tank to inflate the door seals).

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-30-3. 1



DHC-8-402

MINIMUM EQUIPMENT LIST

AIR CONDITIONING

ATA 21

21-30-3 Cabin DIFF Pressure Indicator

21-30-3A

3. Ensure that CAB ALT on CABIN indication panel is at field altitude (± 100 ft). Record ALT reading.
4. If running engine make the following selections on AIR CONDITIONING panel:
 - a) BLEED 1 switch - BLEED
 - b) BLEED flow control selector - MAX

OR

If running APU, select BL AIR OPEN on APU Control Panel.

5. Advance PLA #2 to the take-off rating detent, greater than 60 degrees.

WARNING: ENSURE THAT CABIN DIFFERENTIAL PRESSURE DOES NOT EXCEED 1.0 PSI.

6. Check the following indication on CABIN indication panel:
CABIN ALT - descent towards 400 (± 150 ft) less than value taken in step (3) when stabilized, record CAB. ALT reading.
7. Depressurize the aircraft.

Maintenance Procedures

1. Placard the DIFF Cabin Pressure Indicator on CABIN indication panel in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00

APPROVED BY DAW DELHI, DATED -

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-30-3. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-30-3 Cabin DIFF Pressure Indicator****21-30-3B**

Interval	Installed	Required	Procedure
D	1	0	(O)

May be inoperative provided flight is conducted in an unpressurized configuration, at or below 10,000 feet MSL, in accordance with AFM Supplement 113, UNPRESSURIZED FLIGHT - BLEED ON.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative DIFF Pressure Indicator must be placarded in the flight compartment.

Maintenance Procedures

1. Placard the DIFF Cabin Pressure Indicator on CABIN indication panel in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

Operating Procedures

In case of automatic control failure, carry out unpressurized flight in accordance with AFM Supplement 113, UNPRESSURIZED FLIGHT - BLEED ON.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-30-3. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-30-4 Cabin RATE Indicator****21-30-4A**

Interval	Installed	Required	Procedure
C	1	0	NIL

May be inoperative provided all other instruments and functions of the Pressurization System are operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Cabin Rate of Climb Indicator must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard Inoperative FLT COMPT GASPERS on AIR CONDITIONING PANEL.
2. Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-30-4. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-30-4 Cabin RATE Indicator****21-30-4B**

Interval	Installed	Required	Procedure
D	1	0	(O)

May be inoperative provided flight is conducted in an unpressurized configuration, at or below 10,000 feet MSL, in accordance with AFM Supplement 113, UNPRESSURIZED FLIGHT – BLEED ON.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Cabin Rate of Climb Indicator must be placarded in the flight compartment.

Operating Procedures

Conduct the flight in accordance with AFM Supplement 113, UNPRESSURIZED FLIGHT – BLEED ON.

Maintenance Procedures

1. Placard inoperative the Cabin Rate Indicator in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-30-4. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-30-5 Cabin Pressure Control System****21-30-5-1 AUTO and MAN Modes**

Interval	Installed	Required	Procedure
A	2	0	(M)(O)

May be inoperative provided:

- The FWD OUTFLOW valve and DUMP functions are verified operative,
- The AFT OUTFLOW valve is verified open,
- The flight is conducted in an unpressurized configuration, at or below 10,000 feet MSL, in accordance with AFM Supplement 113, UNPRESSURIZED FLIGHT – BLEED ON, and
- Repairs are made within three flight days.

Minimum Equipment List Procedures (MELP)

NOTE: Failure of the pressurization system is typically evident in flight. To avoid a ground delay, it is advantageous to verify operation of the alternate cabin pressure control system and the outflow valve dump function prior to landing. An appropriate entry must be made in the aircraft journey log.

Placard

Inoperative Cabin Pressure Control system must be placarded in the flight compartment.

Operating Procedures

Flights must be conducted in an unpressurized configuration, at or below 10,000 feet MSL in accordance with AFM Supplement 113, UNPRESSURIZED FLIGHT – BLEED ON.

Maintenance Procedures

NOTE: This function will require engine starting and running of engine #1 OR APU and an assistant outside the aircraft.

WARNING: INSTALL LANDING GEAR GROUND LOCK PINS TO THE MAIN LANDING GEAR. ENGAGE THE NOSE LANDING GEAR GROUND LOCK.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-30-5. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-30-5 Cabin Pressure Control System****21-30-5-1 AUTO and MAN Modes**

1. Apply DC electrical power adequate to support the Main Busses.
2. Ensure all doors are closed.
3. Start No. 1 engine and stabilize at FLT IDLE, OR start APU (Ensure there is air in the Reservoir Tank to inflate the door seals).
4. Select the following on the Cabin Pressure (CABIN ALTITUDE) Control Panel (CPCP):
 - a) AUTO/MAN/DUMP switch – MAN.
 - b) FWD OUTFLOW knob – CLSD position.
5. At the co-pilot's side console, select the FWD SAFETY (OUTFLOW) VALVE selector to NORMAL.
6. If running engine, select the following on the AIR CONDITIONING panel:
 - a) BLEED #1 switch – BLEED 1
 - b) CABIN PACK switch – AUTO
 - c) BLEED MIN/NORM/MAX flow control knob – MAX

OR

If running APU:

- a) Select on the APU Control Panel: BL Air switch – open
 - b) Select on the AIR CONDITIONING panel: CABIN PACK switch – AUTO
7. Advance PLA #2 to the take-off rating detent, greater than 60 degrees.
8. At the CPCP, select and hold the MAN DIFF switch to the INCR position.
9. Check that the cabin begins to pressurize, as indicated on the DIFF indicator gauge on the Cabin Indication Module.
10. Hold the MAN DIFF switch until the DIFF indication gauge on the Cabin Indication Module reads 2 ± 0.2 psi, then, release the MAN DIFF switch.
11. At the CPCP, slowly turn the FW OUTFLOW knob to OPN, and check that the cabin begins to depressurize as indicated on the Cabin Indication Module.
12. Slowly turn the FWD OUTFLOW knob to the CLSD position and check that the cabin starts to pressurize as indicated on the Cabin Indication Module.
13. At the co-pilot's side console, move the FWD SAFETY (OUTFLOW) VALVE SELECTOR to the NORMAL position and check that the cabin remains pressurized.
14. At the CPCP, set the AUTO/MAN/DUMP switch to DUMP and check that the cabin begins to depressurize as indicated on the Cabin Indication Module. This indicates that the aft outflow valve has opened properly.
15. Placard the Cabin Pressure Control System (CPCS) on the CPCP with "CPCS (AUTO/MANUAL) INOP".
16. Make appropriate entry in the aircraft journey log.

ISS III R00**APPROVED BY DAW DELHI, DATE: 07-Jun-2024**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-30-5. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-30-5 Cabin Pressure Control System****21-30-5-2 AUTO Mode**

Interval	Installed	Required	Procedure
A	1	0	(M)

May be inoperative provided:

- MAN control is verified operative,
- The FWD OUTFLOW control and the DUMP function are verified operative,
- Cabin RATE Indicator, Cabin ALT Indicator, and Cabin DIFF Pressure Indicator are verified operative, and
- Repairs are made within three flight days.

Minimum Equipment List Procedures (MELP)

NOTE: Failure of the pressurization system is typically evident in flight. To avoid a ground delay, it is advantageous to verify operation of the alternate cabin pressure control system and the outflow valve dump function prior to landing. An appropriate entry must be made in the aircraft journey log.

Placard

Inoperative Cabin Pressure Control system must be placarded in the flight compartment.

Operating Procedures

None required

Maintenance Procedures

Verification of Manual (MAN) control, DUMP function and FWD SAFETY (OUTFLOW) Valve control on ground.

1. Apply DC electrical power adequate to support the Main Busses.
2. Ensure all doors are closed.
3. Start No. 1 engine and stabilize at FLT IDLE, OR start APU (ensuring there is air in the Reservoir Tank to inflate the door seals).

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATE -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-30-5. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-30-5 Cabin Pressure Control System****21-30-5-2 AUTO Mode**

4. Select the following on the Cabin Pressure (CABIN ALTITUDE) Control panel (CPCP):
 - a) AUTO/MAN/DUMP switch – MAN.
 - b) FWD OUTFLOW knob – CLSD position.
5. If running engine, select the following on the AIR CONDITIONING panel:
 - a) BLEED #1 switch – BLEED
 - b) BLEED MIN/NORM/MAX flow control knob – MAX

OR

If running APU, select BL AIR OPEN on APU Control Panel.

6. Advance PLA #2 to the take-off rating detent, greater than 60 degrees.
7. Control the cabin pressure rate through MAN DIFF toggle switch on the (CPCP). Select INCR to a value of minus (down) 300 ft/min as observed on the RATE indication on the Cabin Indication Module.
8. Observe normal operation of DIFF indication increasing and make note of the ALT level (downward) on the Cabin Indication Module.
9. Without changing the rate of pressurization, select FWD Safety (OUTFLOW) VALVE selector on co-pilot's side console panel to OPEN and check that ALT begins to increase on the Cabin Indication Module.
10. Return FWD SAFETY (OUTFLOW) VALVE selector on co-pilot's side console panel to NORMAL and check that ALT starts to decrease on the Cabin Indication Module.
11. On the CPCP, select the FWD OUTFLOW knob to INCR and observe that ALT increases on the Cabin Indication Module.
12. Return the knob to the CLSD position and confirm the CAB ALT decreases on the Cabin Indication Module.
13. On the CPCP, set AUTO/MAN/DUMP switch to DUMP position and check that ALT increases on the Cabin Indication Module.
14. On the CPCP, set AUTO/MAN/DUMP switch to MAN position.
15. Depressurize aircraft – MAN DIFF toggle switch selected to DECR.
16. Shut down engine OR APU.
17. Placard the Cabin Pressure Control System (CPCS) on the CPCP with "AUTO MODE INOP".
18. Make appropriate entry in the aircraft journey log.

ISS III R00**APPROVED BY DAW DELHI, DATE: 07-Jun-2024**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-30-5. 4

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-30-5 Cabin Pressure Control System****21-30-5-3 MAN Mode**

Interval	Installed	Required	Procedure
C	1	0	(M)

May be inoperative provided:

- AUTO control is verified operative,
- The FWD OUTFLOW control and the DUMP function are verified operative,
- Cabin RATE Indicator, Cabin ALT Indicator, and Cabin DIFF Pressure Indicator are verified operative.

Minimum Equipment List Procedures (MELP)

NOTE: Failure of the pressurization system is typically evident in flight. To avoid a ground delay, it is advantageous to verify operation of the alternate cabin pressure control system and the outflow valve dump function prior to landing. An appropriate entry must be made in the aircraft journey log.

Placard

Inoperative Cabin Pressure Control system must be placarded in the flight compartment.

Operating Procedures

None required

MAINTENANCE (M) PROCEDURES

Verification of Automatic (AUTO) control and AFT OUTFLOW valve DUMP function and FWD SAFETY (OUTFLOW) valve DUMP function.

- Apply DC electrical power adequate to support the Main Busses.
- Ensure all doors are closed.
- Start No. 1 engine and stabilize at FLT IDLE, OR start APU (ensuring there is air in the Reservoir Tank to inflate the door seals).
- Select the following on the Cabin Pressure (CABIN ALTITUDE) Control Panel:
 - AUTO/MAN/DUMP switch – AUTO.
 - FWD OUTFLOW knob – CLSD.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DAT 00 –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-30-5. 5

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-30-5 Cabin Pressure Control System****21-30-5-3 MAN Mode**

- c) LDG ALT – field altitude minus 600 ft.
5. Ensure that ALT on Cabin Indication Module is at field altitude of ± 100 ft and record ALT reading.
6. If running engine, select the following on the AIR CONDITIONING (AC) panel:
- a) BLEED #1 switch – BLEED
 - b) BLEED MIN/NORM/MAX flow control knob – MIN

OR

If running APU, select BL AIR OPEN on APU Control Panel.

7. Check that ALT on the Cabin Indication Module reads 30 ft (± 20 ft) less than reading taken in step (5).
8. On the AC panel, select BLEED flow control knob to MAX and check that ALT indicator on the Cabin Indication Module reads 150 ft (± 75 ft) less than the reading taken in step (5) and record reading.
9. Advance PLA #2 to the take-off rating detent, greater than 60 degrees.
10. Check the following indications on the Cabin Indication Module:
- a) RATE (FPM) – up to 300 ft/min DOWN, then steady.
 - b) ALT – descent towards 400 ft (± 150 ft) less than value taken in step (5) then steady.
 - c) Record ALT reading.
 - d) DIFF (PSI) – equal to 0.2 psi (0.1 psi)
11. At the CPCP, select the AUTO/MAN/DUMP switch to DUMP and observe on the Cabin Indication Module that the DIFF drops to zero and the ALT rises to field elevation.
12. At the CPCP, select the AUTO/MAN/DUMP switch to AUTO and observe DIFF increases on the Cabin Indication Module.
13. Select FWD SAFETY (OUTFLOW) VALVE selector on the co-pilot's side console panel to OPEN and check that DIFF decreases on the Cabin Indication Module.
14. Select FWD SAFETY (OUTFLOW) VALVE selector on the co-pilot's side console panel to NORMAL and check that DIFF increases on the Cabin Indication Module.
15. Select power levers to FLT IDLE and depressurize aircraft.
16. Shut down engine OR APU.
17. Placard the Cabin Pressure Control System (CPCS) on the CPCP with "MAN MODE INOP".
18. Make appropriate entry in the aircraft journey log.

ISS III R00**APPROVED BY DAW DELHI, DATE: 07-Jun-2024**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-30-5. 6

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-30-6 Aft Valves****21-30-6-1 Aft Outflow Valve**

Interval	Installed	Required	Procedure
C	1	0	(M)(O)

May be inoperative provided:

- The AFT OUTFLOW valve is verified open, and
- Flight is conducted in an unpressurized configuration, at or below 10,000 feet MSL, in accordance with AFM Supplement 113, UNPRESSURIZED FLIGHT – BLEED ON.

Minimum Equipment List Procedures (MELP)**Placard**

AUTO and MAN pressurization must be placarded inoperative in the flight compartment.

Operating Procedures

Carry out unpressurized flight in accordance with AFM Supplement 113, UNPRESSURIZED FLIGHT – BLEED ON.

Maintenance Procedures

1. Apply DC electrical power adequate to support the Main Busses.
2. Ensure all doors are closed.
3. Start No. 1 engine and stabilize at FLT IDLE, OR start APU (ensuring there is air in the Reservoir Tank to inflate the door seals).
4. Select the following on the CABIN ALTITUDE panel:
 - a) AUTO/MAN/DUMP switch – MAN
 - b) FWD OUTFLOW knob – CLSD position.
5. If running engine, select the following on the AIR CONDITIONING panel:
 - a) BLEED 1 switch – BLEED
 - b) BLEED flow control selector – MAX.

OR

If running APU, select BL AIR OPEN on APU Control Panel.
6. Advance PLA #2 to the take-off detent, greater than 60 degrees.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-30-6. 1



DHC-8-402

MINIMUM EQUIPMENT LIST

AIR CONDITIONING

ATA 21

21-30-6 Aft Valves

21-30-6-1 Aft Outflow Valve

7. Attempt to control the cabin pressure rate through MAN/DIFF toggle switch on the CABIN ALTITUDE panel, selecting to INCR, and observing the CAB RATE and CAB DIFF indications on the CABIN INDICATION MODULE.
8. Observe that the aircraft does not allow pressurization and that the CAB ALT level does not change.
9. On the CABIN ALTITUDE panel, set AUTO/MAN/DUMP switch to DUMP position.
10. Shut down engine or APU.
11. Placard the CABIN ALTITUDE panel with AUTO/MAN MODES INOP – SWITCH MUST REMAIN IN DUMP.
12. Make appropriate entry in the aircraft journey log with reference to the inoperative outflow/safety valve.

■ ■ ■ ■

ISS III R00

APPROVED BY DAW DELHI, DATED –

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-30-6. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-30-6 Cabin Pressure Control System****21-30-6-2 Aft Safety Valve**

Interval	Installed	Required	Procedure
C	1	0	(M)(O)

May be inoperative provided:

- The AFT OUTFLOW valve is verified open, and
- Flight is conducted in an unpressurized configuration, at or below 10,000 feet MSL, in accordance with AFM Supplement 113, UNPRESSURIZED FLIGHT – BLEED ON.

Minimum Equipment List Procedures (MELP)**Placard**

AUTO and MAN pressurization must be placarded inoperative in the flight compartment.

Operating Procedures

Carry out unpressurized flight in accordance with AFM Supplement 113, UNPRESSURIZED FLIGHT – BLEED ON.

Maintenance Procedures

1. Apply DC electrical power adequate to support the Main Busses.
2. Ensure all doors are closed.
3. Start No. 1 engine and stabilize at FLT IDLE, OR start APU (ensuring there is air in the Reservoir Tank to inflate the door seals).
4. Select the following on the CABIN ALTITUDE panel:
 - a) AUTO/MAN/DUMP switch – MAN
 - b) FWD OUTFLOW knob – CLSD position.
5. If running engine, select the following on the AIR CONDITIONING panel:
 - a) BLEED 1 switch – BLEED
 - b) BLEED flow control selector – MAX.

OR

If running APU, select BL AIR OPEN on APU Control Panel.
6. Advance PLA #2 to the take-off detent, greater than 60 degrees.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED –****Signature valid**

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-30-6. 3



DHC-8-402

MINIMUM EQUIPMENT LIST

AIR CONDITIONING

ATA 21

21-30-6 Aft Valves

21-30-6-2 Aft Safety Valve

7. Attempt to control the cabin pressure rate through MAN/DIFF toggle switch on the CABIN ALTITUDE panel, selecting to INCR, and observing the CAB RATE and CAB DIFF indications on the CABIN INDICATION MODULE.
8. Observe that the aircraft does not allow pressurization and that the CAB ALT level does not change.
9. On the CABIN ALTITUDE panel, set AUTO/MAN/DUMP switch to DUMP position.
10. Shut down engine or APU.
11. Placard the CABIN ALTITUDE panel with AUTO/MAN MODES INOP – SWITCH MUST REMAIN IN DUMP.
12. Make appropriate entry in the aircraft journey log with reference to the inoperative outflow/safety valve.

■ ■ ■ ■

ISS III R00

APPROVED BY DAW DELHI, DATED –

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-30-6. 4

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-50-1 Air Cycle Machines (ACM)**

Interval	Installed	Required	Procedure
C	2	1	NIL

May be inoperative provided the associated PACKS switch is selected and remains OFF.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Air Cycle Machine must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard the associated "PACK" on the AIR CONDITIONING panel in the flight compartment "INOP".
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-50-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-50-2 Turbine Shut-Off Valves**

Interval	Installed	Required	Procedure
C	2	1	(M#)

May be inoperative provided:

- Turbine Shut-Off Valve is secured in the closed position, and
- Associated PACKS switch is selected and remains OFF.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Air Cycle Machine - related to the failed Turbine Shut-Off Valve (TSOV) - must be placarded in the flight compartment.

Operating Procedures

None required

Maintenance Procedures

1. Manually operate and lock the associated Turbine Shut-Off Valve in the closed position by first removing the locking pin on the Turbine Shut-Off Valve from its normally installed position on the valve.
2. Use a wrench to turn the crank on the valve to the closed position.
3. Install the locking pin to maintain the valve in the locked position.
4. Placard "PACK" switch associated with the inoperative TSOV, on the AIR CONDITIONING panel in the flight compartment as "INOP".
5. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-50-2. 1



Interval	Installed	Required	Procedure
C	2	1	(M#)

- a) Pack Bypass Valve is locked in the closed position, and
- b) Associated PACKS switch is selected and remains OFF.

1. Remove the locking screw from the actuator housing. It has a retaining cable.
2. Turn the valve to the closed position. The linkage crank has a hex head so you can put a wrench on it to turn the valve.
3. Install the locking screw in the hole in the actuator housing that is nearest to the linkage crank. This will lock the valve in the closed position.
4. Placard "PACKS" switch associated with the inoperative Pack Bypass Valve, on the AIR CONDITIONING panel in the flight compartment as "INOP".
5. Make appropriate entry in the aircraft journey log.

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-60-1 CABIN TEMP CONTROL****21-60-1-1 AUTO and MAN Modes**

Interval	Installed	Required	Procedure
C	1	0	(M)

May be inoperative provided:

- The associated CABIN PACK is considered inoperative and is selected and remains OFF, and
- FLT COMP TEMP CONTROL is verified operative.

Minimum Equipment List Procedures (MELP)

NOTE: Failure of the AUTO Temperature Control system is typically evident in flight. To avoid a ground delay, it is advantageous to verify operation of the MAN Temperature Control system and the Temperature Gauge function prior to landing. An appropriate entry must be made in the aircraft journey log.

Placard

Inoperative CABIN TEMP CONTROL Mode(s) must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

- Start either No. 1 or No. 2 engine and select POWER lever to FLT IDLE, OR start APU (ensuring there is air in the Reservoir Tank to inflate the door seals).
- If running engine select AIR CONDITIONING controls as follows:
 - Applicable BLEED 1 or 2 switch – BLEED 1 or 2.
 - OFF–MAN–AUTO PACKS switches to MAN.
 - TEMP CONTROL selectors to mid positions.
 - BLEED flow selector to – MAX.
 - RECIRC fan – RECIRC.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-60-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-60-1 CABIN TEMP CONTROL****21-60-1-1 AUTO and MAN Modes**

OR

If running APU, select BL AIR OPEN on APU Control Panel and select AIR CONDITIONING controls as follows:

- a) OFF-MAN-AUTO PACKS switches to MAN.
 - b) TEMP CONTROL selectors to mid positions.
 - c) RECIRC fan – RECIRC.
3. Allow the air conditioning system to stabilize. (Note CABIN DUCT, FC DUCT and CABIN temperatures on TEMPERATURE GAUGE using the GAUGE SWITCH).

Verify Flight Compartment Temp Control Operates Normally

1. AUTO Mode Inoperative – Verify Manual Flight Comp Temp Control Operates Normally
 - a) Select FLT COMP PACK switch to MAN position.
 - b) Rotate the FLT COMP CONTROL rotary knob to full WARM position.
 - c) After waiting approximately 60 to 90 seconds, confirm that the observed temperature trend is increasing, using the Temperature Gauge.
 - d) Rotate the FLT COMP CONTROL rotary knob to full COOL position.
 - e) After waiting approximately 60 to 90 seconds, confirm that the observed temperature trend is decreasing, using the Temperature Gauge.
 - f) Return the temperature control knobs to mid-range position.
2. MAN Mode Inoperative – Verify Auto Flight Comp Temp Control Operates Normally
 - a) Select FLT COMP PACK switch to AUTO position.
 - b) Rotate the FLT COMP CONTROL rotary knob to full WARM position.
 - c) After waiting approximately 60 to 90 seconds, confirm that the observed temperature trend is increasing, using the Temperature Gauge.
 - d) Rotate the FLT COMP CONTROL rotary knob to full COOL position.
 - e) After waiting approximately 60 to 90 seconds, confirm that the observed temperature trend is decreasing, using the Temperature Gauge.
 - f) Return the temperature control knobs to mid-range position.
3. Select appropriate engine or APU BLEED switch to OFF and OFF/MAN/AUTO PACKS switches of OFF.
4. Placard Cabin Temperature Control on AIR CONDITIONING panel in the flight compartment.
5. Make appropriate entry in the aircraft journey log.

ISS III R00**APPROVED BY DAW DELHI, DATE -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-60-1. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-60-1 CABIN TEMP CONTROL****21-60-1-2 AUTO Mode**

Interval	Installed	Required	Procedure
C	1	0	(M)

May be inoperative provided:

- MAN control is verified operative, and
- DUCT TEMP indicator is verified operative.

Minimum Equipment List Procedures (MELP)

NOTE: Failure of the AUTO Temperature Control system is typically evident in flight. To avoid a ground delay, it is advantageous to verify operation of the MAN Temperature Control system and the Temperature Gauge function prior to landing. An appropriate entry must be made in the aircraft journey log.

Placard

Inoperative CABIN TEMP CONTROL Mode(s) must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

- Start either No. 1 or No. 2 engine and select POWER lever to FLT IDLE, OR start APU (ensuring there is air in the Reservoir Tank to inflate the door seals).
- If running engine select AIR CONDITIONING controls as follows:
 - Applicable BLEED 1 or 2 switch – BLEED 1 or 2.
 - OFF-MAN-AUTO PACKS switches to MAN.
 - TEMP CONTROL selectors to mid positions.
 - BLEED flow selector to – MAX.
 - RECIRC fan – RECIRC.

OR

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATE –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-60-1. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-60-1 CABIN TEMP CONTROL****21-60-1-2 AUTO Mode**

If running APU, select BL AIR OPEN on APU Control Panel and select AIR CONDITIONING controls as follows:

- a) OFF-MAN-AUTO PACKS switches to MAN.
 - b) TEMP CONTROL selectors to mid positions.
 - c) RECIRC fan – RECIRC.
3. Allow the air conditioning system to stabilize. (Note CABIN DUCT, FC DUCT and CABIN temperatures on TEMPERATURE GAUGE using the GAUGE SWITCH).

Verify Manual Control Operates Normally

1. Select CABIN PACK switch to MAN position.
2. Rotate the CABIN TEMP CONTROL rotary knob to full WARM position.
3. After waiting approximately 60 to 90 seconds, confirm that the observed temperature trend is increasing, using the Temperature Gauge.
4. Rotate the CABIN TEMP CONTROL rotary knob to full COOL position.
5. After waiting approximately 60 to 90 seconds, confirm that the observed temperature trend is decreasing, using the Temperature Gauge.
6. Return the temperature control knobs to mid-range position.
7. Select appropriate engine or APU BLEED switch to OFF and OFF/MAN/AUTO PACKS switches to OFF.
8. Placard Cabin Temperature Control on AIR CONDITIONING panel in the flight compartment.
9. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-60-1. 4

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-60-1 CABIN TEMP CONTROL****21-60-1-3 MAN Mode**

Interval	Installed	Required	Procedure
C	1	0	(M)

May be inoperative provided AUTO control is verified operative.

Minimum Equipment List Procedures (MELP)

NOTE: Failure of the AUTO Temperature Control system is typically evident in flight. To avoid a ground delay, it is advantageous to verify operation of the MAN Temperature Control system and the Temperature Gauge function prior to landing. An appropriate entry must be made in the aircraft journey log.

Placard

Inoperative CABIN TEMP CONTROL Mode(s) must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Start either No. 1 or No. 2 engine and select POWER lever to FLT IDLE, OR start APU (ensuring there is air in the Reservoir Tank to inflate the door seals).
2. If running engine select AIR CONDITIONING controls as follows:
 - a) Applicable BLEED 1 or 2 switch – BLEED 1 or 2.
 - b) OFF-MAN-AUTO PACKS switches to MAN.
 - c) TEMP CONTROL selectors to mid positions.
 - d) BLEED flow selector to – MAX.
 - e) RECIRC fan – RECIRC.

OR

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-60-1. 5

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-60-1 CABIN TEMP CONTROL****21-60-1-3 MAN Mode**

If running APU, select BL AIR OPEN on APU Control Panel and select AIR CONDITIONING controls as follows:

- a) OFF-MAN-AUTO PACKS switches to MAN.
 - b) TEMP CONTROL selectors to mid positions.
 - c) RECIRC fan – RECIRC.
3. Allow the air conditioning system to stabilize. (Note CABIN DUCT, FC DUCT and CABIN temperatures on TEMPERATURE GAUGE using the GAUGE SWITCH).

Verify Automatic Control Operates Normally

1. Select CABIN PACK switch to AUTO position.
2. Rotate the CABIN TEMP CONTROL rotary knob to full WARM position.
3. After waiting approximately 60 to 90 seconds, confirm that the observed temperature trend is increasing, using the Temperature Gauge.
4. Rotate the CABIN TEMP CONTROL rotary knob to full COOL position.
5. After waiting approximately 60 to 90 seconds, confirm that the observed temperature trend is decreasing, using the Temperature Gauge.
6. Return the temperature control knobs to mid-range position.
7. Select appropriate engine or APU BLEED switch to OFF and OFF/MAN/AUTO PACKS switches to OFF.
8. Placard Cabin Temperature Control on AIR CONDITIONING panel in the flight compartment.
9. Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-60-1. 6

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-60-2 DUCT TEMP GAUGE**

Interval	Installed	Required	Procedure
C	1	0	NIL

May be inoperative provided Flight Attendant Temperature Control is operative and flights are conducted in accordance with AFM supplement 85, Operation with inoperative CAB DUCT/CABIN/FC Duct Gauge.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative DUCT TEMP Indicator or individual function must be placarded in the flight compartment.

Operating Procedures

None required

Maintenance Procedures

1. Placard inoperative DUCT TEMP Indicator and/or function on AIR CONDITIONING panel in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-60-2. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-60-2 DUCT TEMP GAUGE****21-60-2-1 CABIN Temperature**

Interval	Installed	Required	Procedure
C	1	0	NIL

May be inoperative provided Flight Attendant Temperature Control is operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative DUCT TEMP Indicator or individual function must be placarded in the flight compartment.

Operating Procedures

None required

Maintenance Procedures

1. Placard inoperative DUCT TEMP Indicator and/or function on AIR CONDITIONING panel in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-60-2. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-60-2 DUCT TEMP GAUGE****21-60-2-2 CAB DUCT Temperature**

Interval	Installed	Required	Procedure
C	1	0	NIL

May be inoperative provided flights are conducted in accordance with AFM supplement 85, Operation with Inoperative CAB DUCT/CABIN/FC Duct Gauge.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative DUCT TEMP Indicator or individual function must be placarded in the flight compartment.

Operating Procedures

None required

Maintenance Procedures

1. Placard inoperative DUCT TEMP Indicator and/or function on AIR CONDITIONING panel in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-60-2. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-60-2 DUCT TEMP GAUGE****21-60-2-3 FC DUCT Temperature**

Interval	Installed	Required	Procedure
C	1	0	NIL

May be inoperative provided flights are conducted in accordance with AFM supplement 85, Operation with Inoperative CAB DUCT/CABIN/FC Duct Gauge.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative DUCT TEMP Indicator or individual function must be placarded in the flight compartment.

Operating Procedures

None required

Maintenance Procedures

1. Placard inoperative DUCT TEMP Indicator and/or function on AIR CONDITIONING panel in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-60-2. 4

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-60-3 FLT COMP TEMP****21-60-3-1 AUTO and MAN Modes**

Interval	Installed	Required	Procedure
C	2	0	(M)

Both may be inoperative provided:

- The associated FLT COMP PACK is considered inoperative and is selected and remains OFF, and
- CABIN TEMP CONTROL (AUTO & MANUAL) is verified operative.

Minimum Equipment List Procedures (MELP)

NOTE: Failure of the AUTO Temperature Control system is typically evident in flight. To avoid a ground delay, it is advantageous to verify operation of the MAN Temperature Control system and the Temperature Gauge function prior to landing. An appropriate entry must be made in the aircraft journey log.

Placard

Inoperative FLT COMP TEMP CONTROL Mode(s) must be placarded in the flight compartment.

Operating Procedures

None required

Maintenance Procedures

- Start either No. 1 or No. 2 engine and select POWER lever to FLT IDLE, OR start APU (ensuring there is air in the Reservoir Tank to inflate the door seals).
- If running engine select the following on the AIR CONDITIONING panel:
 - Applicable BLEED #1 or #2 switch – BLEED 1 or BLEED 2.
 - OFF–MAN–AUTO PACKS switches to (CABIN and FLT COMP) – MAN.
 - TEMP CONTROL (CABIN and FLT COMP) selectors to midrange position.
 - BLEED flow selector – MAX.
 - RECIRC switch – RECIRC.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-60-3. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-60-3 FLT COMP TEMP****21-60-3-1 AUTO and MAN Modes**

OR

If running APU, select BL AIR OPEN on the APU Control Panel and select the following on the AIR CONDITIONING panel:

- a) OFF/MAN/AUTO PACKS switches (CABIN and FLT COMP) – MAN.
 - b) TEMP CONTROL (CABIN and FLT COMP) selectors to midrange position.
 - c) RECIRC switch – RECIRC.
3. Allow the air conditioning system to stabilize. (Note the CABIN DUCT and FC DUCT temperatures on Temperature Gauge by utilizing the CABIN GAUGE knob/switch on the AIR CONDITIONING panel).
4. Verify Manual (MAN) CABIN TEMP CONTROL operates normally
- a) Select CABIN PACK (Located on the left side, on the Air Conditioning Panel) to MAN position.
 - b) Rotate the CABIN TEMP CONTROL rotary knob to full WARM (clockwise) position.
 - c) After waiting approximately 60 to 90 seconds, confirm that the observed temperature trend is increasing, on the temperature gauge (CABIN DUCT selected on the CABIN GAUGE knob/switch).
 - d) Rotate the CABIN TEMP CONTROL rotary knob to full COOL (counter clockwise) position.
 - e) After waiting approximately 60 to 90 seconds, confirm that the observed temperature trend is decreasing, on the temperature gauge.
 - f) Return the CABIN TEMP CONTROL rotary knob to midrange position.
5. Verify Automatic (AUTO) CABIN TEMP CONTROL operates normally.
- a) Select CABIN PACK (Located on the left side, on the Air Conditioning Panel) to AUTO position.
 - b) Rotate the CABIN TEMP CONTROL rotary knob to full WARM (clockwise) position.
 - c) After waiting approximately 60 to 90 seconds, confirm that the observed temperature trend is increasing, on the temperature gauge (CABIN DUCT selected on the CABIN GAUGE knob/switch).
 - d) Rotate the CABIN TEMP CONTROL rotary knob to full COOL (counter clockwise) position.
 - e) After waiting approximately 60 to 90 seconds, confirm that the observed temperature trend is decreasing on the temperature gauge.

*(...Continued)***ISS III R00****APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-60-3. 2



DHC-8-402

MINIMUM EQUIPMENT LIST

AIR CONDITIONING

ATA 21

21-60-3 FLT COMP TEMP

21-60-3-1 AUTO and MAN Modes

- f) Return the CABIN TEMP CONTROL rotary knob to midrange position.
6. Select appropriate engine, or APU BLEED switch to OFF, and OFF/MAN/AUTO PACKS switches to OFF.
 7. Placard Flight Compartment Temperature Control on AIR CONDITIONING panel in the flight compartment.
 8. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00

APPROVED BY DAW DELHI, DATED -

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-60-3. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-60-3 FLT COMP TEMP****21-60-3-2 AUTO Mode**

Interval	Installed	Required	Procedure
C	1	0	(M)

May be inoperative provided:

- MAN control is verified operative, and
- DUCT TEMP indicator is verified operative.

Minimum Equipment List Procedures (MELP)

NOTE: Failure of the AUTO Temperature Control system is typically evident in flight. To avoid a ground delay, it is advantageous to verify operation of the MAN Temperature Control system and the Temperature Gauge function prior to landing. An appropriate entry must be made in the aircraft journey log.

Placard

Inoperative FLT COMP TEMP CONTROL Mode(s) must be placarded in the flight compartment.

Operating Procedures

None required

Maintenance Procedures

- Start either No. 1 or No. 2 engine and select POWER lever to FLT IDLE, OR start APU (ensuring there is air in the Reservoir Tank to inflate the door seals).
- If running engine select the following on the AIR CONDITIONING panel:
 - Applicable BLEED #1 or #2 switch – BLEED 1 or BLEED 2.
 - OFF–MAN–AUTO PACKS switches to (CABIN and FLT COMP) – MAN.
 - TEMP CONTROL (CABIN and FLT COMP) selectors to midrange position.
 - BLEED flow selector – MAX.
 - RECIRC switch – RECIRC.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-60-3. 4

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-60-3 FLT COMP TEMP****21-60-3-2 AUTO Mode**

OR

If running APU, select BL AIR OPEN on the APU Control Panel and select the following on the AIR CONDITIONING panel:

- d) OFF/MAN/AUTO PACKS switches (CABIN and FLT COMP) – MAN.
 - e) TEMP CONTROL (CABIN and FLT COMP) selectors to midrange position.
 - f) RECIRC switch – RECIRC.
3. Allow the air conditioning system to stabilize. (Note the CABIN DUCT and FC DUCT temperatures on Temperature Gauge by utilizing the CABIN GAUGE knob/switch on the AIR CONDITIONING panel).

Verify Manual (MAN) FLT COMP TEMP CONTROL operates normally.

- 4. Select FLT COMP PACK switch to MAN position (Located on the right side, on the Air Conditioning Panel).
- 5. Rotate the FLT COMP TEMP CONTROL rotary knob to full WARM (clockwise) position
- 6. After waiting approximately 60 to 90 seconds, confirm that the observed temperature trend is increasing, on the temperature gauge (FC DUCT selected on the CABIN GAUGE knob/switch).
- 7. Rotate the FLT COMP TEMP CONTROL rotary knob to full COOL (counter clockwise) position.
- 8. After waiting approximately 60 to 90 seconds, confirm that the observed temperature trend is decreasing, on the temperature gauge.
- 9. Return the FLT COMP TEMP CONTROL rotary knob to midrange position.
- 10. Select appropriate engine, or APU BLEED switch to OFF, and OFF/MAN/AUTO PACKS switches to OFF.
- 11. Placard Flight Compartment Temperature Control on AIR CONDITIONING panel in the flight compartment.
- 12. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-60-3. 5

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-60-3 FLT COMP TEMP****21-60-3-3 MAN Mode**

Interval	Installed	Required	Procedure
C	1	0	(M)

May be inoperative provided AUTO control is operative.

Minimum Equipment List Procedures (MELP)

NOTE: Failure of the AUTO Temperature Control system is typically evident in flight. To avoid a ground delay, it is advantageous to verify operation of the MAN Temperature Control system and the Temperature Gauge function prior to landing. An appropriate entry must be made in the aircraft journey log.

Placard

Inoperative FLT COMP TEMP CONTROL Mode(s) must be placarded in the flight compartment.

Operating Procedures

None required

Maintenance Procedures

1. Start either No. 1 or No. 2 engine and select POWER lever to FLT IDLE, OR start APU (ensuring there is air in the Reservoir Tank to inflate the door seals).
2. If running engine select the following on the AIR CONDITIONING panel:
 - a) Applicable BLEED #1 or #2 switch – BLEED 1 or BLEED 2.
 - b) OFF-MAN-AUTO PACKS switches to (CABIN and FLT COMP) – MAN.
 - c) TEMP CONTROL (CABIN and FLT COMP) selectors to midrange position.
 - d) BLEED flow selector – MAX.
 - e) RECIRC switch – RECIRC.

OR

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATE: 07-Jun-2024**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-60-3. 6

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-60-3 FLT COMP TEMP****21-60-3-2 AUTO Mode**

If running APU, select BL AIR OPEN on the APU Control Panel and select the following on the AIR CONDITIONING panel:

13. OFF/MAN/AUTO PACKS switches (CABIN and FLT COMP) – MAN.
14. TEMP CONTROL (CABIN and FLT COMP) selectors to midrange position.
15. RECIRC switch – RECIRC.
3. Allow the air conditioning system to stabilize. (Note the CABIN DUCT and FC DUCT temperatures on Temperature Gauge by utilizing the CABIN GAUGE knob/switch on the AIR CONDITIONING panel).

Verify Automatic (AUTO) FLT COMP TEMP CONTROL operates normally.

4. Select FLT COMP PACK switch to AUTO position (Located on the right side, on the Air Conditioning Panel).
5. Rotate the FLT COMP TEMP CONTROL rotary knob to full WARM (clockwise) position
6. After waiting approximately 60 to 90 seconds, confirm that the observed temperature trend is increasing, on the temperature gauge (FC DUCT selected on the CABIN GAUGE knob/switch).
7. Rotate the FLT COMP TEMP CONTROL rotary knob to full COOL (counter clockwise) position.
8. After waiting approximately 60 to 90 seconds, confirm that the observed temperature trend is decreasing, on the temperature gauge.
9. Return the FLT COMP TEMP CONTROL rotary knob to midrange position.
10. Select appropriate engine, or APU BLEED switch to OFF, and OFF/MAN/AUTO PACKS switches to OFF.
11. Placard Flight Compartment Temperature Control on AIR CONDITIONING panel in the flight compartment.
12. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-60-3. 7

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AIR CONDITIONING******ATA 21*****21-60-4 Flight Attendant Control Panel – Cabin Temperature Control and CABIN TEMP indication**

Interval	Installed	Required	Procedure
C	-	0	NIL

One or all functions/indications may be inoperative provided cabin temperature control is available from the flight deck.

NOTE: Flight Attendant control of cabin temperature is not available if MANUAL cabin temperature control is selected in the cockpit.

Minimum Equipment List Procedures (MELP)**Placard**

Placard the Flight Attendant Control Panel to indicate the Cabin Temperature Control and CABIN TEMP indication is inoperative.

Operating Procedures

None required

Maintenance Procedures

1. Place a placard on the Flight Attendant Control Panel in the cabin to indicate the Cabin Temperature Control and CABIN TEMP indication is inoperative.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

21-60-4. 1